



Master Cross Reference Chart

Updated April 5, 2010

Includes: Pro A/V, Keyboard, Guitar, Recording, and DJ gear

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
360 Systems	DR600	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17		
3M	S15	Projector	GAV-20				
3M	S40	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
3M	S50	Projector	GAV-1412-R	GAV-PE-1412R			
3M	S55	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
3M	X40	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
3M	X45	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
3M	X50	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
3M	X55	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
3M	X75	Projector	GAV-1412-R	GAV-PE-1412R			
Access	VIRUS CLASSIC	Keyboard	G-MEDIA PROBPXL				
Access	VIRUS TI 61	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Access	VIRUS TI DESKTOP	Keyboard	G-MEDIA PROBPXL				
Adam	SUB10	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Adam	SUB8	Speaker	GPA-600				
Adam Audio	SUB10 MKII	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Akai	APC40	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Akai	Miniak	Keyboard	G-MULTIFX-2411				
Akai	MPC1000	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Akai	MPC2000XL-MCD	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618A
Akai	MPC2500	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Akai	MPC4000 PLUS	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	GP-PC309	G-TOUR 19X21	GX-1921-7.5
Akai	MPC500	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Akai	MPC5000	Digital Audio Gear	GMC-2222	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
Akai	MPD 32	Digital Audio Gear	GKC-1540				
Akai	MPD16	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Akai	MPD24	Digital Audio Gear	G-MEDIA PRO BP	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	
Akai	MPK25	Digital Audio Gear	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOURCARRYONFO	
Akai	MPK49	Keyboard	GKC-1540				
Akai	MPK88	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Akai	PDP4290	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Akai	PDP4294	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Akai	PDP4298ED	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Akai	PDP4298ED1	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
AKG	AS16X12	Mixer	G-MIX 12X24				
AKG	AS8	Mixer	G-MIX 12X24				
AKG	AS8TC	Mixer	G-MIX 12X24				
AKG	WMS40	Wireless System	GM-1W	GM-1WP	GM-2W		
Akira -Neoart	EMP 500	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Akira -Neoart	EMP420A/B	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Akira -Neoart	HPT500AW	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Akira -Neoart	SV-4201	LCD/Plasma	G-LCDCOVER-42				
Akira -Neoart	SV-4201H	LCD/Plasma	G-LCDCOVER-42				
Akira -Neoart	SV4202IQ	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Alesis	A6	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Alesis	ANDROMEDA	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Alesis	CD TWIN LE	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Alesis	FUSION 6HD	Keyboard	GK-49	GKC-1540	G-TOUR 61		
Alesis	FUSION 8HD	Keyboard	GK-76	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Alesis	iMultiMix 16 USB	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-MIX-L 1724	G-MIX-L 1822
Alesis	iMULTIMIX 16USB	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-MIX-L 1724	G-MIX-L 1822
Alesis	iMULTIMIX 8USB	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Alesis	ION	Keyboard	GK-49	GKC-1540			
Alesis	MasterControl	Digital Audio Gear	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21
Alesis	MICRON	Keyboard	G-MULTIFX-2411				
Alesis	MULTIMIX 12 FIREWIRE	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR CDMX1317	
Alesis	MULTIMIX 12 FX	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Alesis	MULTIMIX 12 USB	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Alesis	MULTIMIX 12FXD	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Alesis	MULTIMIX 16 FIREWIRE	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR CDMX1317	
Alesis	MultiMix 4 USB	Mixer	G-MIX-B 1212				
Alesis	MULTIMIX 6FX	Mixer	G-MIX-B 1212				
Alesis	MULTIMIX 8 FW	Mixer	G-MIX-B 1212				
Alesis	MULTIMIX 8 FX	Mixer	G-MIX-B 1212				
Alesis	MULTIMIX 8 USB	Mixer	G-MIX-B 1212				
Alesis	MULTIMIX 8 USB 2.0	Mixer	G-MIX-B 1212				
Alesis	MULTIMIX12FIREWIRE	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A		
Alesis	MULTIMIX16FIREWIRE	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618A
Alesis	MULTIMIX8FIREWIRE	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Alesis	PHOTONX25	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
Alesis	QS6.2	Keyboard	GK-4212	GKB-49	GKPE-49-TSA		
Alesis	QS8.2	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Alesis	SR16	Digital Audio Gear	G-MIX-B 1212				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Alesis	SR-16	Digital Audio Gear	G-MIX-B 1212				
Alesis	STUDIO 24	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Allen & Heath	GL2400 16	Mixer	GMC-3333				
Allen & Heath	GL2400 24	Mixer	GMC-3333				
Allen & Heath	PA 12	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
Allen & Heath	PA 12-CP	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
Allen & Heath	PA-20	Mixer	GMC-3333				
Allen & Heath	WZ3:12:2	Mixer	G-MIX 20X25				
Allen & Heath	WZ3:12M	Mixer	G-MIX 20X25				
Allen & Heath	WZ3:14:4:2	Mixer	G-MIX 20X25				
Allen & Heath	WZ3:16:2	Mixer	G-MIX 20X25				
Allen & Heath	WZ3:20S	Mixer	G-MIX 20X25				
Allen & Heath	XONE 464	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Allen & Heath	ZED 420	Mixer	GMC-3333	G-TOUR 24X36			
Allen & Heath	ZED 436	Mixer	G-MIX 22X46				
Allen & Heath	ZED-12FX	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21	
Allen & Heath	ZED-14	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21	
Allen & Heath	ZED-22FX	Mixer	GMC-3333	G-MIX-L 1926	G-TOUR 20X30		
Allen & Heath	ZED-24	Mixer	GMC-3333	G-MIX-L 1926	G-TOUR 20X30		
Allen & Heath	ZED-R16	Mixer	GMC-3333	G-MIX 24X36	G-TOUR 20X30	G-TOUR 24X36	
Alto Audio	AMX 100	Mixer	G-MIX-B 1212				
Alto Audio	AMX 100 FX	Mixer	G-MIX-B 1212				
Alto Audio	L-12	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	GX-1718-7	
Alto Audio	L-16	Mixer	GMC-2222	G-MIX-B 2020			
Alto Audio	L-20	Mixer	GMC-2222	G-MIX-B 2020			
Alto Audio	L-6	Mixer	G-MIX-B 1212				
Alto Audio	L-8	Mixer	G-MIX-B 1212				
Alto Audio	PM-12 DRAGONFLY	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Alto Audio	S-12	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Alto Audio	S-16	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618A
Alto Audio	S-6	Mixer	G-MIX-B 1212				
Alto Audio	S-8	Mixer	G-MIX-B 1212				
Alvarez	AC60S	Acoustic Guitar	GWE-CLASSIC				
Alvarez	Artist Series AD60K Dao	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Alvarez	Artist Series AD60S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Alvarez	Artist Series AD70S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Alvarez	Artist Series AD80SSB	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Alvarez	CYM95	Acoustic Guitar	GWE-CLASSIC				
Alvarez	MC90	Acoustic Guitar	GWE-CLASSIC				
Alvarez	RC10	Acoustic Guitar	GWE-CLASSIC				
Alvarez	RD20S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Alvarez	RD8	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Alvarez	RD9	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
American Audio	CDI 300	CD/DVD Player	G-TOUR CD-13X17				
American Audio	CDI 300 MP3	CD/DVD Player	G-TOUR CD-13X17				
American Audio	CDI 500	CD/DVD Player	G-TOUR CD-13X17				
American Audio	CDI 500 MP3	CD/DVD Player	G-TOUR CD-13X17				
American Audio	CDS-1	CD/DVD Player	G-TOUR CD-9X12				
American Audio	CK-1000	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-MIX-L 1622	
American Audio	CK-800	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-MIX-L 1622	
American Audio	DLS-15	Speaker	GPA-700	GPA-SCVR450-515			
American Audio	DLS-15P	Speaker	GPA-700	GPA-SCVR450-515			
American Audio	HTD 4.5	Turntable	G-TOUR T-TABLE				
American Audio	MX-1400	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR CDMX1317	
American Audio	PSW-15	Speaker	G-SUB2225-24BAG				
American Audio	PSW-15P	Speaker	G-SUB2225-24BAG				
American Audio	PXI-12P	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
American Audio	PXI-15P	Speaker	GPA-700	GPA-SCVR450-515			
American Audio	Q-221	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
American Audio	Q-221/SX	Turntable	G-TOUR T-TABLE				
American Audio	Q-221/X	Turntable	G-TOUR T-TABLE				
American Audio	Q-D1	Mixer	G-MIX-B 1212				
American Audio	Q-D1 MKII	Mixer	G-MIX-B 1212				
American Audio	Q-D3	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
American Audio	Q-D5	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
American Audio	Q-D5 MKII	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
American Audio	Q-D5B	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
American Audio	Q-D6	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
American Audio	Q-MX2BPM	Mixer	G-MIX-B 1212				
American Audio	TTD-2500MKII	Turntable	G-TOUR T-TABLE				
American Audio	XDM-221	Mixer	G-MIX-B 1212				
American Audio	XDM-241	Mixer	G-MIX-B 1212				
Ampeg	BA600	Amp/Cabinet	G-TOUR-4X12-CAB				
Ampeg	J20	Amp/Cabinet	G-112-ROTO				
Anchor Audio	BWKII	Mixer	G-MIX-B 1515				
Anchor Audio	Liberty LIB-7500	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Apple	20 CINEMA DISPLAY	LCD/Plasma	G-TOURLCDP-2023				
Apple	M8893ZM/A	LCD/Plasma	G-TOURLCDP-2023				
Apple	MACBOOK 13"	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Apple	MACBOOK AIR	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Apple	MACBOOK PRO 15"	Laptop	GAV-1813-UR				
Apple	MACBOOK PRO 17"	Laptop	GAV-1813-UR				
Arp	ODYSSEY MKI (2800)	Digital Audio Gear	G-MIX 20X25	GP-PC309			
Arturia	ANALOG FACTORY	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
Ashly	LX308B	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYONFO	G-TOURCARRYONFO
Ashton	BA50	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Ashton	MPA100	Amp/Cabinet	G-112-ROTO				
Audio Technica	ATM351	Mixer	G-MIX-B 1815	G-TOUR 12X17	G-TOUR CDMX1317		
Audio Technica	ATMX341A	Mixer	G-MIX-B 1212				
Audio Technica	ATPL120	Turntable	G-TOUR T-TABLE				
Audio Technica	ATW2120	Wireless System	GM-1W	GM-2W	GM-5W		
Audio Technica	ATW-2129	Wireless System	GM-1W	GM-2W	GM-5W		
Audio Technica	ATW-2192-TH	Wireless System	GM-1W	GM-2W	GM-5W		
Audio Technica	ATW-251	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Audio Technica	ATW-251/H92-TH	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Audio Technica	ATW-252	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Audio Technica	ATW3131A	Wireless System	GM-1W	GM-2W			
Audio Technica	ATW3141A	Wireless System	GM-1W	GM-2W			
Audio Technica	ATW-3192A	Wireless System	GM-1W	GM-2W			
Audio Technica	ATW-3192A-TH	Wireless System	GM-1W	GM-2W			
Audio Technica	ATW-701	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Audio Technica	ATW-701 700 Series	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Audio Technica	ATW-701/H92-TH	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Audio Technica	ATW-702	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Azden	CAM3	Mixer	G-TOUR CDMX912				
B-52	AT-100	Amp/Cabinet	G-TOUR AMP HEAD				
B-52	AT112	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
B-52	AT212	Amp/Cabinet	G-TOUR AMP HEAD				
B-52	LG10012S	Amp/Cabinet	G-212A				
B-52	LG-100A	Amp/Cabinet	G-901				
B-52	LG200AS	Amp/Cabinet	G-901				
B-52	LG7512	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226	G-TOUR AMP2430	
B-52	PRODIGY	Mixer	G-MIX 20X30				
B-52	PRODIGY FX	Mixer	G-MIX 20X30				
B-52	ST-100A	Amp/Cabinet	G-TOUR AMP HEAD				
B-52	ST6012	Amp/Cabinet	G-212A				
B-52	ST60A	Amp/Cabinet	G-TOUR AMP HEAD				
Behringer	B1220 PRO	Speaker	GPA-700				
Behringer	B212	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Behringer	B212A	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Behringer	B212XL	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Behringer	B215	Speaker	GPA-700				
Behringer	B215A	Speaker	GPA-700	GPA-SCVR450-515			
Behringer	B215XL	Speaker	GPA-700				
Behringer	BCD2000	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Behringer	BCF2000	Digital Audio Gear	G-MEDIA PRO BP	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	
Behringer	BCR2000	Digital Audio Gear	G-MEDIA PRO BP	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	
Behringer	BEDDX3216	Mixer	G-MIX 20X25				
Behringer	BX4210A	Amp/Cabinet	G-TOUR-4X12-CAB				
Behringer	DDM4000	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618A
Behringer	DDX3216	Mixer	G-MIX 20X25				
Behringer	DEEJAY BCD3000	CD/DVD Player	G-TOUR CD-13X17				
Behringer	DJX400	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX912		
Behringer	DJX700	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A		
Behringer	DX052	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17		
Behringer	DX-626	Mixer	G-MIX-B 1212				
Behringer	E1220	Speaker	GPA-600				
Behringer	E1520	Speaker	GPA-700				
Behringer	Eurodesk SX3282	Mixer	GMC-4221				
Behringer	EURORACK UB1202	Mixer	G-MIX-B 1212				
Behringer	EURORACK UB2442FX PRO	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Behringer	EURORACK UB802	Mixer	G-MIX-B 1212				
Behringer	K1800FX	Amp/Cabinet	G-112-ROTO				
Behringer	K900FX	Amp/Cabinet	G-112-ROTO				
Behringer	KX1200	Amp/Cabinet	G-TOUR AMP HEAD				
Behringer	LC2412	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-MULTIFX-2411	G-TOURCARRYONFO
Behringer	LX112	Amp/Cabinet	G-112A	G-TOUR AMP2226	G-TOUR AMP2430		
Behringer	MX1604A	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR CDMX1317
Behringer	MX1804X	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Behringer	MX2004A	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Behringer	MX2442A	Mixer	GMC-3333	G-MIX 24X36	G-TOUR 20X30	G-TOUR 24X36	
Behringer	MX3282A	Mixer	GMC-4221				
Behringer	MX602A	Mixer	G-MIX-B 1212				
Behringer	MX802A	Mixer	G-MIX-B 1212				
Behringer	MX882	Digital Audio Gear	GK-2110	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Behringer	MXB1002	Mixer	G-MIX-B 1212				
Behringer	PMH1000	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Behringer	PMH2000	Mixer	GPA-720				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Behringer	PMH3000	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2020	G-TOUR 19X21	GX-1921-7.5
Behringer	PMH5000	Mixer	GMC-3333	G-MIX 20X30	G-TOUR 20X30		
Behringer	PMH518M	Mixer	G-MIX-B 1815				
Behringer	PMP1000	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Behringer	PMP2000	Mixer	GPA-720				
Behringer	PMP3000	Mixer	GMC-2222	G-MIX-B 2020	G-MIX-B 2519	G-TOUR 19X21	GX-1921-7.5
Behringer	PMP5000	Mixer	GMC-3333	G-MIX 20X30	G-TOUR 20X30		
Behringer	PMX 2000	Mixer	GPA-720				
Behringer	RX-1202FX	Digital Audio Gear	GP-PC314				
Behringer	SL2442FX-PRO	Mixer	G-MIX 20X30	G-TOUR 20X30			
Behringer	SL3242FX-PRO	Mixer	GMC-4221				
Behringer	SX2442FX	Mixer	G-MIX 20X30				
Behringer	SX3242FX	Mixer	GMC-4221				
Behringer	UB1002	Mixer	G-MIX-B 1212				
Behringer	UB1202	Mixer	G-MIX-B 1212				
Behringer	UB1224FX-PRO	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A		
Behringer	UB1622FX-PRO	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Behringer	UB1832FX-PRO	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Behringer	UB2222FX-PRO	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Behringer	UB2442FX-PRO	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Behringer	UB802	Mixer	G-MIX-B 1212				
Behringer	UBB1002	Mixer	G-MIX-B 1212				
Behringer	ULTRACOUSTIC ACX1800	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Behringer	ULTRACOUSTIC ACX900	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Behringer	ULTRASTACK BG412F	Amp/Cabinet	G-TOUR-4X12-CAB				
Behringer	ULTRASTACK BG412H	Amp/Cabinet	G-TOUR-4X12-CAB				
Behringer	ULTRASTACK BG412S	Amp/Cabinet	G-TOUR-4X12-CAB				
Behringer	V-AMPIRE LX1200H	Amp/Cabinet	G-901				
Behringer	VMX100	Mixer	G-MIX-B 1212				
Behringer	VMX1000	Mixer	G-MIX 12X24				
Behringer	VMX200	Mixer	G-MIX-B 1212				
Behringer	VMX300	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Behringer	V-TONE GMX1200H	Amp/Cabinet	G-901				
Behringer	V-TONE GMX210	Amp/Cabinet	G-112A	G-TOUR AMP2226	G-TOUR AMP2430		
Behringer	V-TONE GMX212	Amp/Cabinet	G-212A				
Behringer	X V-AMP	Digital Audio Gear	G-MIX-B 1212				
Behringer	XENYX 1002	Mixer	G-MIX-B 1212				
Behringer	XENYX 1002 FX	Mixer	G-MIX-B 1212				
Behringer	XENYX 1202	Mixer	G-MIX-B 1212				
Behringer	XENYX 1202 FX	Mixer	G-MIX-B 1212				
Behringer	XENYX 1204	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Behringer	XENYX 1204FX	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Behringer	XENYX 1222 FX	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A		
Behringer	XENYX 1622 FX	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Behringer	XENYX 1832 FX	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Behringer	XENYX 2222FX	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Behringer	XENYX 2442 FX	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Behringer	XENYX 802	Mixer	G-MIX-B 1212				
Belkin	TUNE STUDIO	Mixer	G-MIX 17X18				
Benchmark	DAC1C	Digital Audio Gear	G-MIX-B 1212				
BenQ	PB8220	Projector	GAV-1412-R	GAV-PE-1412R			
BenQ / Acer	859	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
BenQ / Acer	46W1	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Bogner	ALCHEMIST CAB	Amp/Cabinet	G-TOUR-4X12-CAB				
Bogner	ALCHEMIST HEAD	Amp/Cabinet	G-901				
Bogner	Alchemist Series 112	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Bogner	Alchemist Series 212	Amp/Cabinet	G-TOUR-4X12-CAB				
Bogner	CAB 112O	Amp/Cabinet	G-112-ROTO	G-TOUR AMP2226			
Bogner	CAB 212C	Amp/Cabinet	G-TOUR-4X12-CAB				
Bogner	CUSTOM SHOP DUENDE HEAD	Amp/Cabinet	G-901				
Bogner	CUSTOM SHOP ECSTASY 101	Amp/Cabinet	G-901				
Bogner	CUSTOM SHOP SHIVA HEAD	Amp/Cabinet	G-901				
Bonger	ALCHEMIST 212	Amp/Cabinet	G-TOUR-4X12-CAB				
Bonger	DUENDE110	Amp/Cabinet	G-212A				
Bonger	DUENDE112-15	Amp/Cabinet	G-212A				
Bonger	SHIVA112RV	Amp/Cabinet	G-212A				
Bose	B1	Speaker	GPA-600				
Bose	T1 ToneMatch	Mixer	G-MIX-B 1212				
Boss	AD-3	Digital Audio Gear	G-MIX-B 1212				
Boss	AD-8	Digital Audio Gear	G-MIX-B 1212				
Boss	BR1180CD	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-B 1815	G-MIX-L 1224	G-MULTIFX-2411
Boss	BR1200CD	Digital Audio Gear	GMC-2222	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622	G-MIX-L 1724
Boss	BR1600CD	Digital Audio Gear	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1622	
Boss	BR-600	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Boss	BR-864	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Boss	BR-900CD	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOURCARRONFO	
Boss	DD-20	Digital Audio Gear	G-MIX-B 1212				
Boss	DR. 880	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Boss	DR-3	Digital Audio Gear	G-MIX-B 1212				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Boss	DR-670	Digital Audio Gear	G-MIX-B 1212				
Boss	GS-10	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Boss	GT-10	Digital Audio Gear	GMC-2222	GMC-2222	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Boss	GT-10B	Digital Audio Gear	GK-2110	GMC-2222	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Boss	GT-3	Digital Audio Gear	G-MIX-B 1212				
Boss	GT-6	Digital Audio Gear	GK-LT25W	GMC-2222	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Boss	GT-6B	Digital Audio Gear	GK-LT25W	GMC-2222	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Boss	GT-8	Digital Audio Gear	GK-LT25W	GMC-2222	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Boss	ME-20	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Boss	ME-50	Digital Audio Gear	G-MIX-B 1815	G-TOUR 12X17	G-TOURCARRYONFO		
Boss	ME-50B	Digital Audio Gear	G-MEDIA PROBPXL	G-MULTIFX-1510	G-TOUR 12X17	G-TOURCARRYONFO	
Boss	ME-70	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-B 1815	G-MULTIFX-1510	G-TOUR 12X17	G-TOURCARRYONFO
Boss	RE-20	Digital Audio Gear	G-MIX-B 1212				
Boss	SP-505	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Boxlight	7200	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Boxlight	PD4600	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Budda	SUPERDRIVE 18	Amp/Cabinet	G-112-ROTO	G-TOUR AMP2226			
Cakewalk	V Studio 100	Mixer	G-MIX-B 1212				
Califone	1005AV	Digital Audio Gear	GP-PC309				
Canon	LV-5220	Projector	GAV-1412-R	GAV-PE-1412R			
Canon	LV-7220	Projector	GAV-1412-R	GAV-PE-1412R			
Canon	LV-7225	Projector	GAV-1412-R	GAV-PE-1412R			
Canon	LV-7230	Projector	GAV-1412-R	GAV-PE-1412R			
Canon	LV-X4	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Canon	REALIS SX-50	Projector	GAV-1412-R	GAV-PE-1412R			
Carl Martin	QUATTRO	Digital Audio Gear	G-MEDIA PROBPXL	G-MULTIFX-2411			
Carlo Robelli	Acoustic Bass	Bass Guitar	GL-AC-BASS				
Carlsbro	COLT 40	Amp/Cabinet	G-112-ROTO				
Carlsbro	COLT 85	Amp/Cabinet	G-112-ROTO				
Carlsbro	DX 8-2 XP	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Casio	140	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	140S	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	CDP-100	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	CTK-2000	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	CTK-230	Keyboard	GKB-49	GKPE-49-TSA			
Casio	CTK3000	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	CTK4000	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	CTK-496	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	CTK5000	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	CTK-691	Keyboard	GKB-61	GKPE-61-TSA	G-TOUR 61		
Casio	CTK710	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	CTK800	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	CTK810	Keyboard	GKB-61	GKPE-61-TSA	G-TOUR 61		
Casio	CTK900	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	LK100	Keyboard	GK-4212	GKC-1540			
Casio	LK-2005	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	LK-220	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Casio	LK-300TV	Keyboard	GKB-61	GKPE-61-TSA	G-TOUR 61		
Casio	LK94	Keyboard	GKC-1540	G-TOUR 61			
Casio	P70	Keyboard	GKPE-88SLXL-TSA				
Casio	P70S	Keyboard	GKPE-88SLXL-TSA				
Casio	PS20	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	PX-100	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	PX110	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	PX-120	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	PX-200	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	PX-300	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	PX-320	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	PX-330	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	PX500L	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Casio	WK-110	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Casio	WK-1300	Keyboard	GKC-1648				
Casio	WK-200	Keyboard	GK-76	GKC-1648			
Casio	WK-3000	Keyboard	GKC-1648				
Casio	WK3200	Keyboard	GKC-1648				
Casio	WK-3300	Keyboard	GKC-1648				
Casio	WK-3500	Keyboard	GKC-1648				
Casio	WK3700	Keyboard	GKC-1648				
Casio	WK-3800	Keyboard	GKC-1648				
Casio	WK500	Keyboard	GK-76	GKC-1648			
Casio	WK8000	Keyboard	GKC-1648				
Casio	YPG-225	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Casio	YPG-525	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Casio	YPG-625	Keyboard	GKC-1648	G-TOUR 88			
Cerwin Vega	CLS-155	Speaker	G-SUB2225-24BAG				
Cerwin Vega	CVA-118	Speaker	G-SUB2225-24BAG				
Cerwin Vega	HT2510	Speaker	GPA-600				
Cerwin Vega	HTS-10	Speaker	GPA-600				
Cerwin Vega	HTS15A	Speaker	G-SUB2225-24BAG				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Cerwin Vega	LW10	Speaker	GPA-600				
Cerwin Vega	LW15	Speaker	GPA-777				
Cerwin Vega	PSX-36	Speaker	G-SUB2225-24BAG				
Cerwin Vega	SUB15 MKII	Speaker	G-SUB2225-24BAG				
Champion	42CV1	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Cicognani	H150	Amp/Cabinet	G-901				
Clavia	G2X	Keyboard	GK-4212				
Clavia	NORD ELECTRO 2 61	Keyboard	GK-4212	GKB-49	GKC-1540	GKPE-49-TSA	
Clavia	NORD ELECTRO 61	Keyboard	GK-4212	GKB-49	GKC-1540	GKPE-49-TSA	
Clavia	NORD LEAD 2	Keyboard	GK-4212	GKB-49			
Clavia	NORD LEAD 2X	Keyboard	GK-4212	GKB-49	GKPE-49-TSA		
Clavia	NORD LEAD 3	Keyboard	GK-4212	GKB-49	GKPE-49-TSA		
Clavia	NORD MODULAR G2X	Keyboard	GK-4212				
Clavia	NORD STAGE 76	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Clavia	NORD STAGE 88	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Clavia	RACK2X	Digital Audio Gear	G-MIX-B 1815	G-TOURCARRYONFO	G-TOURCARRYONFO		
Clavia	RACK3	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYONFO
CME	UF5	Keyboard	GK-49	GKC-1540			
CME	UF50	Keyboard	GK-49	GKC-1540			
CME	UF6	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
CME	UF60	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
CME	UF7	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
CME	UF70	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
CME	UF8	Keyboard	GKPE-88SLXL-TSA				
CME	UF80	Keyboard	GKPE-88SLXL-TSA				
CME	VX5	Digital Audio Gear	GK-49	GKC-1540	GMC-4221		
CME	VX6	Digital Audio Gear	GK-61	GKC-1540	GKPE-61-TSA	GMC-4221	
CME	VX7	Digital Audio Gear	GK-76	GKPE-76-TSA			
CME	VX8	Digital Audio Gear	GKPE-88SLXL-TSA				
Community	SBS12	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Cooper Sound	SYSTEM 6	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Cooper Sound	SYSTEM 8	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Cordoba	32E	Acoustic Guitar	GWE-CLASSIC				
Cordoba	32EF	Acoustic Guitar	GWE-CLASSIC				
Cordoba	45FM	Acoustic Guitar	GWE-CLASSIC				
Cordoba	45FP	Acoustic Guitar	GWE-CLASSIC				
Cordoba	55R	Acoustic Guitar	GWE-CLASSIC				
Cordoba	C5	Acoustic Guitar	GWE-CLASSIC				
Cordoba	Cadete	Acoustic Guitar	GWE-CLASSIC				
Cordoba	Requinto	Acoustic Guitar	GWE-CLASSIC				
Cordoba	Solista	Acoustic Guitar	GWE-CLASSIC				
Cordoba	Solista Flamenca	Acoustic Guitar	GWE-CLASSIC				
Cordova	45R	Acoustic Guitar	GWE-CLASSIC				
Cortex	DMIX-300	Mixer	GMC-2222	G-MIX-L 1224	G-MIX-L 1622		
Cortex	DMIX-600	Mixer	GMC-2222	G-MIX-L 1224	G-MIX-L 1622		
Cortex	HDTT-5000	Turntable	G-TOUR T-TABLE				
Crate	BT220	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	BV120HB	Amp/Cabinet	G-TOUR AMP HEAD				
Crate	BV150HB	Amp/Cabinet	G-901				
Crate	BV215S	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	BV300HB	Amp/Cabinet	G-TOUR AMP HEAD				
Crate	BV412RVB	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	BV412SL	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	BV412ST	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	BV412SVB	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	BV6212	Amp/Cabinet	G-212A				
Crate	CA125DG	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Crate	CSX-12	Mixer	GMC-3333				
Crate	CSX-16	Mixer	GMC-3333	G-TOUR 24X36			
Crate	FW120	Amp/Cabinet	G-TOUR AMP2430				
Crate	FW120H	Amp/Cabinet	G-901				
Crate	FW412A	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	FW412B	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	GLX 212	Amp/Cabinet	G-TOUR AMP2430				
Crate	GLX1200H	Amp/Cabinet	G-901				
Crate	GLX212	Amp/Cabinet	G-TOUR AMP2430				
Crate	GLX412SL	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	GLX412ST	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	GLX50	Amp/Cabinet	G-112-ROTO				
Crate	GLX65	Amp/Cabinet	G-112-ROTO				
Crate	GT112SL	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Crate	GT1200H	Amp/Cabinet	G-901				
Crate	GT212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Crate	GT30	Amp/Cabinet	G-112-ROTO				
Crate	GT3500H	Amp/Cabinet	G-901				
Crate	GT412SL	Amp/Cabinet	G-TOUR-4X12-CAB				
Crate	GT65	Amp/Cabinet	G-112-ROTO				
Crate	GTX212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Crate	GTX65	Amp/Cabinet	G-112-ROTO				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Crate	PX700DLX	Mixer	GPA-720				
Crate	V18-112	Amp/Cabinet	G-112A	G-TOUR AMP2226	G-TOUR AMP2430		
Crate	V18-212	Amp/Cabinet	G-212A				
Crate	V212T	Amp/Cabinet	G-212A				
Crate	V3112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Crate	V-33	Amp/Cabinet	G-212A				
Crate	VFX5112	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Crate	VFX5212	Amp/Cabinet	G-212A				
Crate	VTX200S	Amp/Cabinet	G-212A				
Crate	VTX212B	Amp/Cabinet	G-212A				
Crate	VTX350 HEAD	Amp/Cabinet	G-901				
Crate	VTX65B	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Crate	XT120R	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Creative	PRODIKEYS	Keyboard	GK-2110	GK-LT25W	G-MULTIFX-2411		
Creative-Labs	PROKEYS PD-MIDI	Keyboard	GK-2110	GK-LT25W	G-MEDIA PROBPXL	G-MULTIFX-2411	
Crest Audio	XR20	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Crest Audio	XR24	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Crest Audio	XRM	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Daewoo	DP-425M	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Daewoo	DSP-4210GM	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Daewoo	PD-42520W	LCD/Plasma	G-TOURLCD-3743T				
Daewoo	PPM-4253	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Dave Smith	POLY EVOLVER KEYBOARD	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Dave Smith	POLY EVOLVER RACK	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYONFO
Dave Smith	PROPHET 08	Keyboard	GK-49	GKC-1540	GKPE-49-TSA		
DB Technologies	OPERA LIVE 402	Speaker	GPA-700	GPA-SCVR450-515			
Dean	Edge 5	Bass Guitar	GC-BASS	GPE-BASS-TSA	G-TOUR BASS	GW-BASS	GW-BASS-TW
Dean	Espana CS	Acoustic Guitar	GWE-CLASSIC				
Dean	Espana CSCR	Acoustic Guitar	GWE-CLASSIC				
Dean	Espana CSR	Acoustic Guitar	GWE-CLASSIC				
Dean	Tradition AK48	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Dell	INSPIRON 1200	Laptop	GAV-1412-R	GAV-PE-1412R			
Dell	INSPIRON 1300	Laptop	GAV-1813-UR				
Dell	INSPIRON 6000	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Dell	INSPIRON 9400	Laptop	GAV-1813-UR				
Dell	INSPIRON B120	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Dell	INSPIRON E1505	Laptop	GAV-1813-UR				
Dell	INSPIRON E1705	Laptop	GAV-1813-UR				
Dell	LATITUDE C610	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Dell	W4200	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Dell	XPS M1210	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Dell	XPS M1710	Laptop	GAV-1813-UR				
Delphi	DD42 EVOLUTION	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Delphi	DD42 PANACHE	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Delphi	PRO42 EVOLUTION	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Delphi	PRO42 PANACHE	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Delta Lab	DGFX1	Digital Audio Gear	G-MEDIA PRO BP	G-MIX-L 1618A	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17
Denon	DN-F400	CD/DVD Player	G-TOUR CD-9X12				
Denon	DN-HS5500	Turntable	G-TOUR T-TABLE				
Denon	DN-S1000	CD/DVD Player	G-TOUR CD-9X12				
Denon	DN-S3700	Turntable	G-TOUR T-TABLE				
Denon	DN-X100	Mixer	G-MIX-B 1212				
Denon	DNX1100	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Denon	DN-X1500	Mixer	G-MIX-B 1515	G-MIX-L 1618A			
Denon	DN-X300	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Denon	DP29F	Turntable	G-TOUR T-TABLE				
Denon	RC-F400S	CD/DVD Player	G-TOUR CD-9X12				
Digidesign	003 FACTORY CONTROL SURFACE	Digital Audio Gear	GMC-2222	G-MIX-B 2020	GP-PC309		
Digidesign	COMMAND 8	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Digidesign	DIGI002	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2519	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Digidesign	DIGI-003	Digital Audio Gear	GMC-2222	G-MIX-B 2020	GP-PC309		
Digidesign	MBOX2	Digital Audio Gear	G-MIX-B 1212				
Digidesign	MBOX2 PRO	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Digidesign	OO2R	Digital Audio Gear	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-MIX-L 1724	G-MIX-L 1822
Digitech	GNX1	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOURCARRYONFO	
Digitech	GNX2	Digital Audio Gear	GK-2110	G-MEDIA PROBPXL	G-MIX-B 1815	G-MULTIFX-2411	G-TOURCARRYONFO
Digitech	GNX3	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Digitech	GNX3000	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-B 1815	G-MIX-L 1224	G-MULTIFX-2411
Digitech	GNX4	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
DigiTech	RG335	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Digitech	RP-1000	Digital Audio Gear	GK-LT25W	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Digitech	RP150	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Digitech	RP155	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Digitech	RP250	Digital Audio Gear	G-MIX-B 1212				
DigiTech	RP255	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Digitech	RP350	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Digitech	RP500	Digital Audio Gear	GK-LT25W	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Digitech	RP90	Digital Audio Gear	G-MIX-B 1212				
Digitech	VL2	Digital Audio Gear	G-MIX-B 1212				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Digittech	VL4	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOURCARRYONFO	
Digittech	VOCAL 300	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17		
Dr. Z	Maz 38	Amp/Cabinet	G-212A				
Dynacord	PM 1000	Digital Audio Gear	GP-PC309				
Dynaudio	BM14S	Speaker	GPA-600				
Dynex	DX-L42-10A	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
EAW	FR129Z	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
EAW	FR153Z	Speaker	G-SUB2225-24BAG				
EAW	SB120ZP	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
EAW	SB150Z	Speaker	G-SUB2225-24BAG				
EAW	SB180ZP	Speaker	G-SUB2225-24BAG				
EAW	SM109Z	Speaker	GPA-600				
EAW	SM159Z	Speaker	G-SUB2225-24BAG				
Edirol	M-100FX	Digital Audio Gear	G-MEDIA PRO BP				
Edirol	M10DX	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Edirol	M-10DX	Mixer	G-MIX-B 1212				
Edirol	M-10E	Digital Audio Gear	G-MIX-B 1212				
Edirol	M16DX	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Edirol	M-16DX	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX912		
Edirol	PCR-1	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
Edirol	PCR300	Keyboard	G-MULTIFX-2411				
Edirol	PCR500	Keyboard	GK-4212				
Edirol	PCR800	Keyboard	GK-4212				
Edirol	PCR-A30	Keyboard	G-MULTIFX-2411				
Edirol	PCR-M1	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
Edirol	PCR-M30	Keyboard	G-MULTIFX-2411				
Edirol	PCR-M50	Keyboard	GK-4212				
Edirol	PCR-M80	Keyboard	GK-4212				
Edirol	R-44	Digital Audio Gear	G-MIX-B 1212				
Edirol	SD20	Keyboard	G-MULTIFX-1110				
Edirol	UA101	Digital Audio Gear	G-MIX-B 1212				
Edirol	UA-700	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Edirol	UM-550	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Edirol	UR-80	Digital Audio Gear	G-MEDIA PROBPXL	G-MULTIFX-1510	G-TOUR 12X17	G-TOURCARRYONFO	
Edirol	V-4	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Egnater	Tourmaster Series 4212	Amp/Cabinet	G-212A				
Eiki	LC-XB28	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Eiki	PLD-42UE	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Eiki	PLD-42XU	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Eizo	P5070	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Eizo	P5071	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Electro Harmonix	Holy Stain	Digital Audio Gear	G-MIX-B 1212				
Electro Harmonix	XO HOLY STAIN	Digital Audio Gear	G-MIX-B 1212				
Electro Voice	FORCE I 12"	Speaker	GPA-450-515				
Electro Voice	SB112	Speaker	GPA-700	GPA-SCVR450-515			
Electro Voice	SBA760	Speaker	G-SUB2225-24BAG				
Electro Voice	SX100	Speaker	GPA-700	GPA-SCVR450-515			
Electro Voice	SX250	Speaker	GPA-700	GPA-SCVR450-515			
Electro Voice	SxA360	Speaker	GPA-700	GPA-SCVR450-515			
Electrograph	DTS42	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Electrograph	DTS42DD	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Electrograph	E4203DD	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Electro-Voice	RE2	Wireless System	GM-1WP	GM-1WP	GM-2W	GM-5W	
Electro-Voice	RE2 Handheld	Wireless System	GM-1WP	GM-1WP	GM-2W	GM-5W	
Emes	AMBER	Speaker	GPA-600				
E-MU	0404 USB	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
E-MU	X BOARD 61	Keyboard	GK-4212				
E-MU	XBOARD 25	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
E-MU	XBOARD 49	Keyboard	GKPE-49-TSA				
Engl	Powerball	Amp/Cabinet	G-TOUR AMP HEAD				
Envision	A42W64	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Epiphone	1963 AJ-45	Acoustic Guitar	GC-DREAD	GC-JUMBO	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12
Epiphone	1966 G-400	SG Guitar	GC-SG				
Epiphone	AJ-1	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	AJ-200S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	BLUES CUSTOM 30	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Epiphone	Collegiate	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epiphone	Dove	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	DR-100	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	DR-200S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	DR-212	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	G-310 SG	SG Guitar	GC-SG				
Epiphone	G-400 Custom	SG Guitar	GC-SG				
Epiphone	G-400 SG	SG Guitar	GC-SG				
Epiphone	Hummingbird	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	Joe Perry Boneyard LP Standard	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epiphone	Les Paul Black Beauty	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epiphone	Les Paul Custom	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epiphone	Les Paul Special II	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Epiphone	Les Paul Standard	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epiphone	Les Paul Standard Plus Top	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epiphone	Les Paul Studio	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epiphone	Les Paul Ultra	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epiphone	LP-100	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epiphone	Masterbilt AJ-500M	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	Masterbilt AJ-500R	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	Masterbilt DR-500RA	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	Masterbilt EF-500RA	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	Paul McCartney 1964 Texan	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	PR-150	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Epiphone	SG Special	SG Guitar	GC-SG				
Epiphone	SG Standard	SG Guitar	GC-SG				
Epiphone	SO CAL	Amp/Cabinet	G-TOUR AMP HEAD				
Epiphone	SO CAL 412SL	Amp/Cabinet	G-TOUR-4X12-CAB				
Epiphone	Vintage G-400	SG Guitar	GC-SG				
Epiphone	Zack Wylde Les Paul Custom	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Epson	730	Projector	GAV-20				
Epson	760	Projector	GAV-20				
Epson	730C	Projector	GAV-20				
Epson	73C	Projector	GAV-1412-R	GAV-PE-1412R			
Epson	S3	Projector	GAV-1412-R	GAV-PE-1412R			
ESP	LTD Deluxe EC-1000	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
ESP	LTD EC-400	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
ESP	LTD KH-202 Kirk Hammett	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
ESP	M-1000	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
ESP	M-200FM	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
E VH	Eddie Van Halen Frankenstein	Electric Guitar	GWE-ELEC				
FBT	JOLLY SUB12A	Speaker	G-SUB2225-24BAG				
FBT	JOLLY12RA	Speaker	GPA-700				
FBT	MAXX 2	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
FBT	MAXX 4	Speaker	GPA-700	GPA-SCVR450-515			
FBT	MAXX9SA	Speaker	G-SUB2225-24BAG				
FBT	VERVE 18S	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Fender	'50s Precession Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Fender	'51 Precession Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Fender	57 AMP LTD	Amp/Cabinet	G-112-ROTO				
Fender	57 DELUXE	Amp/Cabinet	G-112-ROTO				
Fender	57 TWIN	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
Fender	59 BASSMAN	Amp/Cabinet	G-TOUR AMP2430				
Fender	'64 Jazz Bass Closet Classic	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	'64 Jazz Bass Relic	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	64 Vibroverb	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
Fender	65 DELUXE REVERB	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Fender	65 PRINCETON REVERB	Amp/Cabinet	G-112-ROTO				
Fender	65 SUPER REVERB	Amp/Cabinet	G-TOUR-4X12-CAB				
Fender	65 TWIN REVERB	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Fender	ACOUSTASONIC JR	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Fender	AERODYNE Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	American Ash Telecaster	Electric Guitar	GWE-ELEC				
Fender	American Deluxe Ash Strat	Electric Guitar	GWE-ELEC				
Fender	American Deluxe Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	American Deluxe Precession Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Fender	American Deluxe Series Telecaster	Electric Guitar	GWE-ELEC				
Fender	American Deluxe Stratocaster	Electric Guitar	GWE-ELEC				
Fender	American Deluxe Stratocaster HSS	Electric Guitar	GWE-ELEC				
Fender	American Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	American Precession Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Fender	American Series Stratocaster HSS	Electric Guitar	GWE-ELEC				
Fender	American Special HSS Stratocaster	Electric Guitar	GWE-ELEC				
Fender	American Stratocaster	Electric Guitar	GWE-ELEC				
Fender	American Vintage '57 Precession Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Fender	American Vintage '62 Stratocaster	Electric Guitar	GWE-ELEC				
Fender	Artist Series Eric Johnson Strat	Electric Guitar	GWE-ELEC				
Fender	Artist Series Yngwie Malmsteen Strat	Electric Guitar	GWE-ELEC				
Fender	BASSMAN 300	Amp/Cabinet	G-212-ROTO				
Fender	BLONDE HOT ROD DELUXE	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226	G-TOUR AMP2430	
Fender	BLUES DELUXE	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226	G-TOUR AMP2430	
Fender	BLUES DEVILLE	Amp/Cabinet	G-TOUR AMP2430				
Fender	CD100	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Fender	CD-140SCE	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Fender	CD220CE	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Fender	CD220S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Fender	CD-60	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Fender	Classic Series '50s Stratocaster	Electric Guitar	GWE-ELEC				
Fender	Classic Series '72 Telecaster Deluxe	Electric Guitar	GWE-ELEC				
Fender	Classic Series '72 Telecaster Thinline	Electric Guitar	GWE-ELEC				
Fender	Artist Series Eric Clapton Strat	Electric Guitar	GWE-ELEC				
Fender	Artist Series Reggie Hamilton Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Fender	CYBER TWIN	Amp/Cabinet	G-212-ROTO				
Fender	Deluxe Active Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Deluxe Active Jazz Bass V	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Deluxe Player's Stratocaster	Electric Guitar	GWE-ELEC				
Fender	Deluxe Precession Bass Special	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Fender	Deluxe Series Nashville Telecaster	Electric Guitar	GWE-ELEC				
Fender	DG100	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Fender	DUAL PROFESSIONAL	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Fender	FM 100H	Amp/Cabinet	G-901				
Fender	FM 212R	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
Fender	FM212 DSP	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Fender	FM412 SL	Amp/Cabinet	G-TOUR-4X12-CAB				
Fender	FRONTMAN 212R	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
Fender	Geddy Lee Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Highway One Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Highway One P Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Fender	HOT ROD DELUXE	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226	G-TOUR AMP2430	
Fender	HOT ROD DEVILLE 212	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
Fender	HOT ROD DEVILLE 410	Amp/Cabinet	G-TOUR AMP2430				
Fender	Jaco Pastorius Relic Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Jaguar Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Jazz Bass 24 V 5-String	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Maerican Series Jazz Bass V	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Marcus Miller Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Mark Hoppus Signature Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	MH-412	Amp/Cabinet	G-TOUR-4X12-CAB				
Fender	MH500	Amp/Cabinet	G-901				
Fender	PROSONIC 412	Amp/Cabinet	G-TOUR-4X12-CAB				
Fender	Quilt-Top Jazz Bass 24	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Reggie Hamilton Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Sonoran S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Fender	STAGE 1000	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Fender	STAGE 1600	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Fender	Standard Fretless Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Standard HSS Stratocaster	Electric Guitar	GWE-ELEC				
Fender	Standard Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Standard Jazz Bass 5 String	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Standard Precession Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Fender	Standard Stratocaster	Electric Guitar	GWE-ELEC				
Fender	Standard Telecaster	Electric Guitar	GWE-ELEC				
Fender	SUPER SONIC HEAD	Amp/Cabinet	G-901				
Fender	SUPER-SONIC 112	Amp/Cabinet	G-212-ROTO				
Fender	SUPER-SONIC 412	Amp/Cabinet	G-TOUR-4X12-CAB				
Fender	TONE MASTER 412	Amp/Cabinet	G-TOUR-4X12-CAB				
Fender	TWIN AMP	Amp/Cabinet	G-TOUR AMP2430				
Fender	ULTIMATE CHORUS	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Fender	US Vintage '62 Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	VG Stratocaster	Electric Guitar	GWE-ELEC				
Fender	VIBRO KING	Amp/Cabinet	G-212A				
Fender	VIBRO KING 212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Fender	VIBRO KING 3 10	Amp/Cabinet	G-212A				
Fender	Victor Bailey Fretless Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Fender	Vintage Hod Rod '52 Telecaster	Electric Guitar	GWE-ELEC				
Fishman	Loud Box	Amp/Cabinet	G-112-ROTO				
Floyd Rose	Discovery Series DST-3	Electric Guitar	GWE-ELEC				
Focusrite	SAFFIRE	Digital Audio Gear	G-MIX-B 1212				
Focusrite	SAFFIRE LE	Digital Audio Gear	G-MIX-B 1212				
Fostex	FR2	Digital Audio Gear	G-MIX-B 1212				
Fostex	FR-2	Digital Audio Gear	G-MIX-B 1212				
Fostex	FR2TC	Digital Audio Gear	G-MIX-B 1212				
Fostex	LR-16	Mixer	GMC-3333	G-MIX 20X30	G-MIX-B 2519	G-MIX-L 1926	
Fostex	MR-16HD	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2519	G-MIX-L 1822	GP-PC309	G-TOUR 19X21
Fostex	MR-16HD/CD	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2519	G-MIX-L 1822	GP-PC309	G-TOUR 19X21
Fostex	MR-8	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Fostex	MR8 MKII	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Fostex	MR8-8 MK11	Mixer	G-MIX-B 1515	G-TOUR 12X17		G-TOUR CDMX1317	
Fostex	MR-8HD	Digital Audio Gear	G-MEDIA PRO BP	G-MIX-L 1618A	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17
Fostex	MR8HDCD	Digital Audio Gear	G-MEDIA PRO BP	G-MIX-L 1618A	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17
Fostex	VF160	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	GX-1718-7	
Fostex	VF160EX	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	GX-1718-7	
Fostex	VF80	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17		
Fostex	VF80EX	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17		
Fostex	X12	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Frontier Design	ALPHA TRACK	Mixer	G-TOUR CDMX912				
Fujitsu	P42HHA10	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	P42VHA10	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	P50XHA10	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Fujitsu	PDS-4201	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Fujitsu	PDS-4203	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Fujitsu	PDS-4204	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Fujitsu	PDS-4207	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Fujitsu	PDS-4208	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-4209	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-4210	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-4211	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-4212	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-4213	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-4214	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-4221	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-4222	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-4233	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Fujitsu	PDS-5001	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Galaxy	AS-ALS-4	Wireless System	GM-1W	GM-2W			
Gateway	42 ED & 42 HD	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Gateway	50 ED & 50 HD	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Gateway	GTW-P42M102	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Gateway	GTW-P42M103	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Gateway	GTW-P46M103	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Gemini	CDJ SERIES	CD/DVD Player	G-TOUR CD-9X12				
Gemini	CFX-30	CD/DVD Player	G-TOUR CD-9X12				
Gemini	DJ-USB TURNTABLE	Turntable	G-TOUR T-TABLE				
Gemini	GT-USB TURNTABLE	Turntable	G-TOUR T-TABLE				
Gemini	ICDJ	CD/DVD Player	G-TOUR CD-9X12				
Gemini	iTRAX	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR CDMX1317	
Gemini	MPX-30	CD/DVD Player	G-TOUR CD-9X12				
Gemini	PDM SERIES	Mixer	G-MIX 12X24				
Gemini	PMX SERIES	Mixer	G-MIX-B 1212				
Gemini	PS SERIES	Mixer	G-MIX-B 1212				
Genelec	7050B	Speaker	GPA-600				
Genelec	7070A	Speaker	G-SUB2225-24BAG				
Genelec	7270A	Speaker	G-SUB2225-24BAG				
General Music	S2	Keyboard	GKC-1648				
Genz-Benz	Shenandoah 100	Amp/Cabinet	G-TOUR AMP2430				
Gibson	Angus Young Signature SG	SG Guitar	GC-SG				
Gibson	Billie Joe Armstrong Les Paul Junior	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	John Lennon Les Paul Junior	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Limited Edition Les Paul	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Slash Les Paul Signature	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Hummingbird Artist	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Gibson	Les Paul Antique	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Antique Deluxe	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul BFG	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Classic	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Classic Custom	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Classic Quilt Top	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Deluxe	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Junior	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Menace	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Standard	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Standard 50s Neck	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Standard 60s Neck	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Standard Double Cut Plus	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Studio	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Supreme Figured	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Les Paul Vintage	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Melody Maker	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	Melody Maker Dual Pickup	Les Paul Guitar	GC-LPS	GPE-LPS-TSA	G-TOUR LPS	GWE-LPS CAMO	GWE-LPS-BLK
Gibson	SG '61 Reissue	SG Guitar	GC-SG				
Gibson	SG Classic	SG Guitar	GC-SG				
Gibson	SG Menace	SG Guitar	GC-SG				
Gibson	SG Special	SG Guitar	GC-SG				
Gibson	SG Special 3 Pickup	SG Guitar	GC-SG				
Gibson	SG Standard 3 Single Coil	SG Guitar	GC-SG				
Gibson	SG Supreme	SG Guitar	GC-SG				
Gibson	SG-3	SG Guitar	GC-SG				
Gibson	Super Goldtone GA30RV	Amp/Cabinet	G-212A				
Gretsch	G4510 Showdown	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Gretsch	VARIETY G6164	Amp/Cabinet	G-TOUR-4X12-CAB				
Guild	D55	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Guild	GAD-30R	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Guild	GAD-40C	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Guild	GAD-C2	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Guild	GAD-C3	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Haier	HL47E	LCD/Plasma	G-TOURLCDLIFT52				
Hammond	XB-1	Digital Audio Gear	GK-76	GKPE-76-TSA			
Hammond	XK-1	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Hammond	XK-2	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Hammond	XK-3	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Hammond	XM2	Digital Audio Gear	G-MEDIA PROBPXL	G-MULTIFX-2411			
Hartke	VX3500	Amp/Cabinet	G-TOUR-4X12-CAB				
Hercules	DJ CONSOLE MK2	Mixer	G-MIX-B 1212				
Hercules	DJ Console Rmx Controller	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Hercules	RMX	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Hewlett-Pckrd	PPL-4245N	LCD/Plasma	G-LCD-4042				
Hitachi	401XU	LCD/Plasma	G-TOURLCDLIFT52				
Hitachi	402HDE	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Hitachi	402HDU	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Hitachi	4120HDU	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Hitachi	42PMA500E	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Hitachi	CMP4201U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Hitachi	CMP4202U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Hitachi	CMP4211U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Hitachi	CMP-5000	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Hitachi	CP-R555	Projector	GAV-20				
Hitachi	CP-S235W	Projector	GAV-1412-R	GAV-PE-1412R			
Hitachi	CP-S318	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Hitachi	CP-S335	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Hitachi	CP-X340	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Hitachi	CP-X345	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Hitachi	CP-X401	Projector	GAV-1412-R	GAV-PE-1412R			
Hitachi	CP-X443	Projector	GAV-1412-R	GAV-PE-1412R			
Hitachi	CP-X445W	Projector	GAV-1412-R	GAV-PE-1412R			
Hitachi	UT47V702	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Hughes & Kettner	ALEX LIFESON SIGNATURE	Amp/Cabinet	G-TOUR AMP HEAD				
Hughes & Kettner	CC412A	Amp/Cabinet	G-TOUR-4X12-CAB				
Hughes & Kettner	DUOTONE	Amp/Cabinet	G-TOUR AMP HEAD				
Hughes & Kettner	MATRIX 100	Amp/Cabinet	G-901				
Hughes & Kettner	PURETONE	Amp/Cabinet	G-901				
Hughes & Kettner	SWITCHBLADE 100 2X12	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
Hughes & Kettner	SWITCHBLADE 100 HEAD	Amp/Cabinet	G-901				
Hughes & Kettner	SWITCHBLADE 50	Amp/Cabinet	G-212-ROTO	G-TOUR AMP2430			
Hughes & Kettner	TRIAMP MKII	Amp/Cabinet	G-TOUR AMP HEAD				
Hughes & Kettner	WARP X	Amp/Cabinet	G-901				
Ibanez	2005 S2720FM	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	ATK Series	Bass Guitar	GC-BASS	GPE-BASS-TSA	G-TOUR BASS	GW-BASS	GW-BASS-TW
Ibanez	AW800RNT	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Ibanez	GA3	Acoustic Guitar	GWE-CLASSIC				
Ibanez	Gio Black Night Double Cuts	Electric Guitar	GSLING-ELEC				
Ibanez	Gio GRG170 Double Cut	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	GRG170DX	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	GRX20	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	IJX121	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	IJX40	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	IS412C	Amp/Cabinet	G-TOUR-4X12-CAB				
Ibanez	JEM7V Steve Vai Signature	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	JS1000 2002	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	JS1200 Joe Satriani Signature	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	RG Series GRG170	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	RG120	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	RG1570	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	RG2EX1	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	RG350MGX	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	RG370DXGP	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	RG3EXQM1	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	RG4EXQM1	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	RG7321	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	S520EX	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Ibanez	SGT120NT	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Ibanez	SR300DX Soundgear	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Ibanez	SR405 Soundgear	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Ibanez	SR500 Soundgear	Bass Guitar	GC-BASS	GPE-BASS-TSA	G-TOUR BASS	GW-BASS	GW-BASS-TW
Ibanez	SR505	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Ibanez	SR900 Soundgear	Bass Guitar	GC-BASS	GPE-BASS-TSA	G-TOUR BASS	GW-BASS	GW-BASS-TW
Ibanez	SRX2EX1	Bass Guitar	GC-BASS	GPE-BASS-TSA	G-TOUR BASS	GW-BASS	GW-BASS-TW
Ibanez	SRX300	Bass Guitar	GC-BASS	GPE-BASS-TSA	G-TOUR BASS	GW-BASS	GW-BASS-TW
Ibanez	SRX3EXQM1	Bass Guitar	GC-BASS	GPE-BASS-TSA	G-TOUR BASS	GW-BASS	GW-BASS-TW
Ibanez	SRX705	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Ibanez	TB100H	Amp/Cabinet	G-901				
Ibanez	TBX150H	Amp/Cabinet	G-901				
Ibanez	TBX150R	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Ibanez	TBX65R	Amp/Cabinet	G-112-ROTO				
Infocus	IN24	Projector	GAV-1412-R	GAV-PE-1412R			
Infocus	LP 530	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Insignia	NS-L37Q-10A	LCD/Plasma	G-LCDCOVER-42				
Insignia	NS-L42Q-10A	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Insignia	NS-LCD37-09	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Insignia	NS-LCD47HD-09	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Insignia	NS-P42Q10A	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Insignia	NS-P501Q-10A	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Insignia	NS-P502Q-10A	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Inter-M	A120	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR CDMX1317
Inter-M	A60	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR CDMX1317
Inter-M	CA 5130D	Mixer	GX-1224-8				
Inter-M	CA 8320	Mixer	GPA-720				
Inter-M	NX1243	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-MIX-L 1724	G-MIX-L 1822
Inter-M	PA1000B	Mixer	G-MIX-B 1212				
Inter-M	PA1000BR	Mixer	G-MIX-B 1212				
Inter-M	PA2000	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR CDMX1317
Inter-M	PA4000	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Inter-M	PA920	Mixer	G-MIX-B 1212				
Inter-M	PA935	Mixer	G-MIX-B 1212				
Inter-M	PAM120	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Inter-M	PAM60	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Inter-M	PAMCDA	Mixer	G-MIX-B 1212				
Inter-M	PAMD	Mixer	G-MIX-B 1212				
Inter-M	PMC-05 PRO D	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Inter-M	RMX1426	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-MIX-L 1724	G-MIX-L 1822
Inter-M	SMX812	Mixer	G-MIX-B 1212				
Jackson	DK2 Dinky	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Jackson	DK2G Dinky	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Jackson	DKMG Dinky	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Jackson	double cut	Electric Guitar	GC-ELECTRIC-A	G-COM-ELEC	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC
Jackson	MG Series DXMG Dinky	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Jackson	SL1 USA Soloist	Electric Guitar	GC-ELECTRIC-A	GL-ELECTRIC	GPE-ELEC-TSA	GWE-ELEC	GW-ELECTRIC
Jamo	D 7SUB	Speaker	G-SUB2225-24BAG				
Jazzkat	TWINKAT 210	Amp/Cabinet	G-112A				
JBL	EON10 G2	Speaker	GPA-600				
JBL	EON15 G2	Speaker	GPA-700				
JBL	EON1500	Speaker	GPA-700				
JBL	EON15P-1	Speaker	GPA-700				
JBL	EON305	Speaker	GPA-700	GPA-SCVR450-515			
JBL	EON315	Speaker	GPA-700	GPA-SCVR450-515			
JBL	EON515	Speaker	GPA-700	GPA-SCVR450-515			
JBL	EON518S	Speaker	G-SUB2225-24BAG				
JBL	EONSUB G2	Speaker	GPA-700				
JBL	JRX112M	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
JBL	JRX118S	Speaker	G-SUB2225-24BAG				
JBL	MP418S	Speaker	G-SUB2225-24BAG				
JBL	MRX512	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
JBL	PRX512M	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
JBL	PRX518S	Speaker	G-SUB2225-24BAG				
JBL	SRX712M	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
JBL	VP7210	Speaker	GPA-450-515				
JBL	VP7212M	Speaker	GPA-600	GPA-SCVR450-515			
JBL	VRX915M	Speaker	GPA-700	GPA-SCVR450-515			
JBL	VRX932LA	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
JBL	VRX932LAP	Speaker	GPA-700				
Jean Baptiste	BCS396SM	Electric Guitar	GSLING-ELEC				
Johnson	JM150	Amp/Cabinet	G-212A				
Johnson	JM250H	Amp/Cabinet	G-TOUR AMP HEAD				
Johnson	JM60	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Johnson	JT50	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
JVC	GD-V4200PZW	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
JVC	GD-V4210PZW	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
JVC	GD-V4211PCE	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
JVC	GD-V425PZW	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
JVC	GD-V500PZU	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
JVC	GD-V501U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
JVC	GM-P420UG	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
JVC	GM-V42UG	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
JVC	LT-47X788	LCD/Plasma	G-LCDCOVER-52				
JVC	PD-42DV2	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
JVC	PD-42V475	LCD/Plasma	G-LCD-4042				
JVC	PD-42WV74	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
JVC	PD-42WV84	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
JVC	PD-42WX84	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Kam	CD DJ PACK	CD/DVD Player	G-TOUR CD-13X17				
Kawai	EP3Kawai	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Kawai	ES6	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Ketron	AUDYA 76	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Ketron	Solton SD-1	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Konka	KDL32AT23U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
Korg	AX10A	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Korg	AX10B	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Korg	AX10G	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Korg	AX1500G	Digital Audio Gear	G-MEDIA PROBPXL	G-MULTIFX-2411	G-TOURCARRYONFO	G-TOURCARRYONFO	

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Korg	AX3000G	Digital Audio Gear	GK-LT25W	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Korg	CR-4	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Korg	CX3	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Korg	D1200 MKII	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-MULTIFX-2411	G-TOUR 12X17
Korg	D1600	Digital Audio Gear	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
Korg	D1600 MKII	Digital Audio Gear	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
Korg	D3200	Digital Audio Gear	GMC-2222	G-MIX-B 2519	G-MIX-L 1622		
Korg	D888	Digital Audio Gear	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A		
Korg	EMX1	Digital Audio Gear	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-MULTIFX-1510	G-TOUR 12X17
Korg	ESX1	Digital Audio Gear	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-MULTIFX-1510	G-TOUR 12X17
Korg	K61P	Keyboard	GK-4212				
Korg	KAOSS PAD 3	Digital Audio Gear	G-MIX-B 1212				
Korg	KARMA	Keyboard	GK-76	GKPE-61-TSA	G-TOUR 61		
Korg	KONTROL49	Keyboard	GKC-1540				
Korg	KORG M1	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Korg	M3 73	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Korg	M3 88	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Korg	M3-61	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Korg	M50-61	Keyboard	GK-4212				
Korg	M50-88	Keyboard	GKPE-88SLXL-TSA				
Korg	MICROKONTROL	Keyboard	GK-2110	GK-LT25W	G-MULTIFX-2411		
Korg	MICROKORG	Keyboard	GK-2110	GK-LT25W	G-MULTIFX-2411		
Korg	microKORG XL	Keyboard	GK-2110	GK-LT25W	G-MULTIFX-2411		
Korg	MICROX	Keyboard	G-MULTIFX-2411				
Korg	MR-1000	Digital Audio Gear	G-MIX-B 1212				
Korg	MS2000	Keyboard	GKC-1540				
Korg	MSR2000B	Keyboard	GKC-1540				
Korg	OASYS 76	Keyboard	GKC-1648				
Korg	OASYS 88	Keyboard	GKC-1648	G-TOUR 88			
Korg	PA1X PRO	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Korg	PA1X PRO ELITE	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Korg	PA2XPRO	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Korg	PA50	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Korg	PA-588	Keyboard	GKC-1648	G-TOUR 88			
Korg	PA80	Keyboard	GKC-1648				
Korg	PA88	Keyboard	GKC-1648	G-TOUR 88			
Korg	PADKONTROL	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Korg	PAD-KONTROL	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Korg	PROPHECY	Keyboard	GKB-49				
Korg	R3	Keyboard	GK-LT25W				
Korg	RADIAS 49-KEY	Keyboard	GKC-1540				
Korg	RADIAS SYNTHESIZER	Keyboard	GKC-1540				
Korg	SP-200	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Korg	SP-250	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Korg	SP-300	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Korg	SP-500	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Korg	SV1	Keyboard	GK-76				
Korg	TR61	Keyboard	GK-4212				
Korg	TR88	Keyboard	GKPE-88SLXL-TSA				
Korg	TRITON EXTREME 61	Keyboard	GK-76	GKPE-61-TSA	G-TOUR 61		
Korg	TRITON EXTREME 76	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Korg	TRITON EXTREME 88	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Korg	TRITON LE 61	Keyboard	GK-4212				
Korg	TRITON LE 88	Keyboard	GKPE-88SLXL-TSA				
Korg	TRITON STUDIO 61	Keyboard	GK-76	GKC-1648	GKPE-61-TSA	G-TOUR 61	
Korg	TRITON STUDIO 88	Keyboard	GKC-1648	G-TOUR 88			
Korg	TRITON STUDIO 76	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Korg	X3	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Korg	X-50	Keyboard	GK-4212				
Korg	X5D	Keyboard	GK-4212				
Korg	ZERO 4	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR CDMX1317
Korg	ZERO 8	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Kurzweil	K2600	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Kurzweil	K2600S	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Kurzweil	K2600X	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Kurzweil	K2600XS	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Kurzweil	K2661	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Kurzweil	PC161	Keyboard	GK-4212	GKC-1540			
Kurzweil	PC1SE	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Kurzweil	PC-1X	Keyboard	GKPE-88SLXL-TSA				
Kurzweil	PC-1XL	Keyboard	GKPE-88SLXL-TSA				
Kurzweil	PC2X	Keyboard	GKPE-88SLXL-TSA				
Kurzweil	PC3	Keyboard	GKPE-88SLXL-TSA				
Kurzweil	PC3X	Keyboard	GKPE-88SLXL-TSA				
Kurzweil	PC88	Keyboard	GKPE-88SLXL-TSA				
Kurzweil	SP2	Keyboard	GKPE-88SLXL-TSA				
Kurzweil	SP3X	Keyboard	GKPE-88SLXL-TSA				
Kurzweil	SP-76	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Kurzweil	SP-88	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Kurzweil	SP-88X	Keyboard	GKPE-88SLXL-TSA				
Kustom	KPC12	Speaker	GPA-777				
Kustom	KPC12M	Speaker	GPA-777				
Kustom	KPM8420	Mixer	GPA-720				
Kustom	KPM8420T	Mixer	GPA-720				
L-Acoustics	SB15P	Speaker	G-SUB2225-24BAG				
Lexicon	ALPHA	Digital Audio Gear	G-MIX-B 1212				
Lexicon	LAMBDA	Digital Audio Gear	G-MIX-B 1212				
Lexicon	OMEGA	Digital Audio Gear	G-MIX-B 1212				
LG	32LC5DC	LCD/Plasma	G-TOURLCDP-2632				
LG	32LG70	LCD/Plasma	G-TOURLCDP-2632				
LG	32LH40	LCD/Plasma	G-TOURLCDP-2632				
LG	37LC-7D	LCD/Plasma	G-LCDCOVER-42				
LG	37LH20	LCD/Plasma	G-LCDCOVER-42				
LG	37LH30	LCD/Plasma	G-LCDCOVER-42				
LG	42LG50	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
LG	42LG70	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
LG	42LH30	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
LG	42LH40	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
LG	42PC3DV	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
LG	42PC5D	LCD/Plasma	G-LCD-4042				
LG	42PQ30C	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
LG	47LG50	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
LG	47LG60	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
LG	47LG70	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
LG	47LG90	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
LG	47LH30	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
LG	47LH40	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
LG	47LH50	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
LG	50PM1M	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
LG	50Pq20	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
LG	50PQ30C	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
LG	50PS60C	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
LG	52LB5D	LCD/Plasma	G-LCDCOVER-52				
LG	52LG50	LCD/Plasma	G-LCDCOVER-52				
LG	60PS60C	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
LG	DU42PX12	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
LG	M3702C-BA	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
LG	M4210N-B21	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
LG	M4212C-BA	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
LG	M4212T-BA	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
LG	M4224C-BA	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
LG	M4714C-BA	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
LG	M4714T-BA	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
LG	M5201C-BA	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
LG	MU-40PA10B	LCD/Plasma	G-TOURLCD-3743T				
LG	MU-42PM11	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
LG	MU-42PZ11B	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
LG	MU-42PZ15B	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
LG	MU50PM10	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
LG	MU60P	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
LG	RU42DX11	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Line 6	212S CAB	Amp/Cabinet	G-212A				
Line 6	412CB	Amp/Cabinet	G-TOUR-4X12-CAB				
Line 6	412S CAB	Amp/Cabinet	G-TOUR-4X12-CAB				
Line 6	AX2	Amp/Cabinet	G-212A				
Line 6	BASS FLOOR POD	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Line 6	BASS POD	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Line 6	BASS POD PRO	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYONFO	G-TOURCARRYONFO
Line 6	BASS POD XT LIVE	Digital Audio Gear	GK-2110	GMC-2222	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Line 6	BASS POD-PRO	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYONFO	G-TOURCARRYONFO
Line 6	BASS XT PRO	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYONFO	G-TOURCARRYONFO
Line 6	BOD	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Line 6	BOD XT PRO	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYONFO	G-TOURCARRYONFO
Line 6	CLASSIC 112 (FLEX 3)	Amp/Cabinet	G-TOUR AMP2226				
Line 6	CLASSIC 212 (FLEX 3)	Amp/Cabinet	G-TOUR-4X12-CAB				
Line 6	CLASSIC PLUS (FLEX 3)	Amp/Cabinet	G-TOUR AMP2226				
Line 6	DL4	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Line 6	DM4	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Line 6	DUOVERB 212	Amp/Cabinet	G-212A				
Line 6	DUOVERB HEAD	Amp/Cabinet	G-901				
Line 6	FBC	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYONFO
Line 6	FLEXTONE II	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Line 6	FLEXTONE II HD	Amp/Cabinet	G-901				
Line 6	FLEXTONE II PLUS	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Line 6	FLEXTONE II XL	Amp/Cabinet	G-212A				
Line 6	FLEXTONE III 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Line 6	FLEXTONE III PLUS 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Line 6	FLEXTONE III XL	Amp/Cabinet	G-212A				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Line 6	FLOOR POD	Digital Audio Gear	GK-LT25W	GMC-2222	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Line 6	Floor POD Plus	Digital Audio Gear	GMC-2222	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Line 6	FM4	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Line 6	HD 147	Amp/Cabinet	G-901				
Line 6	LD15	Amp/Cabinet	G-112-ROTO				
Line 6	M 13 STOMPBOX	Digital Audio Gear	GMC-2222	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 12X17
Line 6	MM4	Digital Audio Gear	G-MIX-B 1212				
Line 6	POD 2.0	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Line 6	POD PRO	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYNFO	
Line 6	POD PRO XT	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYNFO	
Line 6	POD STUDIO UX2	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Line 6	POD X3	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Line 6	POD X3 LIVE	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411	
Line 6	POD XT (SHARC POD)	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Line 6	POD XT LIVE	Digital Audio Gear	GK-2110	GMC-2222	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Line 6	POD XT PRO	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYNFO	
Line 6	POD-Pro	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-L 1224	G-MULTIFX-2411	G-TOURCARRYNFO	
Line 6	SPIDER 212	Amp/Cabinet	G-212A				
Line 6	SPIDER II 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Line 6	SPIDER II 210	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Line 6	SPIDER II 212	Amp/Cabinet	G-901				
Line 6	SPIDER II 412	Amp/Cabinet	G-TOUR-4X12-CAB				
Line 6	SPIDER II HD	Amp/Cabinet	G-901				
Line 6	SPIDER II HD75	Amp/Cabinet	G-901				
Line 6	SPIDER III 120	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Line 6	SPIDER III 150	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Line 6	SPIDER III 75	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Line 6	SPIDER III HD150	Amp/Cabinet	G-901				
Line 6	SPIDER III HD75	Amp/Cabinet	G-901				
Line 6	SPIDER VALVE 212	Amp/Cabinet	G-TOUR-4X12-CAB				
Line 6	SPIDER VALVE MKII HD100	Amp/Cabinet	G-901				
Line 6	STONEPORT GX1	Digital Audio Gear	G-MIX-B 1212				
Line 6	STONEPORT KB37	Keyboard	GK-2110	GK-LT25W	G-MULTIFX-2411		
Line 6	STONEPORT UX1	Digital Audio Gear	G-MIX-B 1212				
Line 6	VETTA HEAD	Amp/Cabinet	G-901				
Line 6	VETTA II CAB	Amp/Cabinet	G-TOUR-4X12-CAB				
Line 6	VETTA II HEAD	Amp/Cabinet	G-901				
Ltd	ESP double cut	Electric Guitar	GC-ELECTRIC-A	G-TOUR ELEC	GW-ELECTRIC	GW-ELECTRIC-TW	GW-ELECT-VIN
Ltd	ESP single cut	Les Paul Guitar	GC-LPS	G-TOUR LPS			
Mackie	1501	Speaker	GPA-700				
Mackie	1202 VLZ PRO	Mixer	G-MIX-B 1212				
Mackie	1202-VLZ3	Mixer	G-MIX-B 1212				
Mackie	1402 VLZ PRO	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR CDMX1317	
Mackie	1402-VLZ3	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR CDMX1317	
Mackie	1604 VLZ PRO	Mixer	GMC-2222	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Mackie	1604-VLZ3	Mixer	GMC-2222	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Mackie	1642 VLZ Pro	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Mackie	1642-VLZ3	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Mackie	24E	Mixer	GMC-3333				
Mackie	24X4	Mixer	GMC-3333				
Mackie	802-VLZ3	Mixer	G-MIX-B 1212				
Mackie	C200	Speaker	GPA-450-515	GPA-777	GPA-E15		
Mackie	C300Z	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Mackie	CFX 12	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Mackie	CFX 16	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1622		
Mackie	CFX 20	Mixer	G-MIX 20X30	G-TOUR 20X30			
Mackie	CFX12mk2	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21	GX-1921-7.5
Mackie	CFX16mk2	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1724		
Mackie	CFX20mk2	Mixer	G-MIX 20X30				
Mackie	CONTROL UNIVERSAL PRO	Digital Audio Gear	GMC-2222	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Mackie	D2	Mixer	G-MIX-B 1815	G-TOUR 12X17	GX-1	GX-2	GX-3
Mackie	d4 Pro	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A		
Mackie	HR624	Speaker	GPA-600				
Mackie	HR626	Speaker	GPA-450-515				
Mackie	HRS120	Speaker	G-SUB2225-24BAG				
Mackie	HUI	Mixer	GMC-2222	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Mackie	LINK USB	Digital Audio Gear	G-MIX-B 1212				
Mackie	MS1402-VLZ	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR CDMX1317	
Mackie	ONYX 1220i	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR CDMX1317
Mackie	ONYX 1620	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Mackie	ONYX 1620i	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1724	G-TOUR 19X21
Mackie	ONYX 1640	Mixer	G-MIX 20X25				
Mackie	ONYX 820i	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Mackie	PPM1008	Mixer	GPA-720				
Mackie	PPM1012	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
Mackie	PPM608	Mixer	GPA-720				
Mackie	PRO FX12	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	GX-1718-7	
Mackie	PRO FX8	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1926	G-TOUR 20X30	
Mackie	SATELLITE BASE	Digital Audio Gear	G-MIX-B 1212				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Mackie	SR32.4 VLZ PRO	Mixer	GMC-4221				
Mackie	SRM350	Speaker	GPA-450-515	GPA-777	GPA-E15		
Mackie	SRM450	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Mackie	SRM450-V2	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Mackie	SWA1501	Speaker	G-SUB2225-24BAG				
Mackie	TAPCO 6306	Mixer	G-MIX-B 1212				
Mackie	U.420	Mixer	G-MIX-B 1212				
Mackie	DFX 12	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Mackie	DFX 6	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR CDMX1317
Mackie	ONYX 1220	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	GX-1718-7
Mackie	SR24.4 VLZ PRO	Mixer	GMC-3333				
Marantz	CDR310	Digital Audio Gear	G-MIX-B 1212				
Marantz	PD4293D	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Marantz	PD5010D	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Marantz	PMD671	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Marshall	1912	Amp/Cabinet	G-112-ROTO				
Marshall	1922	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Marshall	1936	Amp/Cabinet	G-TOUR AMP2430				
Marshall	2203	Amp/Cabinet	G-901				
Marshall	2245	Amp/Cabinet	G-901				
Marshall	2266	Amp/Cabinet	G-901				
Marshall	2466	Amp/Cabinet	G-901				
Marshall	4100	Amp/Cabinet	G-TOUR AMP HEAD				
Marshall	1959SLPX	Amp/Cabinet	G-901				
Marshall	1962BLUESBREAKER	Amp/Cabinet	G-212A				
Marshall	1982 AJH	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	1987X	Amp/Cabinet	G-901				
Marshall	2061 CX	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	2061X	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	2203K	Amp/Cabinet	G-901				
Marshall	2266C	Amp/Cabinet	G-212A				
Marshall	425A	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	425B	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	AS50D	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Marshall	AVT100X	Amp/Cabinet	G-TOUR AMP2226				
Marshall	AVT112X	Amp/Cabinet	G-TOUR AMP2226				
Marshall	AVT150	Amp/Cabinet	G-112-ROTO	G-TOUR AMP2226	G-TOUR AMP2430		
Marshall	AVT150H	Amp/Cabinet	G-901				
Marshall	AVT150HX	Amp/Cabinet	G-901				
Marshall	AVT150X	Amp/Cabinet	G-TOUR AMP2226				
Marshall	AVT20X	Amp/Cabinet	G-112-ROTO				
Marshall	AVT275X	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Marshall	AVT412A	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	AVT412B	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	AVT412XA	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	AVT412XB	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	AVT50H	Amp/Cabinet	G-901				
Marshall	AVT50HX	Amp/Cabinet	G-901				
Marshall	AVT50X	Amp/Cabinet	G-112-ROTO	G-TOUR AMP2226			
Marshall	AVT-50X	Amp/Cabinet	G-112-ROTO	G-TOUR AMP2226			
Marshall	B65	Amp/Cabinet	G-112-ROTO				
Marshall	DSL100	Amp/Cabinet	G-901				
Marshall	DSL401	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Marshall	DSL50	Amp/Cabinet	G-901				
Marshall	JCM800	Amp/Cabinet	G-901				
Marshall	JCM800 2203X	Amp/Cabinet	G-901				
Marshall	JCM900	Amp/Cabinet	G-901				
Marshall	JCM-900	Amp/Cabinet	G-901				
Marshall	JTM100	Amp/Cabinet	G-901				
Marshall	JTM45	Amp/Cabinet	G-901				
Marshall	JVM410C	Amp/Cabinet	G-212A				
Marshall	JVM410H	Amp/Cabinet	G-901				
Marshall	LEAD 100 MOSFET	Amp/Cabinet	G-901				
Marshall	MA100H	Amp/Cabinet	G-901				
Marshall	MA50C	Amp/Cabinet	G-901				
Marshall	MA50H	Amp/Cabinet	G-901				
Marshall	MB4210	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
Marshall	MB60	Amp/Cabinet	G-TOUR AMP2226				
Marshall	MBC115	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	MBC410	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	MC412A	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	MF350	Amp/Cabinet	G-901				
Marshall	MG100DFX	Amp/Cabinet	G-TOUR AMP2226				
Marshall	MG250 DFX	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
Marshall	MG250DFX	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Marshall	MG412	Amp/Cabinet	G-TOUR-4X12-CAB				
Marshall	MG50DFX	Amp/Cabinet	G-112-ROTO				
Marshall	SUPER100JH	Amp/Cabinet	G-901				
Marshall	TSL100	Amp/Cabinet	G-901				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Marshall	TSL122	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Marshall	TSL60	Amp/Cabinet	G-901				
Marshall	TSL601	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Marshall	TSL602	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Marshall	VBA400	Amp/Cabinet	G-TOUR AMP HEAD				
Marshall	VM2266C	Amp/Cabinet	G-TOUR AMP2430				
Marshall	VM2266H	Amp/Cabinet	G-901				
Marshall	VM2466H	Amp/Cabinet	G-901				
Martin	Cowboy V	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	D12-28	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	D12X1	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	D-15	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	D-16GT	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	D-16RGT	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	D-18VE	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	D-28	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	D-35	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	D-42	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DC-15E	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DC-16RE Aura	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DC-16RGTE Aura	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DC-28E	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DCME	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DCX1E	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DCX1KE	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DM	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DM12	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DR	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DSR	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DX1	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DX1E	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DX1K	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	DXM	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	HD-16R LSH	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	HD-28	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	HD-28V	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	HD-28VE	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	M-42	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	MMW	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Martin	SWDGT	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
M-Audio	2	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
M-Audio	AXIOM 25	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
M-Audio	AXIOM 49	Keyboard	GK-49	GKB-49	GKB-49	GKPE-49-TSA	GKPE-49-TSA
M-Audio	AXIOM 61	Keyboard	GK-4212				
M-Audio	BLACK BOX	Digital Audio Gear	G-MIX-B 1212				
M-Audio	FIREWIRE 1814	Digital Audio Gear	G-MIX-B 1212				
M-Audio	FIREWIRE 410	Digital Audio Gear	G-MIX-B 1212				
M-Audio	FIREWIRE SOLO	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
M-Audio	KEYSTATION 61ES	Keyboard	GK-4212				
M-Audio	MICROTRACK II	Mixer	G-TOUR CDMX912				
M-Audio	MIDAIR 25 KEY	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
M-Audio	MIDAIR 37	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
M-Audio	NRV10	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR CDMX1317	GX-1
M-Audio	O2 25 KEY	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
M-Audio	OXYGEN 49	Keyboard	GKPE-49-TSA				
M-Audio	OXYGEN 61	Keyboard	GK-4212				
M-Audio	OXYGEN 8 V2	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
M-Audio	OXYGEN8	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
M-Audio	OZONE	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
M-Audio	PRO88	Keyboard	GKPE-88SLXL-TSA				
M-Audio	PROJECT MIN I/O	Amp/Cabinet	G-212A	G-TOUR AMP2430			
M-Audio	PROJECT MIX I/O	Digital Audio Gear	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1926	G-TOUR 19X21
M-Audio	PROJECTMIX I/O	Digital Audio Gear	GP-PC301				
M-Audio	RADIUM49	Keyboard	GKPE-49-TSA				
M-Audio	RADIUM61	Keyboard	GK-4212				
M-Audio	SONO61	Keyboard	GK-4212				
M-Audio	TORQ XPONENT	Mixer	GMC-2222	G-MIX-L 1618A	G-MIX-L 1622		
M-Audio	TRIGGERFINGER	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Maxent	MX-42VM10	LCD/Plasma	G-LCD-4647				
mesa boogie	Mark V	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Mesaboogie	112 LONESTAR 23	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Mesaboogie	112 LONESTAR 27	Amp/Cabinet	G-212-ROTO				
Mesaboogie	112 THREE-QUARTER BACK	Amp/Cabinet	G-212A				
Mesaboogie	112 WIDE BODY	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Mesaboogie	212 LONESTAR	Amp/Cabinet	G-212-ROTO				
Mesaboogie	212 THREE-QUARTER BACK	Amp/Cabinet	G-212-ROTO				
Mesaboogie	410 LONESTAR	Amp/Cabinet	G-TOUR-4X12-CAB				
Mesaboogie	412 LONESTAR	Amp/Cabinet	G-TOUR-4X12-CAB				
Mesaboogie	412 STILETTO	Amp/Cabinet	G-TOUR-4X12-CAB				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Mesaboogie	NOMAD 45 112	Amp/Cabinet	G-112-ROTO				
Mesaboogie	Triple Rectifier Head	Amp/Cabinet	G-901				
Meyer Sound	M1D SUB	Speaker	GPA-777				
Meyer Sound	UMS-1P	Speaker	GPA-777				
Mitsubishi	LT-46149	LCD/Plasma	G-TOURLCDLIFT52				
Microboards	COPYWRITER 1052	Digital Audio Gear	G-MIX 20X25				
Microboards	DVD RPM 1016	Digital Audio Gear	G-MIX 20X25				
Microboards	GX1	Digital Audio Gear	GP-PC308				
Microtek	MHP1	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Microtek	VS1	Projector	GAV-1412-R	GAV-PE-1412R			
Midas	VENICE-1608	Mixer	G-MIX 20X25				
Misubishi	XD450U	Projector	GAV-1412-R	GAV-PE-1412R			
Mitchell	MD100	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Mitchell	MD100S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Mitchell	MD100S12	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Mitsubishi	LEONARDO	LCD/Plasma	G-LCD-4042				
Mitsubishi	LT46231	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Mitsubishi	LT-52133	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Mitsubishi	LT-52144	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Mitsubishi	LT-52244	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Mitsubishi	PD-5010	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Mitsubishi	XD430U	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Motu	TRAVELER	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOURCARRYONFO	
Motu	ULTRALITE	Digital Audio Gear	G-MIX-B 1212				
Musicxpc	M4	Laptop	GAV-1813-UR				
Musicxpc	M4X	Laptop	GAV-1813-UR				
Musicxpc	M6	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Nady	6600	Mixer	GPA-720				
Nady	CMX16A	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Nady	DKW-DUO	Wireless System	GM-1W	GM-2W	GM-5W		
Nady	E03	Wireless System	GM-4WR				
Nady	Encore Duet Dual Headset	Wireless System	GM-1W	GM-2W			
Nady	Encore Duet Dual Lavalier	Wireless System	GM-1W	GM-2W			
Nady	MC12	Speaker	GPA-777				
Nady	MC15	Speaker	GPA-700	GPA-SCVR450-515			
Nady	MM 4	Mixer	G-MIX-B 1212				
Nady	MPM4130	Mixer	GMC-2222				
Nady	MPM8175	Mixer	GPA-720				
Nady	MXE1212	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Nady	MXE612	Mixer	G-MIX-B 1212				
Nady	MXE812	Mixer	G-MIX-B 1212				
Nady	PFW12	Speaker	G-SUB2225-24BAG				
Nady	PRM400	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1618A	G-TOUR 19X21
Nady	PS112	Speaker	GPA-777				
Nady	PSW15	Speaker	G-SUB2225-24BAG				
Nady	PTS 1015	Speaker	GPA-700				
Nady	PTS515	Speaker	GPA-700				
Nady	SPM6600	Mixer	GPA-720				
Nady	SPM8600	Mixer	GPA-720				
Nady	SRM10X	Mixer	G-MIX-B 1212				
Nady	SRM12X	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Nady	SRM-14X	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A		
Nady	UHF-3	Wireless System	GM-1W	GM-2W			
Nec	3300	LCD/Plasma	G-TOURLCDP-2632				
Nec	4000	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Nec	4200	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	4205	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	4210	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	5000	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	42MP1	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	42MP2	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	42MP4	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	42PD1	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	42PD2	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	42VM5	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
Nec	42VP4	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	42VP5 & 42VP5A	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	42XM3	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	42XM3A	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	50MP1	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	50MP2	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	50MP3	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	50PD1	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Nec	50XM3	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	50XM4A	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	50XM5	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	50XR4A	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	61 XMA	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Nec	61 XR4	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Nec	LCD2335 WXM	LCD/Plasma	G-TOURLCDP-2023				
Nec	LCD4010	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Nec	LCD4020	LCD/Plasma	G-LCDCOVER-42				
Nec	LCD4215	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Nec	LCD4610	LCD/Plasma	G-LCDCOVER-52				
Nec	LCD4615	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Nec	LCD4620	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Nec	LCD46202AV	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Nec	LCD5220	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Nec	LCD5710-2-AV	LCD/Plasma	G-TOURLCDLIFT65				
Nec	LCD5710-2-IT	LCD/Plasma	G-TOURLCDLIFT65				
Nec	M40B-AV	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Nec	M46B-AV	LCD/Plasma	G-LCDCOVER-52				
NEC	NP300	Projector	GAV-1412-R	GAV-PE-1412R			
Nec	P42XC10	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	P42XP10-BK	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	P50XC10	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	P50XP10	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Nec	P60XC10	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Nec	P60XP10-BK	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Nec	PX-42V5RA	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	PX-42VMA	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	PX-42VP4A	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	PX-42XM2A	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Nec	VT-37	Projector	GAV-1412-R	GAV-PE-1412R			
Nec	VT-47	Projector	GAV-1412-R	GAV-PE-1412R			
Nec	VT-470	Projector	GAV-1412-R	GAV-PE-1412R			
Nec	VT-570	Projector	GAV-1412-R	GAV-PE-1412R			
Nec	VT-575	Projector	GAV-1412-R	GAV-PE-1412R			
Nec	VT-670	Projector	GAV-1412-R	GAV-PE-1412R			
Nec	VT-676	Projector	GAV-1412-R	GAV-PE-1412R			
Nec	X461UN	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Nord	ELECTRO 2 61	Keyboard	GK-4212	GKB-49	GKC-1540	GKPE-49-TSA	
Nord	ELECTRO 3 61	Keyboard	GK-4212	GKB-49	GKC-1540	GKPE-49-TSA	
Nord	NC1	Keyboard	GKB-61				
Nord	STAGE 73	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Nord	STAGE 76	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Nord	STAGE 88	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Novation	REMOTE ZERO SL	Digital Audio Gear	G-MEDIA PROBPXL	G-MULTIFX-2411			
Novation	REMOTE25 SL	Keyboard	GK-2110	G-MEDIA PROBPXL			
Novation	REMOTE25 SLC	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
Novation	REMOTE-25LE	Keyboard	G-MEDIA PROBPXL				
Novation	REMOTE37 SL	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
Novation	REMOTE49	Keyboard	GK-49	GKPE-49-TSA			
Novation	REMOTE49 SLC	Keyboard	GK-49	GKPE-49-TSA			
Novation	REMOTE61	Keyboard	GK-4212				
Novation	XIO-SYNTH25	Keyboard	G-MEDIA PROBPXL				
Novation	XSTATION 25	Keyboard	GK-2110	G-MEDIA PROBPXL	G-MULTIFX-2411		
Novation	XSTATION 49	Keyboard	GK-49	GKPE-49-TSA			
Novation	XSTATION 61	Keyboard	GK-4212				
Numark	5000FX	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR CDMX1317	
Numark	AXIS 8	CD/DVD Player	G-TOUR CD-9X12				
Numark	AXIS 9	CD/DVD Player	G-TOUR CD-9X12				
Numark	CD2CD	CD/DVD Player	G-TOUR CD-9X12				
Numark	DM1001X	Mixer	G-MIX-B 1212				
Numark	DM1002 MKII	Mixer	G-MIX-B 1212				
Numark	DM1050	Mixer	G-MIX-B 1212				
Numark	DM2050	Mixer	G-MIX-B 1212				
Numark	DM3001X	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Numark	DM3002X	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Numark	DM3050	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Numark	DM950	Mixer	G-MIX-B 1212				
Numark	DM950 USB	Mixer	G-MIX-B 1212				
Numark	DMX01	Mixer	G-MIX-B 1212				
Numark	DMX03	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317	GX-1	GX-2
Numark	DMX06	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317	GX-1	GX-2
Numark	DXM01 USB	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317	GX-1	GX-2
Numark	DXM06	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317	GX-1	GX-2
Numark	DXM09	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317	GX-1	GX-2
Numark	DXMPRO	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822		
Numark	HDX	Turntable	G-TOUR T-TABLE				
Numark	iDJ	Mixer	G-MIX-B 1212				
Numark	IDJ2	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR CDMX1317	
Numark	M3	Mixer	G-MIX-B 1212				
Numark	MATRIX 2	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Numark	MATRIX 3	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Numark	MIX MEISTER CONTROL	Mixer	GMC-2222	G-MIX-L 1224	G-MIX-L 1622	G-MIX-L 1724	
Numark	NUVJ	Mixer	G-MIX 20X25				
Numark	PPD01	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317	GX-1	

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Numark	TT1600MKII	Turntable	G-TOUR T-TABLE				
Numark	TT1650	Turntable	G-TOUR T-TABLE				
Numark	TT500	Turntable	G-TOUR T-TABLE				
Numark	TTUSB	Turntable	G-TOUR T-TABLE				
Numark	TTX	Turntable	G-TOUR T-TABLE				
Open Labs	NEKO 64 61	Keyboard	GKC-1648				
Open Labs	NEKO 64 76	Keyboard	GKC-1648				
Open Labs	NEKO LE 61	Keyboard	GKC-1648				
Open Labs	NEKO LE 76	Keyboard	GKC-1648				
Optoma	EZ PRO 747	Projector	GAV-1412-R	GAV-PE-1412R			
Panasonic	46PZ80U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	46PZ85U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	PT-37PD1	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Panasonic	PT-42P1	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	PT-50PD3-P	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	PT-AE700U	Projector	GAV-1412-R	GAV-PE-1412R			
Panasonic	PTLB10SVU	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PT-LB10U	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB10VU	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PT-LB20NTU	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB20SU	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB20U	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB20VU	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PT-LB30	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB30NTU	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB50NTU	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB50SU	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB50U	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB60NTU	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	PTLB60U	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Panasonic	TC23LX50	LCD/Plasma	G-TOURLCDP-2023				
Panasonic	TC-32LX60	LCD/Plasma	G-TOURLCDP-2632				
Panasonic	TC-37P1F	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Panasonic	TC-50PX14	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TC-L32C12	LCD/Plasma	G-TOURLCDP-2632				
Panasonic	TC-L37X1	LCD/Plasma	G-LCDCOVER-42				
Panasonic	TC-L42U12	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Panasonic	TC-P42C1	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Panasonic	TCP42S1	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Panasonic	TC-P42U1	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Panasonic	TC-P42X1	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TCP46G10	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Panasonic	TCP46S1	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Panasonic	TCP46U1	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Panasonic	TC-P50G10	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TC-P50S1	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TC-P50U1	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TC-P50X1	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TC-P54S1	LCD/Plasma	G-LCDCOVER-52				
Panasonic	TH37PH9UK	LCD/Plasma	G-LCDCOVER-42				
Panasonic	TH-37PR11UK/UH	LCD/Plasma	G-LCDCOVER-42				
Panasonic	TH-37PWD5UX	LCD/Plasma	G-LCDCOVER-42				
Panasonic	TH-37PWD6	LCD/Plasma	G-LCDCOVER-42				
Panasonic	TH-37PWD7UY	LCD/Plasma	G-LCDCOVER-42				
Panasonic	TH-42PD60U	LCD/Plasma	G-TOURLCD-3743T				
Panasonic	TH-42PDD3B	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PF11UK	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PH11UK	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PH9UK	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PHD5UY	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PHD6	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PHD6UY	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PHD7UY	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PHD8UK	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PR11UK/UH	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Panasonic	TH42PS9UK	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PWD3U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PWD5UY	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH-42PWD6UY	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Panasonic	TH42PX25U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-42PX600U	LCD/Plasma	G-TOURLCD-3743T				
Panasonic	TH-42PX60U	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Panasonic	TH46PZ80U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH46PZ85U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50PF11UK	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH50PF9UK	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50PH11UK	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50PH9	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50PH9UK	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Panasonic	TH-50PHD3U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50PHD5UY	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50PHD7UY	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50PX	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50PX25U/P	LCD/Plasma	G-LCDCOVER-65				
Panasonic	TH-50PX6	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50THD6UI	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-50THD6UY	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Panasonic	TH-58PF11UK	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Panasonic	TH-58PH10UKA	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Panasonic	TH58PX6	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Panasonic	TH-58PZ800U	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Panasonic	TH-65PF11UK	LCD/Plasma	G-LCDCOVER-65				
Panasonic	TH65PF9UK	LCD/Plasma	G-LCDCOVER-65				
Parkwood	PW310M	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Peavey	3120	Amp/Cabinet	G-TOUR AMP HEAD				
Peavey	16FX	Mixer	G-MIX-B 2519				
Peavey	24FX	Mixer	G-MIX 20X25				
Peavey	5150 HEAD	Amp/Cabinet	G-901				
Peavey	6505 212 COMBO	Amp/Cabinet	G-TOUR-4X12-CAB				
Peavey	6505 HEAD	Amp/Cabinet	G-901				
Peavey	6505 PLUS HEAD	Amp/Cabinet	G-901				
Peavey	BANDIT 112	Amp/Cabinet	G-212-ROTO	G-TOUR AMP2430			
Peavey	CLASSIC 212	Amp/Cabinet	G-TOUR-4X12-CAB				
Peavey	CLASSIC 30	Amp/Cabinet	G-112-ROTO				
Peavey	CLASSIC 50/212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Peavey	CLASSIC 50/410	Amp/Cabinet	G-212A				
Peavey	DELTA BLUES 115	Amp/Cabinet	G-112-ROTO	G-TOUR AMP2226			
Peavey	DELTA BLUES 210	Amp/Cabinet	G-112-ROTO	G-TOUR AMP2226			
Peavey	JSX 212COMBO	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Peavey	JSX HEAD	Amp/Cabinet	G-TOUR AMP HEAD				
Peavey	JSX412	Amp/Cabinet	G-TOUR-4X12-CAB				
Peavey	MAX 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Peavey	MAX 115	Amp/Cabinet	G-TOUR AMP2226				
Peavey	NASHVILLE 1000	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Peavey	NASHVILLE 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Peavey	PENTA 412	Amp/Cabinet	G-TOUR-4X12-CAB				
Peavey	PENTA HEAD	Amp/Cabinet	G-TOUR AMP HEAD				
Peavey	PR 10 NEO	Speaker	GPA-600				
Peavey	PR 12 NEO	Speaker	GPA-700	GPA-SCVR450-515			
Peavey	PV 12M	Speaker	GPA-600				
Peavey	PV 15M	Speaker	GPA-700	GPA-SCVR450-515			
Peavey	PV10	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR CDMX1317	GX-1
Peavey	PV14	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Peavey	PV20	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1622		
Peavey	PV20 USB	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1622		
Peavey	PV6	Mixer	G-MIX-B 1212				
Peavey	PV8	Mixer	G-MIX-B 1212				
Peavey	RQ 1606M	Mixer	GMC-3333	G-MIX 24X36	G-TOUR 20X30	G-TOUR 24X36	
Peavey	RQ 200	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Peavey	RQ 2310	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1724	G-TOUR 19X21	GX-1921-7.5
Peavey	RQ 2314	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1926	G-TOUR 19X21
Peavey	RQ 2318	Mixer	GMC-3333	G-MIX 20X30	G-MIX-B 2519	G-MIX-L 1926	G-TOUR 20X30
Peavey	RQ 2326	Mixer	G-MIX 24X36				
Peavey	STUDIO PRO 112	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Peavey	SUPREME XL	Amp/Cabinet	G-212-ROTO				
Peavey	SUPREME XL HEAD	Amp/Cabinet	G-TOUR AMP HEAD				
Peavey	TRANSTUBE 112 EFX	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Peavey	TRIPLE XXX	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Peavey	TRIPLE XXX 112	Amp/Cabinet	G-112A	G-212-ROTO	G-TOUR AMP2226		
Peavey	TRIPLE XXX 212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Peavey	TRIPLE XXX 412	Amp/Cabinet	G-TOUR-4X12-CAB				
Peavey	TRIPLE XXX HEAD	Amp/Cabinet	G-TOUR AMP HEAD				
Peavey	UNITY 1002-8 RQ	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Peavey	VALVE KING 412	Amp/Cabinet	G-TOUR-4X12-CAB				
Peavey	VALVEKING 100 HEAD	Amp/Cabinet	G-901				
Peavey	VALVEKING 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Peavey	VALVEKING 212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Peavey	Vypyr Tube 120	Amp/Cabinet	G-112A	G-TOUR AMP2226			
Peavey	WIGGY 212	Amp/Cabinet	G-TOUR-4X12-CAB				
Peavey	WINDSOR 412	Amp/Cabinet	G-TOUR-4X12-CAB				
Peavey	WINDSOR HD	Amp/Cabinet	G-TOUR AMP HEAD				
Peavey	X XL	Amp/Cabinet	G-212A				
Peavey	XR 1212	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Peavey	XR 684F	Mixer	GPA-720				
Peavey	XR 800F	Mixer	G-MIX-B 2519				
Peavey	XR 800F PLUS	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Peavey	XR1220	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1926	G-TOUR 20X30	
Peavey	XR600G	Mixer	GPA-720				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Peavey	XR696F	Mixer	GPA-720				
Peavey	XXL	Amp/Cabinet	G-212A				
Peavey	XXL HEAD	Amp/Cabinet	G-TOUR AMP HEAD				
Philips	20PF5120	LCD/Plasma	G-TOURLCDP-2023				
Philips	37PF9631D	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Philips	42FD9932	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Philips	42FD9934	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Philips	42FD9935	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Philips	42FD9954	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Philips	42FD9955	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Philips	42PW9962	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Philips	42PW9982	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Philips	47PFL3603D/27	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Philips	47PFL7403D/27	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Philips	50FD9955	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Philips	50PF7321	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Philips	50PF9630A	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Philips	50PF9830	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Philips	52PFL7422D/37	LCD/Plasma	G-LCDCOVER-52				
Philips	52PFL7432D/37	LCD/Plasma	G-LCDCOVER-52				
Phonic	HELIX 18FW	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618A
Phonic	HELIX BOARD 12	Mixer	G-MIX-B 1212				
Phonic	HELIX BOARD 17	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Phonic	IMPACT 24.4	Mixer	GMC-4221				
Phonic	MM1002	Mixer	G-MIX-B 1212				
Phonic	MM1202	Mixer	G-MIX-B 1212				
Phonic	MM1705	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR CDMX1317	
Phonic	MM1805(X)	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Phonic	MM502	Mixer	G-TOUR CDMX912				
Phonic	MR 1843X	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Phonic	MR3243	Mixer	G-MIX 24X36				
Phonic	MR4243(D)	Mixer	G-MIX 22X46				
Phonic	MR4283	Mixer	G-MIX 22X46				
Phonic	MR4283D	Mixer	G-MIX 22X46				
Phonic	MRS 1-20	Mixer	G-MIX 24X36				
Phonic	MRS 1-30	Mixer	G-MIX 22X46				
Phonic	MU1002	Mixer	G-MIX-B 1212				
Phonic	MU1202	Mixer	G-MIX-B 1212				
Phonic	MU502	Mixer	G-MIX-B 1212				
Phonic	MU802	Mixer	G-MIX-B 1212				
Phonic	PAA3	Digital Audio Gear	GP-PC301				
Phonic	POWERPOD 1840	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-B 2519	G-TOUR 19X21	GX-1921-7.5
Phonic	POWERPOD 1860II	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-B 2519	G-TOUR 19X21	GX-1921-7.5
Phonic	POWERPOD 2280	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1926		
Phonic	POWERPOD 620	Mixer	GPA-720				
Phonic	POWERPOD 740	Mixer	GPA-720				
Phonic	POWERPOD 780+	Mixer	GPA-720				
Phonic	Powerpod Series 885 plus	Mixer	GPA-720				
Pioneer	614MX	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Pioneer	CDJ-1000 MK III	CD/DVD Player	G-TOUR CD-13X17				
Pioneer	CDJ-1000 MK3	CD/DVD Player	G-TOUR CD-13X17				
Pioneer	CDJ-1000 MKII	CD/DVD Player	G-TOUR CD-13X17				
Pioneer	CDJ-1005	CD/DVD Player	G-TOUR CD-9X12				
Pioneer	CDJ-200	CD/DVD Player	G-TOUR CD-9X12				
Pioneer	CDJ2000	CD/DVD Player	G-TOUR CD-13X17				
Pioneer	CDJ-400	CD/DVD Player	G-TOUR CD-9X12				
Pioneer	DJC3000RV	Turntable	G-TOUR T-TABLE				
Pioneer	DJM-1000	Mixer	G-MIX-B 2519				
Pioneer	DJM-300	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Pioneer	DJM-3000	Mixer	G-MIX-L 1224				
Pioneer	DJM-3005	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Pioneer	DJM-400	Mixer	G-MIX-B 1212				
Pioneer	DJM-500	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618A
Pioneer	DJM-600	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618A
Pioneer	DJM-707	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317	GX-1	GX-2
Pioneer	DJM-800	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR CDMX1317	
Pioneer	DJM-909	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317	GX-1	GX-2
Pioneer	DMP-555	CD/DVD Player	G-TOUR CD-13X17				
Pioneer	DVD-V7300D	Mixer	G-MIX-B 1815	G-TOUR 12X17			
Pioneer	DVJ-1000	Turntable	G-TOUR T-TABLE				
Pioneer	EFX1000	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Pioneer	EFX500	Mixer	G-MIX-B 1212				
Pioneer	PDP 505CMX	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Pioneer	PDP 5070HD	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Pioneer	PDP 6070	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Pioneer	PDP 6100	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Pioneer	PDP-4050HD	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Pioneer	PDP-4304	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Pioneer	PDP-4330HD	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Pioneer	PDP-4330HD W/SPKS	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Pioneer	PDP-433CMX	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Pioneer	PDP-4340HD	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Pioneer	PDP-501	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Pioneer	PDP-502	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Pioneer	PDP-5020FD	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Pioneer	PDP-502MX	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Pioneer	PDP-5030HD	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Pioneer	PDP-503CMX	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Pioneer	PDP-5040HD	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Pioneer	PDP-505HD	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Pioneer	PDP-50MXE	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Pioneer	PDP-6020FD	LCD/Plasma	G-LCDCOVER-65				
Pioneer	PDP-910HD	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Pioneer	PRO-1110HD	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Pioneer	SVM1000	Mixer	G-MIX 20X25				
Planar	PDP42B	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Planar	PDP42HD	LCD/Plasma	G-TOURLCD-3743T				
Plasmasync	4210W	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Plus	U2-1200	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Polycom	SOUNDSTATION2	Digital Audio Gear	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-TOURCARRYONFO	
Polycom	VSX 3000	LCD/Plasma	G-TOURLCDP-2023				
Presonus	STUDIOLIVE 16.4.2	Mixer	G-MIX 20X25				
Proel	EX185A Sub	Speaker	G-SUB2225-24BAG				
PROEL	M20USB 20	Mixer	G-MIX 20X30	G-TOUR 20X30			
Proscan	40LC45S	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Pyle Pro	PYD-710	Mixer	G-MIX-B 1212				
Pyle-Pro	PYD1010	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Pyle-Pro	PYD1015	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Pyle-Pro	PYD1020	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Pyle-Pro	PYD1910	Mixer	G-MIX 12X24				
Pyle-Pro	PYD1920	Mixer	G-MIX 12X24				
Pyle-Pro	PYD720	Mixer	G-MIX-B 1212				
QSC	HPR122i	Digital Audio Gear	GP-PC301				
QSC	K10	Speaker	GPA-450-515	GPA-777	GPA-E15		
QSC	K12	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Raimundo	Model 125	Acoustic Guitar	GWE-CLASSIC				
Raimundo	Model 128	Acoustic Guitar	GWE-CLASSIC				
Raimundo	Model 130	Acoustic Guitar	GWE-CLASSIC				
Raimundo	Model 146	Acoustic Guitar	GWE-CLASSIC				
Raimundo	Model 148	Acoustic Guitar	GWE-CLASSIC				
Ramirez	125 Anos	Acoustic Guitar	GWE-CLASSIC				
Ramirez	1E	Acoustic Guitar	GWE-CLASSIC				
Ramirez	2E	Acoustic Guitar	GWE-CLASSIC				
Ramirez	4E	Acoustic Guitar	GWE-CLASSIC				
Ramirez	AE	Acoustic Guitar	GWE-CLASSIC				
Ramirez	FL2	Acoustic Guitar	GWE-CLASSIC				
Ramirez	GH George Harrison Model	Acoustic Guitar	GWE-CLASSIC				
Ramirez	R1	Acoustic Guitar	GWE-CLASSIC				
Ramirez	R2	Acoustic Guitar	GWE-CLASSIC				
Ramirez	R4	Acoustic Guitar	GWE-CLASSIC				
Ramirez	S1	Acoustic Guitar	GWE-CLASSIC				
Randall	R412CB	Amp/Cabinet	G-TOUR-4X12-CAB				
Randall	R412CX	Amp/Cabinet	G-TOUR-4X12-CAB				
Randall	RA412XLT	Amp/Cabinet	G-TOUR-4X12-CAB				
Randall	RH150DG3	Amp/Cabinet	G-901				
Randall	RM100M1	Amp/Cabinet	G-TOUR AMP HEAD				
Randall	RM100M2	Amp/Cabinet	G-TOUR AMP HEAD				
Randall	TITAN 412	Amp/Cabinet	G-TOUR-4X12-CAB				
Rane	GRANDMASTER FLASH	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Rane	TTM56	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Rane	TTM57SL	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
RCA	L46FHD37	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
RCA	PH50300	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
RCA	PH50400	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
RCA	PH50500	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
RCA	PR42300	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
RCF	ART 310A	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
RCF	ART 312A	Speaker	GPA-700	GPA-SCVR450-515			
RCF	ART 322A	Speaker	GPA-700	GPA-SCVR450-515			
RCF	ART 522-A	Speaker	GPA-700	GPA-SCVR450-515			
RCF	ART 525-A	Speaker	GPA-700	GPA-SCVR450-515			
RCF	ART 705-AS	Speaker	G-SUB2225-24BAG				
RCF	CW3110	Speaker	GPA-450-515				
RCF	CW5212	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
RCF	CW5215	Speaker	GPA-700				
RCF	SW4012	Speaker	GPA-450-515	GPA-E15			
RCF	TT25-SMA	Speaker	GPA-700				
RCF	TTL31-A	Speaker	GPA-777				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Revox	E-642	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Revox	E-650	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
RMS	10-400S	Mixer	GPA-720				
Rocktron	UTOPIA G100	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A		
Rocktron	UTOPIA G200	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A		
Rogue	Herringbone	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Rogue	Honduran	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Rogue	RA-100	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Rogue	USA Flagh	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Roland	CD2	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Roland	CD2E	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Roland	D 2	Keyboard	G-MEDIA PRO BP				
Roland	DJ-2000	Digital Audio Gear	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOURCARRYONFO	
Roland	DR3	Digital Audio Gear	G-MIX-B 1212				
Roland	DR670	Digital Audio Gear	G-MIX-B 1212				
Roland	DR880	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Roland	E09	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	E80	Keyboard	GKPE-76D-TSA				
Roland	EP880	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Roland	EXR-3	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	EXR46-OR	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	EXR-5	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	EXR-7	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Roland	FANTOM G6	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	FANTOM G7	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Roland	FANTOM X6	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	FANTOM X7	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Roland	FANTOM X8	Keyboard	GKC-1648	G-TOUR 88			
Roland	FANTOM XA 61	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	FP-4	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Roland	FP4BK	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Roland	FP4C-BK	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Roland	FP4C-WT	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Roland	FP4WH	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Roland	FP-5	Keyboard	GK-76	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Roland	FP-5C	Keyboard	GK-76	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Roland	FP-7	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Roland	G-1000	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Roland	G-70	Keyboard	GK-76	GKC-1648			
Roland	GR20	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Roland	GR20S	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Roland	GR-33	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618A	G-MULTIFX-2411
Roland	GW-7	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	GW8	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	Handsonic HPD	Digital Audio Gear	GMC-2222	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618A	GX-1718-7
Roland	JP-8000	Keyboard	GK-49	GKC-1540	G-TOUR 61		
Roland	JUNO D 61	Keyboard	GK-4212				
Roland	JUNO STAGE	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Roland	JUNO-D	Keyboard	GK-4212				
Roland	JUNO-G	Keyboard	GK-4212				
Roland	JV30	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	MC-307	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX-B 1815	G-MIX-L 1618A	G-MULTIFX-2411	G-TOUR 12X17
Roland	MC-808	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Roland	MC-909	Digital Audio Gear	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21
Roland	MV-8000	Digital Audio Gear	GMC-2222	G-MIX-B 2020	GP-PC309		
Roland	MV-8800	Digital Audio Gear	GMC-2222	G-MIX-B 2020	GP-PC309	G-TOUR 19X21	GX-1921-7.5
Roland	PD105WT	Digital Audio Gear	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR 12X17	G-TOURCARRYONFO
Roland	PK-5A	Digital Audio Gear	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1724	G-MIX-L 1926	
Roland	RD150	Keyboard	GKPE-88SLXL-TSA				
Roland	RD-170	Keyboard	GKPE-88SLXL-TSA				
Roland	RD-300GX	Keyboard	GKPE-88SLXL-TSA				
Roland	RD-300SX	Keyboard	GKPE-88SLXL-TSA				
Roland	RD-70	Keyboard	GKC-1648	G-TOUR 88			
Roland	RD-700GX	Keyboard	GKPE-88SLXL-TSA				
Roland	RD-700SX	Keyboard	GKPE-88SLXL-TSA				
Roland	RS-50	Keyboard	GK-4212				
Roland	RS-70	Keyboard	GK-4212				
Roland	SH-201	Keyboard	GK-49	GKC-1540			
Roland	SH-32	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Roland	SONIC CELL	Keyboard	G-MEDIA PRO BP				
Roland	SP-404	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Roland	SP-555	Digital Audio Gear	G-MEDIA PRO BP				
Roland	SP-606	Digital Audio Gear	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR 12X17	G-TOURCARRYONFO
Roland	SPD 20	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Roland	SPD-S	Digital Audio Gear	G-MEDIA PRO BP	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR 12X17	
Roland	TD-20	Digital Audio Gear	G-MIX-B 1515	G-MULTIFX-1510	G-TOUR 12X17		
Roland	V SYNTH	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	V SYNTH GT	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	VA-76	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Roland	V-BASS	Digital Audio Gear	GMC-2222	G-MIX-B 2118	G-MIX-L 1622		
Roland	VG-88	Digital Audio Gear	GMC-2222	G-MIX-B 2118	G-MIX-L 1622		
Roland	VK-7	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Roland	VK8	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Roland	VP-550	Keyboard	GK-49	GKC-1540			
Roland	VR760	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Roland	VS-2000CD	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1622	G-TOUR 19X21	
Roland	VS-2400CD	Digital Audio Gear	GMC-2222	G-MIX-B 2020	GP-PC309	G-TOUR 19X21	GX-1921-7.5
Roland	VS2480CD	Digital Audio Gear	GMC-3333				
Roland	VS2480DVD	Digital Audio Gear	GMC-3333				
Roland	VS2480M	Digital Audio Gear	GMC-3333	G-MIX 20X30	G-TOUR 20X30		
Roland	XP30	Keyboard	GK-4212				
Roland	XP-50	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Roland	XP80	Keyboard	GK-76	GKPE-76-TSA	G-TOUR 76		
Roland	XV-88	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Roland	VS-1824CD	Digital Audio Gear	GMC-2222	G-MIX-B 2519	G-MIX-L 1622		
RSS	M-48	Mixer	G-MIX-B 1212				
Runco	PL-42	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Runco	PL-42C	LCD/Plasma	G-TOURLCD-3743T				
Runco	PL-50C	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sampo	PME-42S6	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sampo	PME-42X6	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sampo	PME-50X6	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Samson	DB1500A	Speaker	G-SUB2225-24BAG				
Samson	L1200	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21	GX-1921-7.5
Samson	L2000	Mixer	G-MIX 20X30				
Samson	L2400	Mixer	G-MIX 24X36				
Samson	L3200	Mixer	G-MIX 22X46				
Samson	MDR 6	Mixer	G-MIX-B 1212				
Samson	MDR 624	Mixer	G-MIX-B 1212				
Samson	MDR10	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Samson	MDR1064	Mixer	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR CDMX1317		
Samson	MDR16	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1724	G-MIX-L 1926	
Samson	MDR1688	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Samson	MDR6	Mixer	G-MIX-B 1212				
Samson	MDR8	Mixer	G-MIX-B 1212				
Samson	MIXPAD 12	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Samson	MIXPAD 4	Mixer	G-MIX-B 1212				
Samson	MIXPAD 9	Mixer	G-MIX-B 1212				
Samson	RESOLV 120A	Speaker	GPA-600				
Samson	RS155	Speaker	G-SUB2225-24BAG				
Samson	RS185	Speaker	G-SUB2225-24BAG				
Samson	Stage 5	Wireless System	GM-5W				
Samson	Stage 55	Wireless System	GM-5W				
Samson	TM 300	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-B 2519	G-MIX-L 1822
Samson	TM 500	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-B 2519	G-MIX-L 1822
Samson	TXM16	Mixer	G-MIX 20X25				
Samsung	400CX	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	400CXN	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	400DX	LCD/Plasma	G-LCDCOVER-42				
Samsung	400DXN	LCD/Plasma	G-LCDCOVER-42				
Samsung	400FP-2	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	400FPN-2	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	400TSN-2	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	403T	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Samsung	460CX	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	460CXN	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	460DR	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	460DRN	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	460DX	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Samsung	460DXN	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Samsung	460FP-2	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	460FPN-2	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	460TSN-2	LCD/Plasma	G-LCDCOVER-52				
Samsung	460UT	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Samsung	460UTN	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Samsung	460UTN-UD	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Samsung	520DX	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	520DXN	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	570DX	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Samsung	570DXN	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Samsung	HPL-5025	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	HPN-4239	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	HPN5039	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	HP-P4271	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	HP-R5052	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	HP-S5053	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	LN32A550	LCD/Plasma	G-TOURLCDP-2632				
Samsung	LN32B360	LCD/Plasma	G-TOURLCDP-2632				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Samsung	LN37B550	LCD/Plasma	G-LCDCOVER-42				
Samsung	LN37B650	LCD/Plasma	G-LCDCOVER-42				
Samsung	LN40A550	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	LN40A650	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	LN40A750	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	LN40B530	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	LN40B550	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	LN40B630	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	LN46A550	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	LN46A650	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	LN46A750	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	LN46B530	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	LN46B550	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	LN46B640	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	LN46B650	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	LN46B750	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	LN52A580	LCD/Plasma	G-LCDCOVER-65				
Samsung	LN52A750	LCD/Plasma	G-LCD-5052	G-LCDCOVER-65	G-TOURLCDLIFT52		
Samsung	LN52A850	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Samsung	LN52B550	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	LN52B750	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	LN55B640	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Samsung	LN55296D	LCD/Plasma	G-LCDCOVER-52				
Samsung	LN-S5296D	LCD/Plasma	G-LCDCOVER-52				
Samsung	LN-T5265F	LCD/Plasma	G-LCDCOVER-65				
Samsung	LN-T5265FX	LCD/Plasma	G-LCDCOVER-65				
Samsung	LNT5271F	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Samsung	P42H	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	P42HP	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	P50FP	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	P50H	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	P50HP	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	P63FP	LCD/Plasma	G-LCDCOVER-65				
Samsung	PDP-42HD	LCD/Plasma	G-TOURLCD-3743T				
Samsung	PDP-50VG	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	PN42B450	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Samsung	PN50B450	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	PN50B550	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	PN50B650	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	PN58B550T2	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Samsung	PPM 42S3	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	PPM-42M5S	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	PPM-50H2	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	PPM-50H3	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	PPM50M5H	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	SPD-42P1	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	SPD-50P2	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Samsung	SPK-4215	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	SPL-4225	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	SPN-4235	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Samsung	SPP4251	LCD/Plasma	G-TOURLCDLIFT52				
Samsung	UN46B6000	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Samsung	UN46B8000	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Samsung	UN55B7100	LCD/Plasma	G-LCD-5052	G-LCDCOVER-65	G-TOURLCDLIFT52		
Samsung	UN55B8000	LCD/Plasma	G-LCD-5052	G-LCDCOVER-65	G-TOURLCDLIFT52		
Sanyo	DP50749	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sanyo	PDP-42H1AN	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sanyo	PDP-42WE	LCD/Plasma	G-LCD-4042	G-TOURLCDLIFT52			
Sanyo	PLC-SU51	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-X25A	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU100	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU41	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU47	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU48	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU51	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU55A	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU56	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU58	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU73	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLC-XU83	Projector	GAV-1412-R	GAV-PE-1412R			
Sanyo	PLC-XU86	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLCXW55	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sanyo	PLV-ZZ	Projector	GAV-1813-UR				
Sceptre	X37SV-NAGA	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Seagull	S6	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Seagull	The Original S6	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Selti	MPD-5010A	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Sennheiser	ew112G2 ME2	Wireless System	GM-4WR				
Sennheiser	ew122G2	Wireless System	GM-4WR				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Sennheiser	EW135G2 E835	Wireless System	GM-1W	GM-2W	GM-5W		
Sennheiser	ew152G2	Wireless System	GM-4WR				
Sennheiser	ew172G2	Wireless System	GM-4WR				
Sennheiser	ew300IEM G2	Wireless System	GM-4WR				
Sennheiser	EW345G2	Wireless System	GM-4WR				
Sharp	46D64U	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Sharp	AQUOS LC-32D40U	LCD/Plasma	G-TOURLCDP-2632				
Sharp	AQUOS LC-52D62U	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sharp	AQUOS LC52D64U	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sharp	AQUOS LC-52D82U	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sharp	LC-32SB24U	LCD/Plasma	G-TOURLCDP-2632				
Sharp	LC-37HV4U	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Sharp	LC-40E67U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sharp	LC-42D64U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sharp	LC-45GD4U	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Sharp	LC-45GD6U	LCD/Plasma	G-LCD-4647				
Sharp	LC-46D64U	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Sharp	LC46D65U	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Sharp	LC46D85U	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Sharp	LC-52D62U	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sharp	LC-52D64U	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sharp	LC52D85U	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sharp	LC-52D92U	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sharp	LCC4655U	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Sharp	LC-M3700	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Sharp	LC-PD50U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Sharp	PG-A20X	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sharp	PG-B10S	Projector	GAV-1412-R	GAV-PE-1412R			
Sharp	PG-MB60X	Projector	GAV-1412-R	GAV-PE-1412R			
Sharp	PN 465	LCD/Plasma	G-LCDCOVER-52				
Sharp	PN455RU	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Sharp	PN465U	LCD/Plasma	G-LCDCOVER-52				
Sharp	PN525U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Sharp	PN655U	LCD/Plasma	G-LCDCOVER-65				
Sharp	PNG655	LCD/Plasma	G-LCDCOVER-65				
Sharp	PNS525	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Sharp	PNS655	LCD/Plasma	G-LCDCOVER-65				
Shure	M367	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Shure	PG1288/PG185	Wireless System	GM-4WR				
Shure	PG14/PG185	Wireless System	GM-4WR				
Shure	PG14/PG30	Wireless System	GM-4WR				
Shure	PG188/PG185	Wireless System	GM-4WR				
Shure	PG24/PG58	Wireless System	GM-4WR				
Shure	PG288/PG58	Wireless System	GM-4WR				
Shure	PGX14	Wireless System	GM-5W				
Shure	PGX14 Clip-on mic	Wireless System	GM-5W				
Shure	PGX24/Beta58	Wireless System	GM-5W				
Shure	PGX24/PG58	Wireless System	GM-5W				
Shure	PGX24/SM58	Wireless System	GM-5W				
Shure	SCM262	Mixer	G-MIX-B 1212				
Shure	SCM268	Mixer	G-MIX-B 1212				
Shure	SLX	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Shure	SLX Beta58	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Shure	SLX SM58	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Shure	SLX Wireless Headset	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Shure	SLX Wireless System	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Shure	SLX1	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Shure	SLX24/Beta87A	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Silver Creek	D-160	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Silver Creek	D-170	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
SM Pro Audio	DI4	Mixer	G-MIX-B 1212				
SM Pro Audio	DI8	Mixer	G-MIX-B 1212				
Softboard	502	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Softboard	503	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Softboard	512	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Softboard	513	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Softboard	522	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Softboard	532	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Soldano	4X12 SL CAB	Amp/Cabinet	G-TOUR-4X12-CAB				
Soldano	SLO100 HEAD	Amp/Cabinet	G-901				
Sony	40V4100	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	Anycast AWS-G500	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Sony	BRAVIA KDL-46V2500	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Sony	Bravia KDL-52S5100	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Sony	BRAVIA KDL-52XBR3	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Sony	BRAVIA KDL-V32XBR2	LCD/Plasma	G-TOURLCDP-2632				
Sony	DMXP01	Mixer	G-MIX-B 1212				
Sony	FWD40LX2F/B	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	FWD40LX2F/S	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Sony	FWD50PX2/B	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	FWD-50PX2/B	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	FWD50PX2/S	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	FWD-50PX2/S	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	KDL-40D26	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40D27	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40D28	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40D30	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40S130	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40S28	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40S30	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40S504	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	KDL-40S5100	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	KDL-40T26	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40T28	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40T30	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-40V4100	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	KDL40XBR6	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	KDL-46D27	LCD/Plasma	G-TOURLCDLIFT52				
Sony	KDL-46D28	LCD/Plasma	G-TOURLCDLIFT52				
Sony	KDL-46D30	LCD/Plasma	G-TOURLCDLIFT52				
Sony	KDL-46S2000	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Sony	KDL-46S30	LCD/Plasma	G-TOURLCDLIFT52				
Sony	KDL-46S4100	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	KDL-46S5100	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	KDL-46T30	LCD/Plasma	G-TOURLCDLIFT52				
Sony	KDL-46V300A	LCD/Plasma	G-TOURLCDLIFT52				
Sony	KDL-46V4100	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Sony	KDL46V5100	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	KDL-46V5100	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	KDL-46XBR4	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	KDL-46Z4100/B	LCD/Plasma	G-TOURLCD-3743T				
Sony	KDL-52S5100	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Sony	KDL-52V5100	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Sony	KDL-52W3000	LCD/Plasma	G-LCDCOVER-52				
Sony	KDL-52XBR4	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Sony	KDL-52XBR5	LCD/Plasma	G-LCDCOVER-65	G-TOURLCDP60			
Sony	KDL-52XBR7	LCD/Plasma	G-LCDCOVER-52				
Sony	KDL-52XBR9	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	KDL-55XBR8	LCD/Plasma	G-LCDCOVER-65				
Sony	KE42TS2U	LCD/Plasma	G-LCD-4042				
Sony	KVL-40V300A	LCD/Plasma	G-TOURLCD-3743T				
Sony	PFM-42B1	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	PFM-42B2H	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	PFM-42B2U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	PFM-42V1	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	PFM-42V1-B	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	PFM-42X1	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	PFM500A2WU	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Sony	PFM500A3WU	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Sony	PFM-50C1	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	PFM510A2WU	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Sony	PSLX250H	Turntable	G-TOUR T-TABLE				
Sony	PWD-42LX1/B	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Sony	SRP-X700	Digital Audio Gear	GMC-2222	G-MIX-B 2118	G-MIX-B 2519	G-MIX-L 1822	GP-PC308
Sony	SWD-50PX1-B	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Sony	VAIO A140	Laptop	GAV-1813-UR				
Sony	VAIO A250	Laptop	GAV-1813-UR				
Sony	VAIO AR	Laptop	GAV-1813-UR				
Sony	VAIO C	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VAIO FE	Laptop	GAV-1813-UR				
Sony	VAIO FJ	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VAIO FS	Laptop	GAV-1813-UR				
Sony	VAIO K35	Laptop	GAV-1813-UR				
Sony	VAIO K37	Laptop	GAV-1813-UR				
Sony	VAIO S150	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VAIO S360P	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VAIO VGN	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VPL-CS7	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VPL-CX70	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VPL-CX75	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VPL-CX80	Projector	GAV-1412-R	GAV-PE-1412R			
Sony	VPL-CX85	Projector	GAV-1412-R	GAV-PE-1412R			
Sony	VPL-DS100	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VPL-ES2	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sony	VPL-EX1	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Sound Devices	442	Mixer	G-MIX-B 1212				
Sound Devices	788T	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Soundcraft	COMPACT 10	Mixer	G-MIX-B 1815				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Soundcraft	COMPACT 4	Mixer	G-MIX-B 1212				
Soundcraft	EFX12	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Soundcraft	EFX8	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR CDMX1317	
Soundcraft	EPM12	Mixer	G-MIX 20X25				
Soundcraft	EPM6	Mixer	G-MIX-B 2519				
Soundcraft	EPM8	Mixer	G-MIX-B 2519				
Soundcraft	FX16	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Soundcraft	FX8	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Soundcraft	GIGRAC 1000	Mixer	GPA-720				
Soundcraft	GIGRAC 1000ST	Mixer	GPA-720				
Soundcraft	K1-8	Mixer	G-MIX 20X25				
Soundcraft	LX7	Mixer	G-MIX 24X36				
Soundcraft	M 4	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21
Soundcraft	M8	Mixer	GMC-3333	G-MIX 20X30	G-TOUR 20X30		
Soundcraft	MFX 12	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21	GX-1921-7.5
Soundcraft	MFX12	Mixer	GMC-2222	G-MIX-B 1818	G-MIX-L 1618A	GX-1718-7	
Soundcraft	MFXi12	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21	
Soundcraft	MFXi20	Mixer	G-MIX 20X30				
Soundcraft	MFXi8	Mixer	GMC-2222	G-MIX-B 1818	G-MIX-L 1618A	GX-1718-7	
Soundcraft	MPM12	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Soundcraft	MPM20	Mixer	G-MIX 20X30				
Soundcraft	NOTEPAD	Mixer	G-MIX-B 1212				
Soundcraft	POWERPAD	Mixer	G-MIX-B 1212				
Soundcraft	SPIRIT E12	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
Soundcraft	SPIRIT E6	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21	GX-1718-7
Soundcraft	SPIRIT E8	Mixer	GMC-2222	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	GX-1718-7
Soundcraft	SPIRIT ES	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
Soundcraft	SPIRIT FX16	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Soundcraft	SPIRIT FX8	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Soundcraft	SPIRIT M12	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2020	G-TOUR 19X21	GX-1921-7.5
Soundcraft	SPIRIT M4	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21
Soundcraft	SPIRIT M8	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2020	G-TOUR 19X21	GX-1921-7.5
Soundcraft	SX 12	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1926	G-TOUR 19X21
Soundcraft	UREI 1601	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR CDMX1317	GX-1
Soundtech	1604	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR CDMX1317	
Squier	Affinity 5-String Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Squier	Affinity Series Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Squier	Affinity Series Precession Bass	Bass Guitar	GW-BASS	GWE-BASS			
Squier	Affinity Series Telecaster Special	Electric Guitar	GWE-ELEC				
Squier	Affinity Stratocaster	Electric Guitar	GWE-ELEC				
Squier	Deluxe Jazz Bass Active V 5-String	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Squier	Mike Dirnt P Bass	Bass Guitar	GW-BASS	GWE-BASS			
Squier	Pete Wentz Precession Bass	Bass Guitar	GW-BASS	GWE-BASS			
Squier	SA100	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Squier	SE Speacial Stratocaster	Electric Guitar	GWE-ELEC				
Squier	Standard Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Squier	Standard P Bass Special Edition	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Squier	Vintage Fretless Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Squier	Vintage '70s Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Squier	Vintage Fretless Jazz Bass	Bass Guitar	G-COBRA-BASS	G-TOUR BASS			
Squier	Vintage Precession Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Squier	Vintage TB Precession Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Stanton	C.324	CD/DVD Player	G-TOUR CD-13X17				
Stanton	C-302	CD/DVD Player	G-TOUR CD-13X17				
Stanton	C-303	CD/DVD Player	G-TOUR CD-13X17				
Stanton	C313	CD/DVD Player	G-TOUR CD-13X17				
Stanton	C314	CD/DVD Player	G-TOUR CD-13X17				
Stanton	CM-203	Mixer	GMC-2222	G-MIX-L 1618A	GX-1	GX-2	GX-3
Stanton	CM-205	Mixer	GMC-2222	G-MIX-L 1618A	GX-1	GX-2	GX-3
Stanton	M-201	Mixer	G-MIX-B 1212				
Stanton	M-202	Mixer	G-MIX-B 1212				
Stanton	M-303	Mixer	G-MIX-L 1618A	G-TOUR 12X17			
Stanton	M-304	Mixer	G-MIX-L 1618A	G-TOUR 12X17			
Stanton	M-505	Mixer	G-MIX 17X18	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317
Stanton	RM-3	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Stanton	RM-3S	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Stanton	S.252	CD/DVD Player	G-TOUR CD-9X12				
Stanton	S-250	CD/DVD Player	G-TOUR CD-9X12				
Stanton	S300	CD/DVD Player	G-TOUR CD-9X12				
Stanton	SA-12	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	GX-1	GX-2
Stanton	SA-3	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Stanton	SA-5	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Stanton	SA-8	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Stanton	SCS3	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Stanton	SK-2	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Stanton	SK-2F	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Stanton	SK-5	Mixer	G-MIX-B 1212				
Stanton	SK-6	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Stanton	SK-6F	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Stanton	SK-ONE	Mixer	G-MIX-B 1515				
Stanton	SMX-201	Mixer	G-MIX-B 1212				
Stanton	SMX-211	Mixer	G-MIX-B 1212				
Stanton	SMX-301	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	GX-1	GX-2
Stanton	SMX-401	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	GX-1	GX-2
Stanton	SMX-501	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17		
Stanton	ST-100	Turntable	G-TOUR T-TABLE				
Stanton	ST-90	Turntable	G-TOUR T-TABLE				
Stanton	STR8-100	Turntable	G-TOUR T-TABLE				
Stanton	STR8-20	Turntable	G-TOUR T-TABLE				
Stanton	STR8-30	Turntable	G-TOUR T-TABLE				
Stanton	STR8-50	Turntable	G-TOUR T-TABLE				
Stanton	STR8-60	Turntable	G-TOUR T-TABLE				
Stanton	STR8-80	Turntable	G-TOUR T-TABLE				
Stanton	STR8-90	Turntable	G-TOUR T-TABLE				
Stanton	T50	Turntable	G-TOUR T-TABLE				
Stanton	T60	Turntable	G-TOUR T-TABLE				
Stanton	T80	Turntable	G-TOUR T-TABLE				
Stanton	T90	Turntable	G-TOUR T-TABLE				
Studio Logic	SL 990XP	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Studio Logic	VMK149	Keyboard	GK-49	GKC-1540			
Studio Logic	VMK188	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Studiologic	SL161PRO	Keyboard	GK-4212	GKB-49	GKPE-49-TSA		
Studiologic	SL880PRO	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Studiomaster	C1	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR CDMX1317		
Studiomaster	CSX	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21	
Studiomaster	PAX10	Speaker	GPA-600				
Studiomaster	PAX12	Speaker	GPA-777				
Studiomaster	VPX12	Speaker	GPA-700	GPA-SCVR450-515			
Studiomaster	VX12	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Studiomaster	VX15	Speaker	GPA-700				
Studiomaster	VX15SUB	Speaker	GPA-700				
Sunn	T50C	Amp/Cabinet	G-212A	G-TOUR AMP2430			
Suzuki	SP-37	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Suzuki	SP-67	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
SVA	HD4208T11	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Sylvania	LC320SS9	LCD/Plasma	G-TOURLCDP-2632				
Takamine	EAN10C	Acoustic Guitar	GL-JUMBO	GW-JUMBO-TW			
Takamine	EF340SC	Acoustic Guitar	GL-JUMBO	GW-JUMBO-TW			
Takamine	EF3415C	Acoustic Guitar	GL-JUMBO	GW-JUMBO-TW			
Takamine	EG334SC	Acoustic Guitar	GL-JUMBO	GW-JUMBO-TW			
Takamine	EGS235C	Acoustic Guitar	GL-JUMBO	GW-JUMBO-TW			
Takamine	G320	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Takamine	G340	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Takamine	G360S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Takamine	GS330-S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Takamine	Jasmine S35	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Takamine	TAN15C	Acoustic Guitar	GL-JUMBO	GW-JUMBO-TW			
Takamine	TAN16 Koa	Acoustic Guitar	GL-JUMBO	GW-JUMBO-TW			
Tannoy	ELLIPSE212ID	Speaker	G-SUB2225-24BAG				
Tapco	6918S	Speaker	G-SUB2225-24BAG				
Tapco	BLEND 6	Mixer	G-MIX-B 1212				
Tapco	MIX100	Mixer	G-MIX-B 1212				
Tapco	MIX120	Mixer	G-MIX-B 1212				
Tapco	MIX220FX	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR 12X17	GX-1
Tapco	MIX260FX	Mixer	GMC-2222	G-MIX-B 1515	G-MIX-L 1618A	GX-1718-7	
Tapco	MIX50	Mixer	G-TOUR CDMX912				
Tapco	MIX60	Mixer	G-MIX-B 1212				
Tapco	TH-15A	Speaker	GPA-700				
Tascam	2488	Digital Audio Gear	GMC-2222	G-MIX-B 2519	G-MIX-L 1822	G-MIX-L 1926	GP-PC308
Tascam	2488 MK2	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1822	G-MIX-L 1926	
Tascam	2488 NEO	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1822	G-MIX-L 1926	
Tascam	2488MKII	Digital Audio Gear	GMC-2222	G-MIX-B 2519	G-MIX-L 1822	G-MIX-L 1926	GP-PC308
Tascam	414 MKII	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOURCARRYONFO	
Tascam	424 MKII	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Tascam	CD-D4000 MKII	CD/DVD Player	G-TOUR CD-9X12				
Tascam	CD-DJ1	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Tascam	DM24	Mixer	GMC-3333				
Tascam	DP-01	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-TOURCARRYONFO	
Tascam	DP01FX	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1622		
Tascam	DP-01FXCD	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618A	G-TOURCARRYONFO
Tascam	DP-02	Digital Audio Gear	GMC-2222	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 12X17
Tascam	DP-02CF	Digital Audio Gear	GMC-2222	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 12X17
Tascam	DP-02FX/CD	Digital Audio Gear	GMC-2222	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 12X17
Tascam	FIREONE	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Tascam	FW-1082	Digital Audio Gear	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21
Tascam	FW-1884	Digital Audio Gear	GMC-3333	G-MIX 20X30	G-MIX-B 2519	G-MIX-L 1926	GP-PC309
Tascam	MD-301RMKII	Digital Audio Gear	GMC-2222	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-TOURCARRYONFO
Tascam	MF-P01	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Tascam	P11 PRINTER	Digital Audio Gear	G-MIX-B 1212				
Tascam	PORTA 02	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Tascam	PORTA 02MKII	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Tascam	US-428	Digital Audio Gear	G-MEDIA PRO BP	G-MIX-B 1515	G-MIX-L 1618A	G-TOUR 12X17	G-TOUR 12X17
Tatun	P42B5MT	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Tatun	P46T	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52	G-TOURLCDP50		
Taylor	110	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Taylor	210	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Taylor	310	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Taylor	110e	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Taylor	210e	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Taylor	410Ce	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Taylor	Big Baby	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
TC Electronic	Desktop Konnekt 6	Digital Audio Gear	G-MIX-B 1212				
TC Electronic	G-SYSTEM	Digital Audio Gear	GMC-2222	G-MIX-L 1224	G-MIX-L 1622	G-MULTIFX-2411	GX-1224-8
TC Electronic	NOVA SYSTEM	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1110			
Technics	SH-EX1200	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
Technics	SH-MZ1200	Mixer	G-MIX-B 1515	G-TOUR 12X17	G-TOUR 12X17	G-TOUR CDMX1317	
THD	2X12 CAB	Amp/Cabinet	G-212-ROTO				
Thomson	42HT93PU	LCD/Plasma	G-LCD-4647				
Thomson	42WS90E3	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Thomson	42WS93E	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
TL Audio	FAT TRACK	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1618A		
TL Audio	M416	Mixer	GMC-3333				
Toft Audio	ATB16	Mixer	GMC-3333				
Tone King	COMET 40B	Amp/Cabinet	G-TOUR AMP2430				
Topaz	S18-4	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1724	G-TOUR 19X21	
Topaz	S28-4	Mixer	G-MIX 24X36				
Toshiba	32AV502U	LCD/Plasma	G-TOURLCDP-2632				
Toshiba	37AV502R/U	LCD/Plasma	G-LCDCOVER-42				
Toshiba	40RV525U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Toshiba	40XV645U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Toshiba	42WP27B	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Toshiba	46XV540U	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Toshiba	46XV645U	LCD/Plasma	G-LCD-4647	G-TOURLCDLIFT52			
Toshiba	47ZV650U	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Toshiba	50HP66	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Toshiba	50WP27B	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Toshiba	52HL167	LCD/Plasma	G-TOURLCDLIFT52				
Toshiba	52LX177	LCD/Plasma	G-LCDCOVER-52				
Toshiba	PORTEGE R100	Laptop	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Toshiba	QOSMIO G20	Laptop	GAV-1813-UR				
Toshiba	SATELLITE M35X	Laptop	GAV-1813-UR				
Toshiba	SATELLITE 2435-S255	Laptop	GAV-1412-R	GAV-PE-1412R			
Toshiba	SATELLITE A105	Laptop	GAV-1813-UR				
Toshiba	SATELLITE A25	Laptop	GAV-1412-R	GAV-PE-1412R			
Toshiba	SATELLITE A45	Laptop	GAV-1412-R	GAV-PE-1412R			
Toshiba	SATELLITE A75	Laptop	GAV-1813-UR				
Toshiba	SATELLITE M35	Laptop	GAV-1813-UR				
Toshiba	SATELLITE P25	Laptop	GAV-1813-UR				
Toshiba	SATELLITE PRO M15-S405	Laptop	GAV-1412-R	GAV-PE-1412R			
Toshiba	SATELLITE R15	Laptop	GAV-1412-R	GAV-PE-1412R			
Toshiba	TDP-S20U	Projector	GAV-1412-R	GAV-PE-1412R			
Toshiba	TDP-SW80U	Projector	GAV-1412-R	GAV-PE-1412R			
Turbosound	TXD115	Speaker	G-SUB2225-24BAG				
Turbosound	TXD-118	Speaker	G-SUB2225-24BAG				
Universal	42	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Universal	MVP 2420	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Vestax	CDX-05	Mixer	G-MIX-B 1212				
Vestax	PCV-275	Mixer	G-MIX 12X24				
Vestax	PMC-007	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	GX-1	
Vestax	PMC-05PRO III	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	GX-1	GX-2
Vestax	PMC-05PRO SL	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	GX-1	GX-2
Vestax	PMC-07	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	GX-1	GX-2
Vestax	PMC-37 PRO	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	GX-1	GX-2
Vestax	VCM-600	Digital Audio Gear	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-TOURCARRYONFO	
Vestax	VMC-002	Mixer	G-MIX-B 1212				
Vestax	VMC-185	Mixer	GMC-2222	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 12X17	GX-1
Vestax	HANDY TRAX	Turntable	G-TOUR T-TABLE				
Vestax	PCV150	Mixer	G-MIX-L 1224				
Vestax	PMC06PROA	Mixer	G-MIX-B 1815				
Vestax	PMC07PRO	Mixer	GMC-2222	G-MIX-L 1618A	G-TOUR 12X17	GX-1	GX-2
Vestax	VCI-100	Turntable	G-TOUR T-TABLE				
Vestax	VCI-300	Turntable	G-TOUR T-TABLE				
Viewsonic	CINE1000	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Viewsonic	N3751W	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Viewsonic	N4290P	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Viewsonic	N4785P	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Viewsonic	PJ400	Projector	GAV-20				

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Viewsonic	PJ452	Projector	GAV-20				
Viewsonic	PJ656	Projector	GAV-1412-R	GAV-PE-1412R			
Viewsonic	PJ658	Projector	GAV-1412-R	GAV-PE-1412R			
Viewsonic	PJ766D	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R	
Viewsonic	PJ862	Projector	GAV-1412-R	GAV-PE-1412R			
Viewsonic	VPW-425	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Viewsonic	VPW-4255	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Viewsonic	VPW-450WD	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Viewsonic	VPW-505	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Vizio	P50HDM	LCD/Plasma	G-TOURLCDLIFT52				
Vox	AC100CPH	Amp/Cabinet	G-901				
Vox	AC15H1TV LTD	Amp/Cabinet	G-112-ROTO				
Vox	AC15H1TVL	Amp/Cabinet	G-112-ROTO				
Vox	AC30BM	Amp/Cabinet	G-212A				
Vox	AC30CC1	Amp/Cabinet	G-TOUR AMP2226				
Vox	AC30CC2	Amp/Cabinet	G-212A				
Vox	AC30CC2X	Amp/Cabinet	G-212A				
Vox	AC30CCH	Amp/Cabinet	G-901				
Vox	AC50CP2	Amp/Cabinet	G-212A				
Vox	AD100VT	Amp/Cabinet	G-212A				
Vox	AD120VTH	Amp/Cabinet	G-212A				
Vox	AD120VTX NEODOG	Amp/Cabinet	G-212A				
Vox	AD212	Amp/Cabinet	G-212A				
Vox	AD50VT	Amp/Cabinet	G-112-ROTO	G-TOUR AMP2226			
Vox	AD60VTX NEODOG	Amp/Cabinet	G-112-ROTO	G-TOUR AMP2226			
Vox	DA20	Amp/Cabinet	G-112-ROTO				
Vox	TONELAB	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510	G-TOUR 12X17	G-TOUR 12X17	
Vox	TONELAB LE	Digital Audio Gear	GK-2110	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-L 1224	G-MULTIFX-2411
Vox	V112HTV	Amp/Cabinet	G-112-ROTO				
Vox	V212BN	Amp/Cabinet	G-212A				
Vox	V212BNX	Amp/Cabinet	G-212A				
Vox	V412BK	Amp/Cabinet	G-TOUR-4X12-CAB				
Vox	V412BN	Amp/Cabinet	G-TOUR-4X12-CAB				
Warwick	Corvette \$\$ Double Buck	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Warwick	Corvette Standard Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Warwick	Corvette Standard Fretless Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Warwick	Rock Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Warwick	Thumb Bass	Bass Guitar	GW-BASS	GWE-BASS	GWE-BASS-PINK		
Washburn	C40N	Acoustic Guitar	GWE-CLASSIC				
Washburn	C40S	Acoustic Guitar	GWE-CLASSIC				
Washburn	C80S	Acoustic Guitar	GWE-CLASSIC				
Washburn	D10QSB	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Washburn	D10S12	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Washburn	D30S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Washburn	D52SW	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Washburn	WD10	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Washburn	WD32SW	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Westinghouse	LTV-20V4	LCD/Plasma	G-TOURLCDP-2023				
Westinghouse	LTV-32W4	LCD/Plasma	G-TOURLCDP-2632				
Westinghouse	TX-52F480S	LCD/Plasma	G-TOURLCDLIFT52				
Westinghouse	VM-47F140S	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Wharfedale	R-1604FX	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618A		
Wharfedale	R-2004FX	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Wharfedale	SW300	Speaker	GPA-777				
Wharfedale	SW380	Speaker	G-SUB2225-24BAG				
Wharfedale	TITAN 12	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Williams	ENCORE	Keyboard	GKPE-88SLXL-TSA				
Yamaha	01V	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1822	G-MIX-L 1926	
Yamaha	01X	Digital Audio Gear	GMC-2222	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21	GX-1718-7
Yamaha	9000 Pro	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Yamaha	A12M	Speaker	GPA-600	GPA-SCVR450-515			
Yamaha	A15W	Speaker	G-SUB2225-24BAG				
Yamaha	AW1600	Digital Audio Gear	GMC-2222	G-MIX-B 1815	G-MIX-L 1622		
Yamaha	AW16G	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Yamaha	AW2400	Mixer	GMC-2222				
Yamaha	AW4416HDCD	Digital Audio Gear	GMC-3333	G-MIX 20X30	G-MIX-B 2519	G-MIX-L 1926	GP-PC309
Yamaha	BR10	Speaker	GPA-450-515	GPA-777	GPA-E15		
Yamaha	BR12	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Yamaha	BR12M	Speaker	GPA-600	GPA-SCVR450-515			
Yamaha	C112V	Speaker	GPA-700	GPA-SCVR450-515			
Yamaha	CG Series	Acoustic Guitar	GWE-CLASSIC				
Yamaha	CG101A	Acoustic Guitar	GWE-CLASSIC				
Yamaha	CG111C	Acoustic Guitar	GWE-CLASSIC				
Yamaha	CG111S	Acoustic Guitar	GWE-CLASSIC				
Yamaha	CG151C	Acoustic Guitar	GWE-CLASSIC				
Yamaha	CG171S	Acoustic Guitar	GWE-CLASSIC				
Yamaha	CG171SF	Acoustic Guitar	GWE-CLASSIC				
Yamaha	CGS102	Acoustic Guitar	GWE-CLASSIC				
Yamaha	CM10V	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Yamaha	CM12V	Speaker	GPA-700	GPA-SCVR450-515			
Yamaha	CP300	Keyboard	GKC-1648				
Yamaha	CP33	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Yamaha	CSX1	Keyboard	GK-4212				
Yamaha	DD65	Digital Audio Gear	G-MIX 20X25	GP-PC309			
Yamaha	DG-60	Amp/Cabinet	G-112-ROTO				
Yamaha	DG-80	Amp/Cabinet	G-112-ROTO				
Yamaha	DGX203	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Yamaha	DGX230	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Yamaha	DGX305	Keyboard	GKC-1648				
Yamaha	DGX505	Keyboard	GKC-1648				
Yamaha	DGX620	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Yamaha	DJX 203	Keyboard	GKB-61				
Yamaha	EMX 212S	Mixer	GPA-720				
Yamaha	EMX 312S	Mixer	GPA-720				
Yamaha	EMX 312SC	Mixer	GPA-720				
Yamaha	EMX 5014C	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Yamaha	EMX 5016CF	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Yamaha	EMX 512S	Mixer	GPA-720				
Yamaha	EMX 512SC	Mixer	GPA-720				
Yamaha	EMX 620	Mixer	GPA-720				
Yamaha	EMX 640	Mixer	GPA-720				
Yamaha	EMX 860ST	Mixer	GPA-720				
Yamaha	EMX2000	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Yamaha	EMX3000	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Yamaha	EMX5000	Mixer	G-MIX 20X25				
Yamaha	EMX5000-12	Mixer	G-MIX 20X25				
Yamaha	EMX62M	Mixer	GPA-720				
Yamaha	EMX66M	Mixer	GPA-720				
Yamaha	EMX68S	Mixer	GPA-720				
Yamaha	EMX88S	Mixer	GPA-720				
Yamaha	EZ150	Keyboard	GK-49	GKPE-61-TSA	G-TOUR 61		
Yamaha	EZ200	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	EZ250I	Keyboard	GK-49	GKPE-61-TSA	G-TOUR 61		
Yamaha	F335	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Yamaha	F345	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Yamaha	FD01S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Yamaha	FG700S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Yamaha	FG720S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Yamaha	FG730S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Yamaha	FG735S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Yamaha	FG750S	Acoustic Guitar	GC-DREAD	G-COM-DREAD	GL-DREAD	G-TOUR DREAD-12	GW-DREAD
Yamaha	GF12/12	Mixer	G-MIX 20X25				
Yamaha	GF16/12	Mixer	G-MIX 24X36				
Yamaha	GF24/12	Mixer	G-MIX 22X46				
Yamaha	KX25	Keyboard	GK-2110	G-MEDIA PROBPXL			
Yamaha	KX49	Keyboard	GK-49	GKPE-49-TSA			
Yamaha	KX61	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	KX8	Keyboard	GKB-88	GKPE-88-TSA	G-TOUR 88		
Yamaha	MD4S	Digital Audio Gear	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Yamaha	MD8	Digital Audio Gear	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1724	G-TOUR 19X21
Yamaha	MG10/2	Mixer	G-MIX-B 1212				
Yamaha	MG102C	Mixer	G-MIX-B 1212				
Yamaha	MG12/4	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR CDMX1317
Yamaha	MG12/4 FX	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR CDMX1317
Yamaha	MG124C	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Yamaha	MG124CX	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Yamaha	MG16/4	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Yamaha	MG16/6FX	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21
Yamaha	MG166C	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2020	G-TOUR 19X21	GX-1921-7.5
Yamaha	MG166CX	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2020	G-TOUR 19X21	GX-1921-7.5
Yamaha	MG206C	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2020	G-TOUR 19X21	GX-1921-7.5
Yamaha	MG206C-USB	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2020	G-TOUR 19X21	GX-1921-7.5
Yamaha	MG24/14	Mixer	G-MIX 24X36				
Yamaha	MG24/14FX	Mixer	GMC-3333	G-TOUR 24X36			
Yamaha	MG32/14FX	Mixer	G-MIX 22X46				
Yamaha	MG8/2FX	Mixer	G-MIX-B 1212				
Yamaha	MG82CX	Mixer	G-MIX-B 1212				
Yamaha	MM1242	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Yamaha	MM1402	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	G-TOUR 19X21
Yamaha	MM6	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	MM8	Keyboard	GKB-88	GKPE-88-TSA	G-TOUR 88		
Yamaha	MO6	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	MO8	Keyboard	GKC-1648	G-TOUR 88			
Yamaha	MOTIF ES6	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	MOTIF ES7	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Yamaha	MOTIF ES8	Keyboard	GKC-1648	G-TOUR 88			
Yamaha	MOTIF XS6	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	MOTIF XS7	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Yamaha	MOTIF XS8	Keyboard	GKC-1648	G-TOUR 88			
Yamaha	MOTIF6	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	MOTIF8	Keyboard	GKC-1648	G-TOUR 88			
Yamaha	MSR250	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Yamaha	MSR400	Speaker	GPA-700	GPA-SCVR450-515			
Yamaha	MSR800W	Speaker	G-SUB2225-24BAG				
Yamaha	MW10 USB	Mixer	G-MIX-B 1212				
Yamaha	MW12 USB	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618A	
Yamaha	MX12/4	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Yamaha	MX12/6	Mixer	GMC-2222	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618A	G-TOUR 19X21
Yamaha	MX20/6	Mixer	G-MIX 20X30	G-TOUR 20X30			
Yamaha	MX200-12	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1926		
Yamaha	MX200-16	Mixer	GMC-3333	G-MIX 24X36	G-TOUR 20X30	G-TOUR 24X36	
Yamaha	MX200-24	Mixer	GMC-4221				
Yamaha	MX200-8	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	GX-1921-7.5
Yamaha	N8	Mixer	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
Yamaha	O1V96	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1822	G-MIX-L 1926	
Yamaha	O1V96VCM	Mixer	GMC-2222	G-MIX-B 2519	G-MIX-L 1822	G-MIX-L 1926	
Yamaha	P120	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Yamaha	P120S	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Yamaha	P140	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Yamaha	P-150	Keyboard	GKB-88	GKPE-88-TSA	G-TOUR 88		
Yamaha	P155B	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Yamaha	P200	Keyboard	GKC-1648	G-TOUR 88			
Yamaha	P250	Keyboard	GKC-1648				
Yamaha	P60	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Yamaha	P60S	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Yamaha	P-70	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Yamaha	P85	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Yamaha	P90	Keyboard	GK-88 SLIM	GKPE-88SLIM-TSA	G-TOUR 88 SLIM		
Yamaha	PDM-1	LCD/Plasma	G-LCDCOVER-52	G-TOURLCDP50			
Yamaha	PF15	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Yamaha	PF500	Keyboard	GKC-1648				
Yamaha	PSR 175	Keyboard	GK-49	GKPE-61-TSA	G-TOUR 61		
Yamaha	PSR-172	Keyboard	GK-49	GKPE-61-TSA	G-TOUR 61		
Yamaha	PSR-273	Keyboard	GK-49	G-TOUR 61			
Yamaha	PSR-293	Keyboard	GKB-61	GKPE-61-TSA	G-TOUR 61		
Yamaha	PSR-3000	Keyboard	GK-61	GKC-1540			
Yamaha	PSR-E203	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	PSR-E213	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	PSR-E223	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	PSR-E303	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	PSR-E313	Keyboard	GK-49	G-TOUR 61			
Yamaha	PSR-E323	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	PSR-E403	Keyboard	GKB-61	GKPE-61-TSA	G-TOUR 61		
Yamaha	PSR-E413	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	PSR-OR700	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	PSR-S500	Keyboard	GKB-61	GKPE-61-TSA	G-TOUR 61		
Yamaha	PSR-S550BK	Keyboard	GKB-61	GKPE-61-TSA	G-TOUR 61		
Yamaha	PSR-S700	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	PSR-S900	Keyboard	GK-61	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	RADIUS-R	Mixer	G-MIX 12X24				
Yamaha	S03	Keyboard	GK-4212				
Yamaha	S08	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Yamaha	S112V	Speaker	GPA-700	GPA-SCVR450-515			
Yamaha	S70 XS	Keyboard	GKC-1648				
Yamaha	S90	Keyboard	GKC-1648	G-TOUR 88			
Yamaha	S90ES	Keyboard	GKC-1648	G-TOUR 88			
Yamaha	S90XS	Keyboard	GKC-1648				
Yamaha	SM12V	Speaker	GPA-700	GPA-SCVR450-515			
Yamaha	STAGEPAS 250M	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Yamaha	STAGEPAS 500	Speaker	GPA-450-515	GPA-777	GPA-E15	GPA-SCVR450-515	
Yamaha	TYROS	Keyboard	GKC-1648				
Yamaha	TYROS2	Keyboard	GKC-1648				
Yamaha	TYROS3	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Yamaha	YPG225	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Yamaha	YPG-235	Keyboard	GK-76	GKC-1648	GKPE-76-TSA	G-TOUR 76	
Yamaha	YPG525	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Yamaha	YPG625	Keyboard	GK-88	GKC-1648	GKPE-88-TSA	G-TOUR 88	
Yamaha	YPT-200	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	YPT-310	Keyboard	GK-49	GKC-1540	GKPE-61-TSA	G-TOUR 61	
Yamaha	YPT-400	Keyboard	GKB-61	GKPE-61-TSA	G-TOUR 61		
Yorkville	AP812	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1926	G-TOUR 20X30	
Yorkville	AP818	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1926	G-TOUR 20X30	
Yorkville	MAX16	Mixer	GMC-3333	G-MIX 24X36	G-TOUR 20X30		
Yorkville	MAX22	Mixer	GMC-4221				
Zenith	P42W22B	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Zenith	P42W24B/P	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		
Zenith	P42W34/34H	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T	G-TOURLCDLIFT52		

Manufacturer	Model	Type	Fit (1)	Fit (2)	Fit (3)	Fit (4)	Fit (5)
Zenith	P42W46X	LCD/Plasma	G-LCDCOVER-42	G-TOURLCDLIFT52			
Zenith	P50W28B	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Zenith	P50W38/38H	LCD/Plasma	G-LCD-5052	G-TOURLCDLIFT52	G-TOURLCDP50		
Zoom	G2	Digital Audio Gear	G-MIX-B 1212				
Zoom	G7	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-B 1815	G-MIX-L 1224	G-MULTIFX-2411
Zoom	G7.1UT	Digital Audio Gear	G-MEDIA PROBPXL	G-MIX 12X24	G-MIX-B 1815	G-MIX-L 1224	G-MULTIFX-2411
Zoom	G92TT	Digital Audio Gear	G-MIX-L 1224				
Zoom	HD-16	Mixer	GMC-2222	G-MIX-B 2118	G-MIX-L 1622	G-MIX-L 1724	G-MIX-L 1822
Zoom	John 5 G1J	Digital Audio Gear	G-MIX-B 1212				
Zoom	MRS1044	Digital Audio Gear	GMC-2222	G-MEDIA PROBPXL	G-MIX-B 1815	G-MIX-L 1618A	G-MULTIFX-2411
Zoom	MRS1608CD	Digital Audio Gear	GMC-2222	G-MIX 20X25	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
Zoom	MRS4B	Digital Audio Gear	G-MIX-B 1212				
Zoom	MRS-8	Digital Audio Gear	G-MEDIA PRO BP	G-MULTIFX-1510			
Zoom	MRS802BCD	Digital Audio Gear	GMC-2222	G-MIX-L 1618A	G-MULTIFX-2411	G-TOUR 12X17	G-TOURCARRYONFO
Zoom	RT223	Digital Audio Gear	G-MIX-B 1212				
Zoom	SB246	Digital Audio Gear	G-MIX-B 1212				

This list is intended as a guide; not a substitute for testing the actual fit of an instrument. All product information referenced above is based on the manufacturer's published specifications. These specifications may change over time and without notice. If you have questions on a specific case or product, or see that a correction is needed, please contact Gator Customer Service at 813.221.4191 or send us an email at info@gatorcases.com.



Master Cross Reference Chart

Interior Case Dimenisons

Standard

Model	Length	Width	Height	Overall Length	Lower Bout Width	Middle Bout Width	Upper Bout Width	Body Length	Body Height
GUITAR									
G-112A	25	12	19.5						
G-112-ROTO	23.5	12.5	21						
G-212A	30	12	24						
G-212-ROTO	26.75	12.5	21						
G-901	30	10.5	12.5						
GC-BASS				47.5	13.75	13.75	13.75	21.25	3
GC-DREAD				41.75	16.5	12.5	13	23	5.25
GC-DREAD-12				43.625	16.25	11.75	12.375	23.625	5.25
GC-ELECTRIC-A				40	12.75	12.75	12.75	19.38	3.25
GC-ELEC-XL				42	12.75	12.75	12.75	18.75	3.5
GC-JUMBO				44	17.25	11	12.5	21	5.5
GC-LPS				41.25	13.25	7.75	9.25	18	3.75
G-COBRA-BASS				47	15	13	12	21	3.5
G-COBRA-CLASS				40.5	15.25	10.25	11.5	20	3.75
G-COBRA-DREAD				41.5	16	13	12	22	5.5
G-COBRA-ELEC				38	12.75	14.75	14.5	20	3.5
G-COM-BASS				47	15	13	12	21	3.5
G-COM-DREAD				41.5	16	13	12	22	5.5
G-COM-ELEC				38	12.75	14.75	14.5	20	3.5
GC-SG				40.5	13.5	10	11	17	2.25
GL-AC-BASS				50.5	17.25	12	13.75	25	6.5
GL-BASS				47.5	13.63	13.63	13.63	21	3
GL-CLASSIC				41	15.5	10.25	11.75	20.5	4.5
GL-DREAD				41.75	16	12.5	12.5	21.25	5
GL-DREAD-12				43	16	12.5	13	21.5	5
GL-ELECTRIC				39.5	12.75	12.75	12.75	19	3.38
GL-JUMBO				44.625	17.625	11.375	13	23.25	5.5
GL-LPS				42.25	13.875	9.375	10	21.625	3.375
GL-SG				40.375	13.625	9.875	11.125	17.75	2
G-MULTIFX-1110	11.25	10.25	4.25						
G-MULTIFX-1510	15.5	10.5	5						
G-MULTIFX-2411	24	11.25	4.75						
GPE-335-TSA				43	16.5	11.5	13	22.5	4.5
GPE-BASS-TSA				47.625	13.625	13.625	13.625	21.125	2.625
GPE-CLASSIC-TSA				40	15.5	10.5	11.5	21.25	4.5
GPE-DREAD-TSA				41.5	16.5	12.75	13.75	22.5	4.75
GPE-ELEC-TSA				39.5	12.75	12.75	12.75	19.25	3.25
GPE-LPS-TSA				42	13.25	7.75	9.5	18.5	3.25
GSLING-BASS				47.5	16	14	12.5	21	2.5
GSLING-CLASS				40.5	16	13.5	11.5	20	4
GSLING-DREAD				42.5	15.5	12.5	12.75	22	4
GSLING-ELEC				40.5	15.25	14	14.5	22	4
G-TOUR AMP HEAD	32	12	14						
G-TOUR AMP2226	26	13	22						
G-TOUR AMP2430	30	13	24						
G-TOUR BASS				46	14	11	13	21	2.5
G-TOUR DREAD-12				43.5	16.75	11.5	12	22.25	5.75
G-TOUR ELEC				40.13	12.75	12.75	12.75	19.25	2.5
G-TOUR LPS				40	13	13	13	18	3.5
G-TOUR-4X12-CAB	32	17	32						
GW-BASS				47	13	13	13	21.75	3.75
GW-BASS-TW				46.25	13	13	13	21.25	3.5
GW-CLASSIC				41	15.5	11.5	12	23.25	5
GW-CLASSIC-TW				41.5	15	11.5	11.75	20	3.75
GW-DREAD				43	16.5	11.75	12	22.25	5.5
GW-DREAD-TW				42.5	16.5	12.25	12.75	18.25	5.5
GWE-ACOU-3/4				38	13.75	9.75	10.25	19	4.75
GWE-BASS				46.75	12.75	12.75	12.75	22	3.25
GWE-CLASSIC				40.75	14.5	10.5	11.5	23.5	4.5
GWE-DREAD 12				43.5	16.875	13.125	13.625	22.5	5.5
GWE-ELEC				39.5	13	13	13	18.875	3.125
GWE-ELEC TW				39.5	12.68	12.68	12.68	18.33	3.32
GW-ELECTRIC				40.5	12.5	12.5	12.5	19	3.25
GW-ELECTRIC-TW				40	12.75	12.75	12.75	18.75	3
GW-ELECT-VIN				40	12.75	12.75	12.75	18.75	3
GWE-LPS CAMO				40	14	9.75	10	21.25	4.5

Model	Length	Width	Height	Overall Length	Lower Bout Width	Middle Bout Width	Upper Bout Width	Body Length	Body Height
GWE-LPS-BLK				40	14	9.75	10	21.25	4.5
GW-JUMBO				44.5	17.25	11.25	13	23.5	5.5
GW-JUMBO-TW				44.5	17.25	11.25	13	23.5	5.5
GW-LP-BROWN				39.5	13.5	9.5	9.5	20.5	4.25
GW-LPS				39.5	13.5	9.5	9.5	20.5	4.25
GW-LPS-TW				39.5	13.5	9.5	9.5	20.5	4.25
GW-SG-BROWN				40.5	13	9	10.5	19.75	3.25

KEYBOARD

GK-2110	22.5	11.5	4						
GK-4212	42.25	12	5.5						
GK-49	38	15	5.5						
GK-61	43	17.5	6.5						
GK-76	51.5	18	6.25						
GK-88	57.5	18	6						
GK-88 SLIM	54	15	6						
GKB-49	37	15	5						
GKB-61	43	17.5	6.5						
GKB-76	51.5	18	6.25						
GKB-88	57.5	18	6.25						
GKB-88 SLIM	54	15	6						
GKC-1540	43	17.5	6.5						
GKC-1648	59.1	23	7						
GK-LT25W	25	12	3						
GKPE-49-TSA	36.5	12.5	4						
GKPE-61-TSA	44	17.38	6						
GKPE-76D-TSA	51.25	20	8						
GKPE-76-TSA	51.25	18	6						
GKPE-88SLIM-TSA	54	15	6						
GKPE-88SLXL-TSA	59	15	6						
GKPE-88-TSA	59	19	6.63						
G-TOUR 61	44	17.38	6						
G-TOUR 76	51.25	18	6						
G-TOUR 88	59	19	6.63						
G-TOUR 88 SLIM	54	15	6						

DJ AND RECORDING

GDJ-2500	18	17	6.5						
G-MEDIA PRO BP	15	12	4						
G-MEDIA PROBPXL	20	12	4						
G-TOUR CD-13X17	17	13	4.25						
G-TOUR CD-9X12	12.5	9	4.25						
G-TOUR CDMX1317	17	13	4.25						
G-TOUR CDMX912	12.5	9	4.25						

PROJECTOR AND LAPTOP

GAV-1412-R	14	12	4						
GAV-1813-UR	18	13	4						
GAV-20	14	10.5	3.5						
GAV-DLX-1412R	14	12	4						
GAV-DLX-20	14	10.5	3.5						
GAV-PE-1412R	14	12	4						
G-TOURCARRYONPL	11.15	9.06	5.9						

LCD

G-LCD-4042	41.5	5	30						
G-LCD-4647	45.5	5	30						
G-LCD-5052	52	5	32						
G-LCDCOVER-3819	38	6	19						
G-LCDCOVER-42	43	6	26						
G-LCDCOVER-52	52	6	33						
G-LCDCOVER-65	63	6	40						
G-TOURLCD-3743T	42.5	7	28						
G-TOURLCDLIFT52	52	7	34						
G-TOURLCDLIFT65	66	7	38						
G-TOURLCDP-2023	24	7	20.13						
G-TOURLCDP-2632	32.5	7	25.75						
G-TOURLCDP50	50.13	8	32.5						
G-TOURLCDP60	58.33	8	36.25						

MICROPHONE

GM-1W	8.5	8.5	2						
GM-1WEVAA	8	8	1.75						
GM-1WP	8.5	8.5	2						
GM-2W	8.5	8.5	3.25						
GM-4WR	11	16	1.5						

Model	Length	Width	Height	Overall Length	Lower Bout Width	Middle Bout Width	Upper Bout Width	Body Length	Body Height
GM-5W	8.5	7	4						
GM-7W	9.5	5.5	1.75						
G-TOUR WIRELES4									
MIXER									
GMC-2222	22	22	6						
GMC-3333	33	33	6						
GMC-4221	42	21	6						
G-MIX 12X24	23.25	12	4.25						
G-MIX 17X18	17.75	17.25	6.5						
G-MIX 19X21	21	19	7						
G-MIX 20X25	25	20	8						
G-MIX 20X30	29.13	20	6						
G-MIX 22X46	46	22	6.5						
G-MIX 24X36	35.13	24	6.5						
G-MIX-B 1212	12	11.75	5.5						
G-MIX-B 1515	15.13	14.75	5.5						
G-MIX-B 1815	18.5	15	6.5						
G-MIX-B 1818	18	17.75	5.5						
G-MIX-B 2020	20	20	5.5						
G-MIX-B 2118	21	18.5	7						
G-MIX-B 2519	25	19	8						
G-MIX-L 1224	24	12	5						
G-MIX-L 1618A	18	16	6						
G-MIX-L 1622	22	16	5						
G-MIX-L 1724	24	17	5						
G-MIX-L 1822	22	18	7						
G-MIX-L 1926	26	19	6						
G-TOUR 12X17	17	12	7.5						
G-TOUR 19X21	21	19	7						
G-TOUR 20X25	25	20	8						
G-TOUR 20X30	30	20	6.5						
G-TOUR 24X36	36	24	5.5						
SPEAKER									
GPA-450-515	15	15.75	26						
GPA-600	16.5	16.5	23.25						
GPA-700	17.5	18	27.5						
GPA-720	13	13.5	20						
GPA-777	17.5	18	27.5						
GPA-E15	15	15.75	26						
GPA-SCVR450-515	14.8	17.3	27						
G-SUB2225-24BAG	22	24	26.25						
UTILITY									
GP-PC300	45	19	12						
GP-PC301	30	24	16						
GP-PC303	29	17	17						
GP-PC304	36	16	12						
GP-PC308	30	12	14						
GP-PC309	24	12	24						
GP-PC314	25	12	10						
G-TOUR 12X17	17	12	7.5						
G-TOURCARRYONFO	19	12.25	4.5						
GX-1	17.5	12.25	5.25						
GX-1224-8	24	12	8						
GX-1718-7	18	17	7						
GX-1921-7.5	21	19	7.5						
GX-1928-17	28	19	17						
GX-2	17.5	12.25	7.75						
GX-3	17.5	12.25	7.75						
GX-42	32.75	16.25	7.25						
GX-BAG-1313-15	15	13	13						
GX-BAG-2112-12	21	12	12						



Master Cross Reference Chart

Interior Case Dimensions

Metric

Model	Length	Width	Height	Overall Length	Lower Bout Width	Middle Bout Width	Upper Bout Width	Body Length	Body Height
GUITAR									
G-112A	635	305	495						
G-112-ROTO	597	318	533						
G-212A	762	305	610						
G-212-ROTO	679	318	533						
G-901	762	267	318						
GC-BASS				1207	349	349	349	540	76
GC-DREAD				1060	419	318	330	584	133
GC-DREAD-12				1108	413	298	314	600	133
GC-ELECTRIC-A				1016	324	324	324	492	83
GC-ELEC-XL				1067	324	324	324	476	89
GC-JUMBO				1118	438	279	318	533	140
GC-LPS				1048	337	197	235	457	95
G-COBRA-BASS				1194	381	330	305	533	89
G-COBRA-CLASS				1029	387	260	292	508	95
G-COBRA-DREAD				1054	406	330	305	559	140
G-COBRA-ELEC				965	324	375	368	508	89
G-COM-BASS				1194	381	330	305	533	89
G-COM-DREAD				1054	406	330	305	559	140
G-COM-ELEC				965	324	375	368	508	89
GC-SG				1029	343	254	279	432	57
GL-AC-BASS				1283	438	305	349	635	165
GL-BASS				1207	346	346	346	533	76
GL-CLASSIC				1041	394	260	298	521	114
GL-DREAD				1060	406	318	318	540	127
GL-DREAD-12				1092	406	318	330	546	127
GL-ELECTRIC				1003	324	324	324	483	86
GL-JUMBO				1133	448	289	330	591	140
GL-LPS				1073	352	238	254	549	86
GL-SG				1026	346	251	283	451	51
G-MULTIFX-1110	286	260	108						
G-MULTIFX-1510	394	267	127						
G-MULTIFX-2411	610	286	121						
GPE-335-TSA				1092	419	292	330	572	114
GPE-BASS-TSA				1210	346	346	346	537	67
GPE-CLASSIC-TSA				1016	394	267	292	540	114
GPE-DREAD-TSA				1054	419	324	349	572	121
GPE-ELEC-TSA				1003	324	324	324	489	83
GPE-LPS-TSA				1067	337	197	241	470	83
GSLING-BASS				1207	406	356	318	533	64
GSLING-CLASS				1029	406	343	292	508	102
GSLING-DREAD				1080	394	318	324	559	102
GSLING-ELEC				1029	387	356	368	559	102
G-TOUR AMP HEAD	813	305	356						
G-TOUR AMP2226	660	330	559						
G-TOUR AMP2430	762	330	610						
G-TOUR BASS				1168	356	279	330	533	64
G-TOUR DREAD-12				1105	425	292	305	565	146
G-TOUR ELEC				1019	324	324	324	489	64
G-TOUR LPS				1016	330	330	330	457	89
G-TOUR-4X12-CAB	813	432	813						
GW-BASS				1194	330	330	330	552	95
GW-BASS-TW				1175	330	330	330	540	89
GW-CLASSIC				1041	394	292	305	591	127
GW-CLASSIC-TW				1054	381	292	298	508	95
GW-DREAD				1092	419	298	305	565	140
GW-DREAD-TW				1080	419	311	324	464	140
GWE-ACOU-3/4				965	349	248	260	483	121
GWE-BASS				1187	324	324	324	559	83
GWE-CLASSIC				1035	368	267	292	597	114
GWE-DREAD 12				1105	429	333	346	572	140
GWE-ELEC				1003	330	330	330	479	79
GWE-ELEC TW				1003	322	322	322	466	84
GW-ELECTRIC				1029	318	318	318	483	83
GW-ELECTRIC-TW				1016	324	324	324	476	76
GW-ELECT-VIN				1016	324	324	324	476	76
GWE-LPS CAMO				1016	356	248	254	540	114

Model	Length	Width	Height	Overall Length	Lower Bout Width	Middle Bout Width	Upper Bout Width	Body Length	Body Height
GWE-LPS-BLK				1016	356	248	254	540	114
GW-JUMBO				1130	438	286	330	597	140
GW-JUMBO-TW				1130	438	286	330	597	140
GW-LP-BROWN				1003	343	241	241	521	108
GW-LPS				1003	343	241	241	521	108
GW-LPS-TW				1003	343	241	241	521	108
GW-SG-BROWN				1029	330	229	267	502	83

KEYBOARD

GK-2110	572	292	102						
GK-4212	1073	305	140						
GK-49	965	381	140						
GK-61	1092	445	165						
GK-76	1308	457	159						
GK-88	1461	457	152						
GK-88 SLIM	1372	381	152						
GKB-49	940	381	127						
GKB-61	1092	445	165						
GKB-76	1308	457	159						
GKB-88	1461	457	159						
GKB-88 SLIM	1372	381	152						
GKC-1540	1092	445	165						
GKC-1648	1501	584	178						
GK-LT25W	635	305	76						
GKPE-49-TSA	927	318	102						
GKPE-61-TSA	1118	441	152						
GKPE-76D-TSA	1302	508	203						
GKPE-76-TSA	1302	457	152						
GKPE-88SLIM-TSA	1372	381	152						
GKPE-88SLXL-TSA	1499	381	152						
GKPE-88-TSA	1499	483	168						
G-TOUR 61	1118	441	152						
G-TOUR 76	1302	457	152						
G-TOUR 88	1499	483	168						
G-TOUR 88 SLIM	1372	381	152						

DJ AND RECORDING

GDJ-2500	457	432	165						
G-MEDIA PRO BP	381	305	102						
G-MEDIA PROBPXL	508	305	102						
G-TOUR CD-13X17	432	330	108						
G-TOUR CD-9X12	318	229	108						
G-TOUR CDMX1317	432	330	108						
G-TOUR CDMX912	318	229	108						

PROJECTOR AND LAPTOP

GAV-1412-R	356	305	102						
GAV-1813-UR	457	330	102						
GAV-20	356	267	89						
GAV-DLX-1412R	356	305	102						
GAV-DLX-20	356	267	89						
GAV-PE-1412R	356	305	102						
G-TOURCARRYONPL	283	230	150						

LCD

G-LCD-4042	1054	127	762						
G-LCD-4647	1156	127	762						
G-LCD-5052	1321	127	813						
G-LCDCOVER-3819	965	152	483						
G-LCDCOVER-42	1092	152	660						
G-LCDCOVER-52	1321	152	838						
G-LCDCOVER-65	1600	152	1016						
G-TOURLCD-3743T	1080	178	711						
G-TOURLCDLIFT52	1321	178	864						
G-TOURLCDLIFT65	1676	178	965						
G-TOURLCDP-2023	610	178	511						
G-TOURLCDP-2632	826	178	654						
G-TOURLCDP50	1273	203	826						
G-TOURLCDP60	1482	203	921						

MICROPHONE

GM-1W	216	216	51						
GM-1WEVAA	203	203	44						
GM-1WP	216	216	51						
GM-2W	216	216	83						
GM-4WR	279	406	38						

Model	Length	Width	Height	Overall Length	Lower Bout Width	Middle Bout Width	Upper Bout Width	Body Length	Body Height
GM-5W	216	178	102						
GM-7W	241	140	44						
G-TOUR WIRELES4									
MIXER									
GMC-2222	559	559	152						
GMC-3333	838	838	152						
GMC-4221	1067	533	152						
G-MIX 12X24	591	305	108						
G-MIX 17X18	451	438	165						
G-MIX 19X21	533	483	178						
G-MIX 20X25	635	508	203						
G-MIX 20X30	740	508	152						
G-MIX 22X46	1168	559	165						
G-MIX 24X36	892	610	165						
G-MIX-B 1212	305	298	140						
G-MIX-B 1515	384	375	140						
G-MIX-B 1815	470	381	165						
G-MIX-B 1818	457	451	140						
G-MIX-B 2020	508	508	140						
G-MIX-B 2118	533	470	178						
G-MIX-B 2519	635	483	203						
G-MIX-L 1224	610	305	127						
G-MIX-L 1618A	457	406	152						
G-MIX-L 1622	559	406	127						
G-MIX-L 1724	610	432	127						
G-MIX-L 1822	559	457	178						
G-MIX-L 1926	660	483	152						
G-TOUR 12X17	432	305	191						
G-TOUR 19X21	533	483	178						
G-TOUR 20X25	635	508	203						
G-TOUR 20X30	762	508	165						
G-TOUR 24X36	914	610	140						
SPEAKER									
GPA-450-515	381	400	660						
GPA-600	419	419	591						
GPA-700	445	457	699						
GPA-720	330	343	508						
GPA-777	445	457	699						
GPA-E15	381	400	660						
GPA-SCVR450-515	376	439	686						
G-SUB2225-24BAG	559	610	667						
UTILITY									
GP-PC300	1143	483	305						
GP-PC301	762	610	406						
GP-PC303	737	432	432						
GP-PC304	914	406	305						
GP-PC308	762	305	356						
GP-PC309	610	305	610						
GP-PC314	635	305	254						
G-TOUR 12X17	432	305	191						
G-TOURCARRYONFO	483	311	114						
GX-1	445	311	133						
GX-1224-8	610	305	203						
GX-1718-7	457	432	178						
GX-1921-7.5	533	483	191						
GX-1928-17	711	483	432						
GX-2	445	311	197						
GX-3	445	311	197						
GX-42	832	413	184						
GX-BAG-1313-15	381	330	330						
GX-BAG-2112-12	533	305	305						