



Pan Mode

Normal	Track #	Mark	Pan
Shift	Track #	Chan Type	Motor On/Off

Send Mode

Page 1	Send Level	Send On/Off	Send Pre/Pst
Shift	Track #	Chan Type	Motor On/Off

EQ Mode

Page 1	Gain	Freq	Q
Shift	Track #	Chan Type	Motor On/Off

Plug-In Mode

Page1	InsParam	InsParam	InsParam
Shift	Track #	Chan Type	Motor On/Off

Auto Mode

Page 1	All on/off	Rd Toggle	Wr Toggle
Shift	Track #	Chan Type	Motor On/Off

Notes

On/Off type controls can sometimes be toggled by pushing the encoder.
 F1/F2 are used to step up/down EQ Bands, Sends, and Insert Parameters.
 **Indicates user-programmable functions.