



Digital Performer Layout

Freq **Gain** **Q**
 40Hz 3dB 1.0

FootSwitch
 Record

ANY SOLO
 AUTO
 WRITE
 READ

Arm Track
 All Safe

Solo Track
 Clear Solos

Mute Track
 Clear Mutes

LEGEND
 Normal
 Shift

PAN SEND EQ PLUG-IN AUTO

Opt+F1** Opt+F2** Opt+F3** Opt+F4**
 Shift+Opt+F1** Shift+Opt+F2** Shift+Opt+F3** Shift+Opt+F4**

Next Track Prev Track Toggle Loop Flip
 Set Loop In Set Loop Out Toggle Punch Toggle Window

RTZ END ESC ENTER MODE
 Rewind Fast Forward Stop Play Record
 Return to Zero Go To End Hardware Setup Enter Key Save

Left Tap **One Finger** **Two Finger** **Right Tap**
 Prev Mark Scrub Shuttle Next Mark



Pan Mode

Normal	Track #	Mark	Pan
Shift	Track #		Motor On/Off

Send Mode

Page 1	Send #	Send Lvl	Send Pan
Page 2	Send Mute	Pre/Post	
Shift	Track #		Motor On/Off

EQ Mode

Page 1	Freq	Gain	Q
Page 2	Band	Filter	Bypass
Shift	Track #		Motor On/Off

Plug-In Mode

Page1	Insert	Parameter	Value
Shift	Track #		Motor On/Off

Auto Mode

Page 1	Auto Mode	Rd Toggle	Wr Toggle
Page 2	Auto On/Off		
Shift	Track #		Motor On/Off

Notes

On/Off type controls can sometimes be toggled by pushing the encoder.
 ** invokes user-programmable keyboard functions.