



Pro Tools Layout

Vox3 SendB DVrb
Post ##--

FootSwitch
Record

ANY SOLO
AUTO
WRITE
READ

Rec Arm Track
Clear All Recs

Solo Track
Clear All Solos

Mute Track
Clear All Mutes

SHIFT

LEGEND
Normal
Shift

PAN SEND EQ PLUG-IN AUTO

Zoom In Zoom Out Scrub/Shuttle Undo
Pre-roll Post-roll Audition Redo

Previous Track Next Track Loop On/Off Flip (Send)
Set In Point Set Out Point Quickpunch Edit/Mix

RTZ END ESC ENTER MODE

Rewind FForward Stop Play Record
Return To Zero Go To End ESC (locals) ENTER Clear Clips

Left Tap **One Finger** **Two Finger** **Right Tap**
(unused) Jog/Scrub Shuttle (unused)

FRONTIER



Pan Mode

LED Solid	Track Select	Pan Left/Mono
LED Flash	Track Select	Pan Right

Send Mode

	SEND Select	SEND Level
	Push=Pre/Post	
with SHIFT	Track Select	SEND Select
with SHIFT	Push = SMute	
FLIP	SEND Select	SEND Pan Left

EQ Mode

	Q	Frequency	Gain
with SHIFT	Band Select	On/Off	Band Type

Plug-In Mode

	Insert Select	Param Select	Param Value
		Push=Bypass	Push=Toggle
with SHIFT	Track Select	Push = AllByp	

Auto Mode

	Track Select	Track Mode	Auto Select
			Push=On/off

Notes

STOP+PLAY = 1/2 speed play
 STOP+RECORD = change record mode
 STOP+REC = save
 STOP+SOLO = online on/off
 STOP+MUTE = motor on/off