




## USB Turntable (iTUSB05)



### Quick Start Owner's Manual (*ENGLISH*)

#### Box Contents:

1. iTUSB05 Turntable
2. Dust Cover
3. Slipmat
4. USB Cable
5. CD
6. 45RPM Adapter

### Manual de inicio rápido para el usuario (*ESPAÑOL*)

#### Contenido de la caja:

1. Giradiscos iTUSB05
2. Cubierta antipolvo
3. Alfombrilla
4. Cable USB
5. CD
6. Adaptador para 45 RPM

### Kurzbedienungsanleitung (*DEUTSCH*)

#### Inhalt der Verpackung:

1. iTUSB05 Turntable
2. Staubabdeckhaube
3. Matte für den Plattenteller
4. USB Kabel
5. CD
6. 45RPM Adapter

### Guide d'utilisation rapide (*FRANÇAIS*)

#### Contenu de la boîte :

1. Tourne-disque iTUSB05
2. Couverture anti-poussière
3. Tapis
4. Câble USB
5. Disque compact
6. Adaptateur 45 t/min

### Manuale Rapido di Utilizzazione (*ITALIANO*)


#### Contenuti della confezione:

1. Giradischi iTUSB05
2. Coperchio antipolvere
3. Tappetino
4. Cavo USB
5. CD
6. Adattatore 45 giri



## **QUICK START GUIDE (ENGLISH)**

- Make sure all items listed on the front of this guide are included in the box.
- **READ SAFETY INSTRUCTION BOOKLET BEFORE USING THE PRODUCT**
- Go to <http://www.ion-audio.com> for product registration.



### **GENERAL CONTROLS**

1. **Power Cable:** This power cable should be plugged into a wall receptacle **AFTER** all audio connections are made.
2. **RCA Audio Output Cables:** These cables should be plugged into the audio inputs of your home stereo system. (Please note: you can still copy records to your computer, even if the audio outputs of the turntable are not connected to a stereo system. It is also possible to hear your records through your computer, as long as you have configured your computer's sound input and output options correctly and enabled Software

Playthrough in the Audacity software. Please see the Software Guide for more information on configuring your computer to play the audio from the turntable.

**IMPORTANT WARNING: The RCA cables are LINE level. Please only connect these cables to LINE level inputs. You may damage your receiver if you plug in a LINE level into a PHONO input.**

3. **USB Audio Output:** Use the included USB Cable to connect your turntable to your computer. Refer to the software instruction guide before plugging in your turntable.
4. **Tonearm:** The tonearm can be raised and lowered by hand, or by pressing the Raise/Lower button.
5. **Platter:** Put the record you would like to play on this platter.
6. **Raise/Lower Button:** Press this button in to raise the tonearm. To lower the tonearm, press this button so it is in the out position.
7. **Stop:** Press this button to stop playback. When this button is pressed, the tonearm will return back to its original resting position.
8. **Speed 33/45 RPM:** This button controls the playback speed of the record. Depending on what kind of record you are playing, you will need to adjust the speed to match the speed of the record (or else the music might sound too slow or too fast).

### **IMPORTANT**

Make sure that the felt slipmat is always placed on top of the platter while using the turntable. Failure to use the slipmat may cause damage to your media as well as damage to the turntable.

Remove the plastic cartridge cover (needle cover) before operating the turntable.

**BEFORE RETURNING THE PRODUCT, please contact Ion Audio or your retailer for technical support. Contact information can be found in the Safety Instruction Booklet included with this product.**

# Specifications (iTTUSB05)

Manual Version: 1.1

## Part List:

- iTTUSB05 Turntable
  - Slipmat
  - RCA Cable connected
- USB Cable Included
- 45 RPM Adapter Included
- Software CD (MAC/PC)
- Software User Manual
- Hardware Quick Start Guide

Turntable Weight: 5.3 lbs

Product Dimensions: 13-3/8" x 16-1/2" x 4-5/6"

Motor: Belt Drive

Speed: 33 1/3 RPM or 45 RPM operation

Outputs: RCA (LINE), USB Audio.