



THIS IS THE OCTAHIVE V2, ONE OF OUR LEGENDARY BEES THAT HAS BEEN BUZZING SINCE DAY ONE! THIS PEDAL DRAWS INSPIRATION FROM THE ICONIC '70S OCTAVE PEDALS, BLENDING VINTAGE TONES WITH MODERN ENHANCEMENTS.

IN BUZZZ MODE, PREPARE TO UNLEASH A FEROCIOUS HIGH-GAIN FUZZ THAT'S PERFECT FOR LOW RIFFAGE AND POWERFUL CHORDS. ENTER THE MYSTICAL OCTAVE MODE AND WATCH AS YOU'RE TRANSPORTED TO A MIND-BENDING PSYCHEDELIC WONDERLAND. AND HERE'S A TIP FIT FOR A QUEEN BEE: ROLL DOWN THE PRE CONTROL, SWITCH TO YOUR NECK PICKUP, AND WATCH THOSE BEAUTIFUL OCTAVE HARMONICS TAKE CENTER STAGE.

BUT THAT'S NOT ALL! WE'VE MATCHED VINTAGE TONE WITH CUTTING-EDGE FEATURES TO ENHANCE YOUR PLAYING EXPERIENCE. HOLD THE FOOTSWITCH TO INSTANTLY SWITCH FROM BUZZZ TO OCTAVE, GIVING YOU COMPLETE CONTROL OVER YOUR SONIC DESTINY. AND WITH A QUICK DOUBLE TAP, SEAMLESSLY SHIFT BETWEEN MODES, KEEPING YOUR CREATIVE FLOW BUZZING.

WITH THREE FOOTSWITCH PROFILES, YOU CAN CUSTOMIZE THE SPEED OF YOUR MOMENTARY SWITCHING. IT'S ALL ABOUT TAILORING THE PEDAL TO PERFECTLY SUIT YOUR UNIQUE VIBE!

THE OCTAHIVE V2 IS HERE TO DELIVER THE SWEETEST HIGH OCTAVE BUZZ AND ALLOW YOUR CREATIVITY TO SOAR. EMBRACE THE HIVE MAGIC AND LET YOUR SOUND BEE HEARD LIKE NEVER BEFORE!

•PRE•
LEVEL BEFORE CIRCUIT

BUZZZ MODE
INDICATOR

•OUTPUT•

2.1MM +9VDC JACK

CENTER NEGATIVE POLARITY

CURRENT DRAW - 50MA

EFFECT ON/OFF
INDICATOR

PEDAL DIMENSIONS:
4-1/2" X 2-1/2" X 2-1/4"

INPUT IMPEDANCE: 100K

OUTPUT IMPEDANCE:

~1K TO ~500K

(DEPENDING ON THE VOL POT)



•VOL•
MASTER VOLUME

•HONEY•
GAIN CONTROL

OCTAVE MODE
INDICATOR

•INPUT•

•FOOTSWITCH•
SINGLE TAP
ON/OFF
DOUBLE TAP
SWITCH BETWEEN
BUZZZ / OCTAVE

BEEWARE! BEETRONICS WILL REPAIR/REPLACE ANY MALFUNCTIONING PRODUCT WITHIN A YEAR OF THE PURCHASE DATE. ANY DAMAGE CAUSED BY MODIFICATIONS OR MISUSE MAY CANCEL THIS WARRANTY.

MADE IN CALIFORNIA

Family Beezness

FOOTSWITCH PROFILE SETTING

SINCE THE OCTAHIVE V2 FOOTSWITCH CAN PERFORM MULTIPLE FUNCTIONS, WE HAVE DESIGNED UNIQUE FOOTSWITCH PROFILES FOR THE MOMENTARY CHANGE SPEED (HOLD).

TO SELECT YOUR DESIRED FOOTSWITCH PROFILE, FOLLOW THESE STEPS:

1. DISCONNECT THE POWER FROM THE PEDAL.
2. HOLD DOWN THE FOOTSWITCH.
3. RECONNECT THE POWER WHILE CONTINUING TO HOLD THE FOOTSWITCH.
4. YOU CAN NOW CHOOSE ONE OF THE THREE FOOTSWITCH PROFILES.

THE AVAILABLE PROFILES ARE AS FOLLOWS:

- FAST (20MS) - BUZZZ LED ON (WHITE)
- MEDIUM (100MS) - OCTAVE LED ON (BLUE)
- LAZY (250MS) - BOTH LEDS ALTERNATING

TO CYCLE THROUGH THE PROFILES, SIMPLY TAP THE FOOTSWITCH ONCE. TO SELECT A PROFILE, HOLD DOWN THE FOOTSWITCH.

ONCE YOU HAVE CHOSEN A PROFILE, THE PEDAL WILL RESUME PLAYING AND YOUR SELECTED PROFILE WILL BE SAVED UNTIL YOU DECIDE TO CHANGE IT AGAIN.

ADDITIONALLY, THE OCTAHIVE V2 WILL REMEMBER ITS LAST STATE BEFORE THE POWER WAS TURNED OFF.

FOR EXAMPLE, IF YOU HAD THE EFFECT ENGAGED IN OCTAVE MODE WHEN POWERING OFF, THE PEDAL WILL AUTOMATICALLY POWER ON WITH THE EFFECT ENGAGED IN OCTAVE MODE WHEN YOU RECONNECT THE POWER.