

Rescue1350



Owner's Manual

Specifications

POWER

USB INPUT: 5V DC

USB OUTPUT: 5V DC 1A

BATTERY

1350 mAh Lithium-Ion

This package includes:

- Rescue1350
- xePowerPack Battery
- USB A to USB Micro B Cable
- Velcro cable strap

CAUTION: Changes or modifications not expressly approved by Revolve Electronics, Inc. for compliance with FCC rules and regulations could void authority to operate this equipment.

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to instructions. xePowerPack battery is designed exclusively for use with Revolve Electronics products. DO NOT USE WITH ANY OTHER PRODUCTS.

How to Use the Rescue1350

The Rescue1350 has been designed to provide reliable battery backup power for charging USB-powered devices on the go. No matter what conditions you find yourself in, Rescue1350's all-weather enclosure means you will always have a ready supply of emergency power anywhere, anytime. Plus, all Rescue series products are made using Revolve's exclusive Earth Friendly Electronics®, offering unique features and utilizing advanced materials and processes that are all designed to enhance sustainability and minimize impact on the environment.


IMPORTANT: Confirm Rescue1350 power input and output requirements match external device(s) before making connections.

1 Connect to Power

Charge the Rescue1350 by connecting power input to an external **USB 5V DC** power source such as an AC adapter, computer or car charger.


2 Charge External Device

Connect an external device that accepts 5V DC power (USB standard) and requires 1.2A or less to the Rescue1350's USB power output using USB cable.



Cable Strap

To install the cable strap for storing your USB cables, insert one end of the strap into the slot, slide it under the rubber cover, and thread back up through the opposite slot.




The Battery

Checking Battery Status


To determine the amount of energy stored in the xePowerPack, press the Battery Status Button.

Green, yellow & red lights = fully charged;
yellow and red lights = medium charge;
red light only = low charge, recharge now!



Removing the Battery

- 1 Carefully remove the rubber cover.
- 2 Insert pin or paper clip into hole.



- 3 Slide battery cover off and remove battery.



Replacing the Battery

The xePowerPack is an advanced lithium-ion battery designed for years of service. To obtain a replacement battery and participate in our hassle-free battery recycling program, contact product support at www.revolveusa.com or by calling us toll-free at (800) 693-0068.

CAUTION: The Rescue1350 is designed to work exclusively with Revolve's xePowerPack, which is included in this package. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries as instructed in this manual.

Limited Warranty

Revolve Electronics, Inc. ("the Company") warrants to the original purchaser that this equipment will be free from defects in materials and workmanship for a period of 1 (one) year from the original date of purchase. If a defect exists that is covered by this Limited Warranty, the Company will, at its sole option, (i) repair the product at no charge, using new or refurbished replacement parts, (ii) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product, or (iii) refund the purchase price of the product. A replacement product/part assumes the remaining warranty of the original product or ninety (90) days from the date of replacement or repair, whichever provides longer coverage for you. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes the Company's property. When a refund is given, your product becomes the Company's property. All warranty returns must be sent with postage and insurance prepaid.

LIMITATIONS

This Limited Warranty applies only to hardware products manufactured by or for the Company. This Limited Warranty does not apply to any non-Company hardware products or any equipment, even if packaged or sold with Company hardware. This warranty does not apply: (a) to damage caused by accident, abuse, misuse, misapplication, or non-Company products; (b) to damage caused by service (including upgrades and expansions) performed by anyone other than the Company; (c) to a product or a part that has been modified without the written permission of the Company; or (d) if any Company serial number has been removed or defaced.

Responsibility is limited to the actual cost of the item. Revolve Electronics, Inc. will not be responsible for expenses or inconveniences, or consequential damages occasioned by equipment, or by breach of any expressed or implied warranty with respect thereto. Implied warranties on this item shall be in effect only for duration of the expressed warranty set forth above and after the expiration of such expressed warranty there shall be no warranties, expressed or implied (including merchantability) on the product.

To obtain service for your Rescue1350, contact the Revolve Electronics Support department either online at www.revolveusa.com or by calling (800) 693-0068.

Revolve Electronics, Inc.
2151 Alessandro Dr, Ste. 250
Ventura, CA 93001
Phone (800) 693-0068
Fax (805) 435-2063

©2011 Revolve Electronics, Inc.
All Rights Reserved.