

Marshall

Micro
Stack

MS-4




Marshall Amplification plc

Denbigh Road, Bletchley, Milton Keynes, MK1 1DQ, England

Tel: (01908) 375411 Fax: (01908) 376118 Web: www.marshallamps.com

MS-4



Gain

Adjusts the amount of pre-amp gain. High gain setting will produce more distortion and sustain

Volume Control
Controls volume level

Tone Control
Bass to treble tone
control

ON/OFF

On/Off
Status
Indicator

Headphone
socket

For connection
to headphones
(mutes internal
socket)

Pull-out Stand

Battery

compartment —
Use PP3 or
equivalent battery



Input
For connection
to the guitar

Mains adaptor
socket

9V $\equiv$ 100mA



English