Typical SOLO/610 or SOLO/110 Instrument Setup



Switch Positions
(SOLO/610 or SOLO/110)

FRONT

MIC / DI: DI
LO-Z / HI-Z: either
+48V / OFF: OFF
LO CUT / FLAT: FLAT
OUTø / INø: IN

REAR

MIC / LINE: match to mixer input
LIFT / GND: If humming, LIFT

Typical SOLO/610 or SOLO/110 Microphone Setup



Switch Positions
(SOLO/610 or SOLO/110)

FRONT

MIC / DI: MIC
LO-Z / HI-Z: either
+48V / OFF: +48V if needed
LO CUT / FLAT: LO CUT if needed
OUTø / INø: IN

REAR

MIC / LINE: LINE
LIFT / GND: GND