

WARNING! - Important safety instructions

WARNING: This apparatus must be earthed!

- A. PLEASE read this instruction manual carefully before switching on.
- **B.** ALWAYS use the supplied mains lead, if a replacement is required please contact your authorised Marshall Dealer.
- C. NEVER attempt to by-pass the fuses or fit ones of the incorrect value.
- D. DO NOT attempt to remove the amplifier chassis, there are no user serviceable parts.

E. Refer all servicing to qualified service personnel.

Servicing is required when the apparatus has been damaged in any way, such as when the power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally or has been dropped.

- F. NEVER use an amplifier in damp or wet conditions. No objects filled with liquids should be placed on the apparatus.
- G. ALWAYS unplug this apparatus during lightning storms or if unused for long periods of time.
- **H. PROTECT** the power cord from being walked on or pinched particularly at plugs, convenience receptacles and at the point where they exit from the apparatus.
- I. DO NOT switch the amplifier on without the loudspeaker(s) connected.

O Note: This equipment has been tested and found to comply with the requirements of the EMC directive (Environments E1, E2 and E3 EN 55103-1/2) and the Low Voltage directive in the E.U.

C EUROPE ONLY - Note: The Peak Inrush current for the MG50DFX is 9.6 amps. The Peak Inrush current for the MG250DFX is 19.8 amps.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance may void the users authority to operate the equipment.

C Note: It is recommended that all audio cables, with the exception of the speaker lead, used to connect to the MG50DFX and MG250DFX are of a high quality screened type. These should not exceed 10 metres in length.

Always use a non-screened Marshall approved speaker lead when connecting an extension cabinet to these units.

O WARNING: Always ensure free movement of air around the amplifier!

USA ONLY - DO NOT defeat the purpose of the polarised or grounding type plug. A polarised
plug has two blades with one wider than the other. A grounding type plug has two blades and a
third grounding prong. The wide blade or the third prong are provided for your safety. When the
provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

Follow all instructions and heed all warnings

KEEP THESE INSTRUCTIONS !

From Jim Marshall

UL U I would like to personally thank you for selecting one of my new MG range of combos – the MG50DFX 1x12" or the stereo MG250DFX 2x12".

As a musician myself, I fully understand what it takes to perform live in a band situation. In addition to talent, dedication and a lot of hard work, you also need equipment that will help you deliver the goods in each and every playing situation you find yourself in. With this goal firmly in mind, I set my experienced R&D team the task of designing a new range of affordable MG amplifiers that will deliver the tone you're looking for at all volume levels – from quiet late night practice to a full-blown live gig and all points in-between – in the way only a Marshall can.

Utilising groundbreaking new technologies, some of which were developed for our critically acclaimed AVT range, the new MG Series raises the standard for what can be expected from a value-for-money range of guitar amplifiers and defines a new benchmark. For example, the power amp section of your new combo boasts FDD (Frequency Dependent Damping) – a radical new feature that is exclusive to Marshall Amplification and accurately mimics the way our all-valve amplifiers interact with a loudspeaker. As a direct result of FDD, your new MG50DFX/MG250DFX will give you a sound and feel never before thought possible in such an affordable, non-valve amp.

The DFX (Digital Effects) featured in both the MG50DFX and MG250DFX have been custom voiced by our in-house digital effects experts. Each one of the five effect types on offer (Chorus/Delay, Delay, Chorus, Flange and Reverb) have been designed to emulate the much sought after warmth and feel of analogue effects, but in a highly flexible digital format. Furthermore, a wide range of variations for each effect are quite literally at your fingertips – merely tweaking the three DFX controls (Preset/Adjust & FX Level controls for the Chorus/Delay, Delay, Chorus and Flange options; and a separate Level control for the Reverb) on the front panel, will give rise to sounds that range from subtle to radical, while always remaining both natural and musical.

Like all the amplifiers in the new MG range, state-of-the-art manufacturing and stringent quality control procedures ensure that these combos meet the high standard of build you have come to expect from all Marshall products. The MG50DFX and MG250DFX were completely designed and engineered at my Headquarters in Milton Keynes, England.

Whether the MG50DFX or MG250DFX is your first ever Marshall, or is the latest addition to your arsenal of amps, the tone, flexibility and feel of these compact, rugged combos is guaranteed to deliver the goods – from bedroom to backstage to onstage!


I wish you every success with your new Marshall. Welcome to the family...

Yours Sincerely,

Tim Masshall



MG50DFX & MG250DFX Front Panel Features



1. INPUT jack

Use a good quality guitar cable (i.e. one that's screened/shielded) to plug your guitar in here.

2. Clean Channel GAIN control

When the Clean Channel is selected, this control adjusts its volume. At low settings the sound will be very clean with a pleasing, bell-like ring. Turning this control above half way will introduce a desirable, bluesy distortion as the power amplifier stage is driven into 'crunch mode'.

3. Clean Channel BASS control

Turning up the Bass control will add warmth and low-end depth to your clean sound. The Bass control can be used in conjunction with the FDD switch (17) to produce deep sounding, valve-like clean tones that are well defined yet still full and round.

4. Clean Channel MIDDLE control

Adjusting the middle frequencies in your clean channel will vary the amount of body to your sound. Attenuating (decreasing) the middle by turning this control anticlockwise will yield a more hollow sound with the bass and treble frequencies appearing to be more accentuated. Conversely, increasing the middle will add body to the Clean Channel's sound.

5. Clean Channel TREBLE control

Increasing the Treble will make your clean sounds brighter and more cutting, turning it down will decrease your tones edge and make it sound softer as a result.

6. CHANNEL SELECT switch

This push switch allows you to change between the amp's two channels, Clean and Overdrive, via the front panel. When this switch is 'out' the Clean channel is engaged, pushing it 'in' switches to the Overdrive Channel. Channel switching can also be done via the included two-way footswitch (when the footswitch is connected the CHANNEL SELECT switch is not functional). **Note:** When the Overdrive Channel is selected, the OD LED (7) will light up red.

7. OD LED

When illuminated, this LED indicates that the Overdrive Channel has been selected by either the Channel Select switch (6) or the supplied two-way footswitch.

8. Overdrive Channel GAIN control

Turning up the Gain control will increase the amount of preamp distortion generated in the Overdrive Channel. Low Gain control settings will produce classic rock and blues tones. Crank this control for fat and aggressive sounds that are perfect for soloing or hard rock and nu-metal riffing.

9. Overdrive Channel BASS control

Turning up this control will add extra low-end 'thump' to high gain riffs and a warm, natural sounding depth to lower gain crunch tones. Using the Bass control in conjunction with the FDD switch (17) will allow you to dial in the exact amount of low-end 'thump' and tightness you are looking for.

10. Overdrive Channel CONTOUR control

This highly effective tone control works by radically modifying the mid-range (body) of your sound. The tone can vary from traditional and woody sounding (control set at 0), to balls-to-thewall (control set midway), to aggressive, 'scooped' and modern (turned up to 10) and all points inbetween.

11. Overdrive Channel TREBLE control

This important knob controls the aggressive topend 'sizzle' you have on high gain sounds and the 'cut' and definition of lower gain crunch tones. Experimenting with this control will help you to dial in your own signature tones on your amp.

12. Overdrive Channel VOLUME control

This control adjusts the volume of the Overdrive Channel. The louder you turn-up this channel, the 'looser' your amp will sound and feel – especially with the FDD switch (17) engaged. This behaviour is exactly what a good all-valve amplifier does and is a result of our proprietary FDD circuitry.

13. Digital FX PRESET / ADJUST control

This control serves a dual purpose. Not only does it allow you to select one of the four types of effects on offer (Chorus / Delay (CHR/DLY), Delay (DLY), Chorus (CHR) or Flange (FLG)), it also allows you to adjust a parameter as you sweep it through each of the four effect segments. The parameter you can adjust for each of the four effect segments is shown below:

Effect	Adjustable Parameter	Description
Chorus and Delay (CHR/DLY)	Delay Time (from short to long as you turn the Preset/Adjust control clockwise through the CHR/DLY segment)	This multi-effect combines a lush, fixed speed Chorus with a variable time Delay.
Delay (DLY)	Delay Time (from short to long as you turn the Preset/Adjust control clockwise through the DLY segment)	Short Delay Times will have less repeats for 'groovy' surf and rockabilly tones. Increasing the Delay Time increases the number of repeats for a much more atmospheric, 'stadium' effect.
Chorus (CHR)	Speed (from slow to fast as you turn the Preset/Adjust control clockwise through the CHR segment)	At slow Speeds a mellow, Phase-like sweep occurs. As the Speed is increased a more traditional chorus effect is heard. At maximum Speed, a psychedelic vibrato results.
Flange (FLG)	Speed (from slow to fast as you turn the Preset/Adjust control clockwise through the FLG segment)	At slow Speed settings the amount of regeneration is increased for huge 'jet engine- like' sweeps. As the speed is increased the regeneration decreases to produce a lush, natural sounding Flange effect. When the Speed is maxed out, a fast vibrato results.

14. Digital FX LEVEL control

This controls how much of the chosen effect gets mixed in with your unaffected (dry) guitar tone. Want to hear more of the DFX you've just selected? Then simply turn this control up!

Important Footswitch Note: Using the supplied two-way footswitch, you can switch the selected DFX on/off.

15. REVERB LEVEL control

This control lets you add a lush Reverb to your sound – from a subtle hint to cavernous and all points in-between. Designed by our in-house digital experts, this custom designed Marshall Reverb is highly musical and always sounds natural – it never gets harsh or 'fake' sounding.

Important Footswitch Note: The supplied footswitch does NOT switch the Reverb on/off.

16. MASTER VOLUME control

As its name suggests, the Master Volume control determines the overall volume of your amplifier. So after setting-up the relative volume of Channels 1 & 2 the overall level can be adjusted without affecting your all-important Clean/Overdrive balance.

17. FDD (Frequency Dependent Damping) switch

Marshall's proprietary FDD circuit accurately mimics the way an all-valve amplifier interacts with the loudspeaker(s) and adds a width and depth to your sound which has been unachievable in an affordable solid-state amplifier... until now! To engage FDD simply press this switch in.

18. EMULATED LINE OUT & HEADPHONES jack

This jack can be used as either an Emulated Line Out or as a Headphone output. This means you can use this socket to connect your amp directly to your multi-track recording machine and you'll get a great, speaker emulated guitar sound direct to disk or tape. Alternatively you can plug your headphones in here for a killer, speaker-emulated sound!

TIP: How to practise or record in 'silence': The Clean Channel GAIN control (2) and the Overdrive Channel VOLUME control (12) will control the level of the headphone and line out.

The speaker output can be adjusted independently using the Master VOLUME control(16). Setting the Master VOLUME control(16) to zero will allow silent recording or practice.


19. POWER Switch & LED

The power switch turns your amplifier on and off. The LED will be lit when your amplifier is on and will not be lit when the amplifier is switched off.


Note: Before connecting to the mains electricity supply, always ensure that your amplifier is compatible with your electricity supply, as detailed on the rear panel.

Please ensure the amplifier is switched off and unplugged from the mains electricity supply before being moved.

MG50DFX Rear Panel Features



MG250DFX Rear Panel Features



1. MAINS INPUT Connector

The MG amplifier is provided with a detachable mains (power) lead which is connected here. The specific mains input voltage rating that your amplifier requires is clearly indicated on the back panel. Before connecting to the mains for the first time please make sure that your amplifier is compatible with your electricity supply.

2. LOUDSPEAKER Output(s)

The internal loudspeaker(s) connect here – one in the case of the MG50DFX and two in the case of the MG250DFX.

Always use a non-screened Marshall approved speaker lead when connecting an extension cabinet to these units.

3. CD IN jack

If you want to jam to your favourite CD or tape, merely connect the headphone output of your CD or tape player here, adjust the CD /tape player's volume to match that of your guitar and you've got the perfect 'play-along' practice system.

4. FX RETURN(s)

This is where you connect the output of the effects processor you are using in the effects loop. As the MG250DFX is a stereo amplifier it offers two FX Return jacks – LEFT and RIGHT. This allows you to take full advantage of a stereo effects processor. If, however, the effects unit you are using only has a single, mono output then use the LEFT (MONO) FX Return.

5. FX SEND

If you want to use an external effects processor in your amp's built-in Series effects loop, this is the jack you connect to the INPUT of the unit you are using. For optimum performance, the FX loop is best suited for use with a rack or multi-effects processor which has a manual adjustment for INPUT SIGNAL LEVEL.

6. FOOTSWITCH

Connect the supplied two-way footswitch here. Its left button (marked Channel) enables you to change channels and its right button (marked DFX) allows you to switch the DFX Section on/off.

Important Footswitch Note: The supplied footswitch does NOT switch the Reverb on/off.





Technical Specification Especificaciones técnicas Technische Daten Caractéristiques techniques 技術情報

Techni

Técnicas

Technische


Techniques

技術情報

Power Output	50W RMS into 8 Ω
Potencia de salida	50W RMS sobre 8Ω
Ausgangsleistung	50W RMS an 8Ω
Puissance de sortie	50W RMS sous 8 ohms
パワー出力	50W RMS / 8Ω 接続
Main Guitar • Input Impedance	1 <i>Μ</i> Ω
Impedancia de entrada principal de guitarra	1 <i>Μ</i> Ω
Guitar • Input Eingangsimpedanz	1 <i>Μ</i> Ω
Impédance d'entrée	1 <i>Μ</i> Ω
メインギター・入力インピーダンス	1 <i>Μ</i> Ω
CD Input • Input impedance	5.6k Ω
Impedancia de entrada de CD	$5.6k\Omega$
CD Input • Eingangsimpedanz	5.6kΩ
Impédance d'entrée CD	5.6kΩ
CD入力・入力インピーダンス	5.6kΩ
Emulated Output • Level	+4dBV Nom.
Nivel de salida de línea simulada	+4dBV Nom.
Emulated Output • Ausgangspegel	+4dBV Nom.
Niveau de sortie	+4dBV Nom.
エミュレート出力・レベル	+4dBV Nom.
Weight	16kg
Peso	16kg
Gewicht	16kg
Poids	16kg
重量	16kg
Size (mm)	518mm x 498mm x 275mm
Tamaño (mm)	518mm x 498mm x 275mm
Maße (mm)	518mm x 498mm x 275mm
Taille (mm)	518mm x 498mm x 275mm
サイズ	518mm x 498mm x 275mm

Technical Specification Especificaciones técnicas Technische Daten Caractéristiques techniques 技術情報

Power Output	2 x 50W RMS into 8 Ω
Power Output	
Potencia de salida	2 x 50W RMS sobre 8Ω 2 x 50W RMS an 8Ω
Ausgangsleistung Puissance de sortie	$2 \times 50W$ RMS an δs_2 $2 \times 50W$ RMS sous 8 ohms
Puissance de sonie パワー出力	2 x 50W RMS 5008 8 0000 2 x 50W RMS / 8Q 接続
パジー出力	2 X 50W RIMS / 822 接続
Main Guitar • Input Impedance	1 <i>Μ</i> Ω
Impedancia de entrada principal de guitarra	1 <i>Μ</i> Ω
Guitar • Input Eingangsimpedanz	1 <i>Μ</i> Ω
Impédance d'entrée	1 <i>Μ</i> Ω
メインギター・入力インピーダンス	$1M\Omega$
CD Input • Input impedance	5.6k Ω
Impedancia de entrada de CD	5.6kΩ
CD Input • Eingangsimpedanz	5.6kΩ
Impédance d'entrée CD	$5.6k\Omega$
CD入力・入力インピーダンス	5.6kΩ
Emulated Output • Level	+4dBV Nom.
Nivel de salida de línea simulada	+4dBV Nom.
Emulated Output • Ausgangspegel	+4dBV Nom.
Niveau de sortie	+4dBV Nom.
エミュレート出力・レベル	+4dBV Nom.
Weight	22kg
Peso	22kg
Gewicht	22kg
Poids	22kg
重量	22kg
Size (mm)	671mm x 498mm x 275mm
Tamaño (mm)	671mm x 498mm x 275mm
Maße (mm)	671mm x 498mm x 275mm
Taille (mm)	671mm x 498mm x 275mm
サイズ	671mm x 498mm x 275mm



www.marshallamps.com

Whilst the information contained herein is correct at the time of publication, due to our policy of constant improvement and development, Marshall Amplification plc reserve the right to alter specifications without prior notice.